## 15. TEST SETUP PHOTO

Laptop Mode with Flat Phantom


Tablet Mode 1: Edge - Primary Landscape

*This report shall not be reproduced except in full, without the written approval of CCS.*

Tablet Mode 2: Edge – Secondary Landscape

Tablet Mode 3: Edge – Primary Portrait

Tablet Mode 4: Edge – Secondary Portrait

Both A and C antennas disabled by software

Main Antenna (A)

3rd Antenna (C)

Aux Antenna (B)

Tablet Mode 5: Bottom Face – Lap-held

Main Antenna (A)

3rd Antenna (C)

16. HOST DEVICE PHOTO

LENOVO X200/X201 Tablet – Laptop mode

Aux Antenna (B)

Main Antenna (A)

3rd Antenna (C)

LENOVO X200/X201 Tablet – Tablet mode

B

A

C

END OF REPORT