Label Location

1. Open SIM & MicroSD door
2. Pull out the Label



Note: Any hard copy of this document is for reference only. Due to template and application dependencies the header and footer may fail to display correct data. It is the responsibility of the user to ensure that they have a correct and valid version. Any outdated hard copy is invalid and must be removed from possible use.