尺寸: 70X100MM，材质：100g书纸，1C+1C，风琴折页



Bluetooth Speaker

USER MANUAL

BT117

Package Includes

- 1 xSpeaker
- 1x Micro-USB Cable
- 1 xAUX Cable (Φ3.5mm)
- 1x User Manual

Overvivew of Speaker



Charging

1.Before first time use,fully charge the built-in battery.
2.Connect the USB Type-C Cable (included) between the DC IN port on the speaker,and a USB Type-C Port on a computer or USB AC Adapter.

LED Indicator	Battery Status
/	Low battery(<10%)
Solid Red	Under Charging
Red light off	Full charged

Turn On / Off LED Indicator
Long press the play/pause button ▷

Note: When the battery charge <3%， the speaker will power off automatically.

Power On

Press ⏻ button until hear a rising tone and LED indicator light on.

Power Off

Press ⏻ button until hear a descending tone and LED indicator light off.

Bluetooth connection

Make sure that the speaker is within 10 meters from your mobile device,
1.Press ⏻ button until hear a rising tone and LED indicator fast blinking blue.

2.Go to the Bluetooth settings on your mobile device, search and select “BT117” from the list.
3.Once paired, the LED indicator turns solid blue.

Note:
• When power on, the speaker automatically reconnects to the last mobile device it was connected to. (The speaker can memorize maximum of 8 paired devices).
• The speaker will automatically shut down after 10 minutes in pairing mode if no devices are paired for power saving.

Music Control

Play/Pause …… Click ▷
Volume UP ……..…….... Click +
Volume Down…… Click —
Next track ……..…….. Press and Hold +
Previous track ……..…… Press and Hold —

Speakerphone(in Bluetooth Connection)

Answer an incoming call……Click ▷
Reject an incoming call……Press and Hold ▷
End the current call……Click ▷

Bluetooth Disconnection

Press “+”, “—” buttons simultaneously until LED Indicator fast blinking blue to disconnect the current connected device, and go into new Bluetooth-paring mode.

TWS (True Wireless Stereo) Function

TheTWS technology enables you to use two speakers pairing via Bluetooth to create a wireless dual-channel system to deliver true stereo sound effect.

TWS connection operation

1.Place the two speakers near each other (the distance should not be over 10 meters).
2.Power on the two speakers, double click the ⏻ button on one speaker as MASTER speaker (playback left channel), the LED indicator fast blinking blue and green, then the two speaker will pair to each other automatically (The other speaker will be as SLAVE speaker and playback right channel)
3.Once paired, the MASTER speaker LED indicator slow flash blue.

Disconnect the TWS connection

Press“ +”, “—” button on one of the speaker simultaneously until LED Indicator fast blinking blue to disconnect the TWS connection.

Listening music from external audio source

1.Power on the speaker.
2.Using the AUX Cable(φ3.5mm),connect your external device to AUX-in port on speaker.
3.It will automatically turn to AUX-in mode,the LED Indicator turns solid green.

Note: Under AUX-IN mode,skip songs and speakerphone function are not workable.

IPX5 Water-Resistant Feature

This Speaker is IPX5 Water-Resistant for rainfall, spills, or water jets,but do NOT submerge it in water or liquids.

IMPORTANT Note - To ensure the speaker is prepared to use for water-resistant,remove all the cable connections and close the port protection cover tightly.

Reset the speaker: If the function buttons without working,disconnect the charging cable, place a small pin(<3mm)into the reset key and hold it for 2 seconds until the LED light off.

Specifications

- Bluetooth Version: 5.0
- Suport:A2DPV1.2,AVRCPV1.4,HPV1.6,HSPV1.2
- Wireless work distance:10 meters
- Driver Unit: φ66mm (4Ω,15W)
- Frequency response: 80Hz-16kHz
- Signal-to-noise ratio: >75dB
- Battery type: Lithium-ion (3.7V/1800mAh)
- DC input voltage/current: MICRO USB DC 5V/0.5A - 2A
- Playtime: 2.2-9 hours (varies by volume level and content)
- Battery charge time: 2.5 hours
- Dimensions: 124x90x90 mm
- Weight: 605g

Caution

• Keep the speaker and its accessories away from the reach of kids as they might cause a choking hazard.
• Keep the speaker away from fire,water,liquids,extreme heat,and strong magnetic fields.
• Do NOT use this speaker at high volume for extended periods,as this may cause permanent hearing damage or loss.
• Do NOT drop or knock the speaker on hard surfaces.
• Do NOT use chemicals or detergents to clean the speaker.
• Do NOT scrape the surface with sharp objects.
• Do NOT make unauthorized alterations to this product.

Troubleshooting

Cannot Power On
Charge the speaker and make sure it has enough battery.

Cannot connect with the device

• Please check the following:
• The Bluetooth device supports A2DP profile
• The Speaker is within 10m from the device.
• The Speaker is in pairing mode, the LED indicator blinking blue and red.

No Sound

• Make sure the music volume is at audible level on both your device and speaker.
• Make sure your device is successfully paired with the speaker, the LED indicator turn solid blue.

Poor sound quality

Move the device closer to this Speaker or remove any obstacle between them.

FCC compliance statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

--Increase the separation between the equipment and receiver.

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.