Mode	CB: 10MHz, 16QAM

Low Channel, 1RB L



Low Channel, 1RB H



Low Channel, Full RB



Middle Channel, 1RB L



Middle Channel, 1RB H



Middle Channel, Full RB



Mode	CB: 10MHz, 16QAM	
High Channel, 1RB L	High Channel, 1RB H	
		
High Channel, Full RB	---	
	---	

Mode	CB: 10MHz, 64QAM

Low Channel, 1RB L



Low Channel, 1RB H



Low Channel, Full RB



Middle Channel, 1RB L



Middle Channel, 1RB H



Middle Channel, Full RB



Mode	CB: 10MHz, 64QAM
High Channel, 1RB L	**High Channel, 1RB H**
	
High Channel, Full RB	**---**
	**---**

Mode	CB: 15MHz, QPSK

Low Channel, 1RB L



Low Channel, 1RB H



Low Channel, Full RB



Middle Channel, 1RB L



Middle Channel, 1RB H



Middle Channel, Full RB



Mode	CB: 15MHz, QPSK	
High Channel, 1RB L		High Channel, 1RB H
		
High Channel, Full RB		---
		---

Mode	CB: 15MHz, 16QAM

Low Channel, 1RB L



Low Channel, 1RB H



Low Channel, Full RB



Middle Channel, 1RB L



Middle Channel, 1RB H



Middle Channel, Full RB



Mode	CB: 15MHz, 16QAM	
High Channel, 1RB L	High Channel, 1RB H	
		
High Channel, Full RB	---	
	---	

Mode	CB: 15MHz, 64QAM

Low Channel, 1RB L



Low Channel, 1RB H



Low Channel, Full RB



Middle Channel, 1RB L



Middle Channel, 1RB H



Middle Channel, Full RB



Mode	CB: 15MHz, 64QAM	
	High Channel, 1RB L	**High Channel, 1RB H**
		
	High Channel, Full RB	**---**
		**---**