Polaroid

9" Tablet & Wireless Keyboard

Quick Start Guide

Model : P900

Bluetooth

In the box

Buttons, ports & hardware



1. ⏻ Power Button
2. Home Button
3. Micro USB port
4. Headphone Jack
5. DC Input
6. Micro SD Card Slot
7. Mini HDMI
8. Microphone
9. Front Camera
10. Rear Camera
11. Speaker

Google Play™

Google Play enables you to store up to 20,000 songs for free and buy millions of new songs. It's home to 1,000,000 Android™ apps and games. It houses the world's largest selection of eBooks. It's where you can rent thousands of movies including new releases and HD titles. It's how you buy and experience digital entertainment on your Android device and any web browser on any computer.

To take advantage of these features, please login or set up a Google™ account; this can be done in the setup wizard the first time you power on the tablet.

Charging the tablet

Charging the battery:

Connect the tablet to a wall outlet using the included AC adaptor as shown below.



Battery Tips:

- *Turn off Wi-Fi when it's not in use.*
- *Lock the tablet (using the sleep/on-off) to shorten charging time.*
- *To optimize battery time and performance, adjust the "Brightness" and "Screen timeout" options in the Settings panel.*

Power ON / OFF

Turning on the tablet

Press and hold the ⏻ button until the startup screen appears.

Power off the tablet

Press & hold the ⏻ button until the "Power off" options appear.

Lock the tablet (standby)

Briefly press the ⏻ button. (Lock the tablet to conserve the battery).

Unlock the tablet

Briefly press the ⏻ button, and slide the "Lock icon" to the right.

Connecting

Wi-Fi and Bluetooth®

To setup Wi-Fi or connect the tablet to a Bluetooth enabled device, slide down on the top right of the Home screen as shown below.



Using the wireless Bluetooth® keyboard

Turning the keyboard on / off

Slide the switch as shown above, the indicator light will briefly turn on.

Pairing the keyboard to the tablet

1. Turn on the keyboard.
2. Press the "**Pair**" button, the Bluetooth indicator light will blink and the keyboard is ready to pair with the tablet.



3. On the tablet's settings,select Bluetooth, turn on **Bluetooth**, and select "**Bluetooth Keyboard**".

4. Using the keyboard, type the password shown on the tablet, and press enter.



5. After pairing successfully with the tablet, "**Bluetooth Keyboard Connected**" is displayed.

Charging the keyboard:

You can charge the Bluetooth keyboard by connecting it with included USB cable to a PC.



Home screen



Apps screen



Widgets

To add a widget, press and hold anywhere on the home screen, Select the Widgets option as shown below.

Press and hold Widgets to place them on the Home screen.

Micro SD card

Inserting a Micro SD card

The tablet supports Micro SD cards up to 64GB (not included).

To install a Micro SD card into the tablet, insert the card as shown below into the card slot until it clicks and locks into place. To remove the Micro SD card, gently press it inward to eject.



Specifications

- Operating System: Android™ 4.4 (KitKat®)
- Processor: Quad-Core
- Display: 9" (1024X600)
- Cameras: Front + Rear
- Speaker: Built-in
- Internal Memory: 8GB*
- External Memory: Micro SD
- Networking: Wi-Fi (802.11 b/g/n)
- Connectivity: Wi-Fi & Bluetooth®
- Battery: Rechargeable Li-ion Polymer

*Actual internal memory may vary depending on the operating system of the device and the preloaded apps.

HDMI®

You can connect the tablet to an HD display with a mini HDMI to HDMI cable (not included).

To connect:

1. Connect the mini end of the HDMI cable to the HDMI port of the tablet.
2. Connect the other end of the HDMI cable to the HDMI port of the TV or display.
3. Select the correct input on your TV.
4. The tablet display is now shown on your TV or display.



Legal information



Limited warranty