
23,00
1.8
10,20
2.00
7,00
54,00
© 2007 Hasbro.
All Rights Reserved.
Made in China
To turn motor sounds **on** or **off**: In Play mode,
press & hold down horn button for 5 seconds.


8,60
40,20
17,00
6,00
18
N353
PLAY OFF DEMO
+ 1.5V AA / LR6 −
− 1.5V AA / LR6 +
2.0
1.2
11.20
24.0
53.4
FCC ID: RS464068
This device complies with part 15 of the FCC Rules. Operation
is subject to the following two conditions:
(1) This device may not cause
harmful interference, and
(2) this device must accept any
interference received, including
interference that may cause
undesired operation.

1 : 1