Date: 16 October 2019

Product Manual for

Gaming controller

Model: RC30-03090L, RC30-03090R

WHAT'S INSIDE / WHAT'S NEEDED

WHAT'S INSIDE

- Gaming controller (Model: RC30-03090L, RC30-03090R)

A. Status indicators	**G.** START button
B. Clickable thumbsticks	**H.** Power switches
C. Slide-in controller grip	**I.** Type C charging ports
D. Directional pad	**J.** Bumpers (L1/R1)
E. Tactile Switch action buttons	**K.** Triggers (L2/R2)
F. SELECT button	

- Phone-grip cases*

- Important Product Information Guide

Included cases may vary.

WHAT'S NEEDED

- Android™ 7.1 Nougat (or higher)

- Bluetooth connectivity

- Internet connection

LET'S GET YOU COVERED

You've got a great device in your hands, complete with a 1-year limited warranty coverage. Now maximize its potential and score exclusive Razer benefits by registering at razerid.razer.com

[PLACEHOLDER IMAGE ONLY]

Got a question? Ask the Razer Support Team at support.razer.com

SETTING UP YOUR RAZER JUNGLECAT

1. Plug in both of your controllers to powered USB ports using a Type C cable (not included) to charge your controllers. It takes approximately 2.6 hours to fully charge each controller.

   ⓘ *Unplug both controllers once they finish charging.*

   Charging   Charged

2. With your phone placed in its correct phone-grip case, detach the left and right controllers from the slide-in controller grip, then slide in each controller to the sides of the case.

   ⓘ *For longer hours of gaming, you may continue using the slide-in controller for more comfort.*

3. Switch on both controllers. The status indicators will flash in blue to indicate that your controllers are reconnecting and in pairing mode. The status indicator on the left controller (primary device) shows that the controllers can now be paired to your phone via Bluetooth, while the indicator on the right controller (secondary device) will immediately turn solid green to show that your controllers are connected to each other via 2.4 GHz.

Controller	Pairing / Reconnecting	Paired / Connected
Primary	☀ Bluetooth	⭕
Secondary	☀ 2.4 GHz	

ⓘ *By default, the left and right controllers are set as the primary and secondary devices respectively when both controllers are active. When a controller is active and its corresponding battery is low, any non-charging status will alternately blink in red. This sequence will repeat until its battery is drained or the corresponding controller is charged.*

4. Open the Bluetooth settings on your phone and select Razer Junglecat from the list of available devices.

ⓘ *To conserve battery, the controllers automatically enter standby mode if they remain unpaired (to a controller and/or phone) within 60 seconds or when left idle for 10 minutes. Press the START or SELECT button to wake your controllers.*

The status indicators of both controllers will turn solid green, indicating that they are now paired to your phone.

ⓘ *You can pair your phone with just one controller and the second controller will automatically connect to your phone (and controller) once available. Primary and secondary designation for the left and right controllers (and the behavior of their status indicators) may switch depending on which controller is first paired with your phone.*

5. Download the Razer Gamepad app to customize your controllers' button functions and thumbsticks exactly as you want them and even access a list of compatible games which you can launch through its built-in launcher with predefined controls precisely made for your Razer controller.

[PLACEHOLDER IMAGE ONLY]

Razer Gamepad

Find out more about your feature-packed controller at support.razer.com

SAFETY AND MAINTENANCE

SAFETY GUIDELINES

In order to achieve maximum safety while using your Razer Junglecat, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, make sure to unplug the device (if applicable) and contact the Razer hotline or go to support.razer.com for support.

The controllers should slide in smoothly into the controller grip or phone-grip cases. Should you have trouble attaching any of the controllers, check if you're sliding it into its allocated side. Don't forcefully slide them into the controller grip or phone-grip cases.

Don't take apart the device (doing so will void your warranty) and don't attempt to operate it under abnormal current loads.

Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device in order to let the temperature stabilize to an optimal level.

MAINTENANCE AND USE

The Razer Junglecat requires minimum maintenance to keep it in optimum condition. Once a month, we recommend you switch off and detach both controllers, remove any attached cables, and gently clean all components using a soft cloth or cotton swab to prevent dirt buildup.

BATTERY WARNING

The Razer Junglecat contains an internal, lithium-ion polymer rechargeable battery. In general, the life expectancy of such battery is dependent upon usage. If you suspect that the lithium-ion polymer rechargeable battery inside the Razer Junglecat may be drained (has a low charge), try charging it. If the battery does not recharge after several attempts, it may be non-operational. Do not open, mutilate, or expose to conducting materials (metal), moisture, liquid, fire, or heat. Doing so may cause the battery to leak or explode, resulting in personal injury. Do not leave the device discharged or unused for extended periods.

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2019 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers.", Razer Phone 2 and "Powered by Razer Chroma" logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. All other trademarks are the property of their respective owners.

©2018 Google LLC All rights reserved. Android, Google, Google Logo, Google Play, and the Google Play logo are registered trademarks of Google LLC.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Razer is under license.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer Junglecat (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit razer.com/warranty.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and consider removing the no-collocation statement.

Canada Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1) L'appareil ne doit pas produire de brouillage;

2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

SAFETY AND MAINTENANCE

SAFETY GUIDELINES

In order to achieve maximum safety while using your Razer Junglecat, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, make sure to unplug the device (if applicable) and contact the Razer hotline or go to **support.razer.com** for assistance.

The controllers should slide in smoothly into the controller grip or phone-grip cases. Should you have trouble attaching any of the controllers, check if you're sliding it into its allocated side. Don't forcefully slide them into the controller grip or phone-grip cases.

Don't take apart the device (doing so will void your warranty) and don't attempt to operate it under abnormal current loads.

Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device in order to let the temperature stabilize to an optimal level.

Gaming Controller Left:
Radio Frequency: 2.4GHz Bluetooth
Operating Frequency: 2400-2483.5Mhz
Max Output power: ≤10dBm

Gaming Controller Right:
Radio Frequency: 2.4GHz Bluetooth
Operating Frequency: 2400-2483.5Mhz
Max Output power: ≤10dBm