alhua
TECHNOLOGY

CONFERENCE CAMERA
WITH SPEAKERPHONE
DH-VCS-C3E0-G

User Manual

V1.0.0

Zhejiang Dahua Vision Technology Co., Ltd

Content

Copyright Statement

Declaration of Trademark

Update and Modification

To enhance the security of this product and provide you better user experience, Dahua may improve this product by automatically updating the software without prior notice and assume no responsibility.

Dahua reserves the right to change any information contained in the document at any time, which will be then included in a new version, without prior notice. Some features of the product allow subtle differences before and after change.

Overview

This document describes in detail the quick configuration of the DH-VCS-C3E0-G series.

Symbol Conventions

For the purpose of this document, the following signs that may exist herein mean as below:

Symbol	Description
⚠ Danger	Danger indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
⚠ Warning	Warning indicates moderately or lowly hazardous situation which, if not avoided, will result in minor or moderate injury.
⚠ Caution	Caution alerts you to possible equipment damage, data loss, performance degradation or unpredictable results if you do not follow instructions.
⚠ Anti -static	Alert you to static-sensitive equipment.
⚠ Protection Against Electric Shock	Alert you to high voltage.
☀ Laser Radiation	Alert you to intense laser radiation.
☜ Tip	Help you with solving a problem or saving your time.
📖 Note	Additional information for the main body, which can be known as an emphasis and supplement to the main body.

Before using the product, read and abide by the following requirements to prevent damage to the product or your belongings.

⚠ Caution
· Transport, use, and store the product only under the appropriate temperatures and humidity.
· Install the product in a well-ventilated place and do not block the device's air vents.
· Install the product in a steady place.
· Do not place the product in damp, dusty, or smoky areas.
· Do not place the product in direct sun light or near a heat source.
· Do not let the product come in contact with liquids.
· Do not disassemble the product at will.

⚠ Warning
· Turn off all power sources when opening the device cover or when repairing the device to prevent electric shock.
· Use a new battery of the same kind to replace the old one.
· Use the recommended power cord and use it within its rated specifications.
· If a power plug or appliance coupler is used as a disconnecting device, please ensure that the disconnecting device is always easy to operate.

Important Statements
· The physical product shall prevail while this User Manual is for reference only.
· The product will automatically update itself. If there is an upgrade, no notifications will be given.
· For the latest procedure and supplementary documentation, please contact the service center.
· Should there be any doubts or any disputes over the product instructions, the company reserves the rights of final interpretation.

1 Product Overview

1.1 Product Introduction

DH-VCS-C3E0-G is a separate audio-video conference camera,configured with 120 ° shooting angle,1080P HD webcam and 2.4 G wireless speakerphone, suitable for small and medium-sized conference scenes, personal business, home or leisure place.

1.2 Features

· 1080P HD camera
  120 degree shooting wide-angle, clear and fluid picture
· Mechanical adjustable lens
  The lens can be adjusted vertical -30 to 30 degree and horizontally -150 to 150 degree, enabling flexible shooting angle
· Audio and video integration
  Supporting Skype, Wechat, MSN and other online communication software
· Intelligent audio high-tech
  360-degree mic coverage
  256ms acoustic echo cancellation
  Full duplex
  Dynamic Noise Reduction(DNR)
· Portable external microphone and speaker
  No need driver; Clear, unmixed and not harsh sound quality

1.3 Package list

Please check whether the materials are complete according to the following table when opening the box.

No	Name	Picture	Pcs	Function Description
1	Camera		1	Conference shooting. Pickup and display conference audio
2	Speaker-phone		1	
3	Jack column		1	Optional accessories and goods in kind prevail
4	USB cable		1	Speakerphone charging cable
5	Charger		1	Speakerphone charger
6	User manual		1	Help users to install, connect, and use video terminal devices

1.4 Component description

Part 1: HD network camera

Lens

Horizontal shaft

Adjustable base (option)

Lens clamp

Clamp

USB cable

Part 2: 2.4G wireless speakerphone

Triangular Indicator

Loudspeaker

Mini USB interface

3.5mm audio interface

Microphone

Bottom right Indicator

Bottom left indicator

Loudspeaker mute

Microphone mute

vol-   vol+

Power

LED Indicator
· Blue triangular Indicator: normal working status
· Blue bottom right indicator: loudspeaker mute
· Blue bottom left indicator: microphone mute
· Blinking blue bottom left indicator: volume adjustment
· Blinking orange bottom left indicator: low power

Connect HD camera to PC and long press to power on speaker phone,long press again to power off.

• Connecting USB line to computer, the following tips will appear in the lower right corner of the computer when first time using.

> **Installing device driver software**
> Click here for status.

• When the device driver is installed successfully, the following prompt will appear on the computer side

> **Your device is ready to use**
> Device driver software installed successfully.

• If you need to confirm whether the equipment installation is successful, turned on the computer side "computer properties" - click on the "device manager" - click on the "image equipment" appear below equipment items, after confirmed, can be used with instant messaging software.

▷ Local Users and Groups
▷ ⊙ Performance
　Device Manager
🖳 Storage
　📄 Disk Management
📇 Services and Applications

▷ 📇 IDE ATA/ATAPI controllers
▲ 📷 Imaging devices
　　📷 DH-VCS-C3E0-G
　　📷 WSD Scan Device
▷ ⌨ Keyboards
▷ 🖰 Mice and other pointing devices
▷ 🖥 Monitors
▷ 🖧 Network adapters
▷ 📇 Other devices
▷ 🖵 Ports (COM & LPT)
▷ 📇 Processors
▲ 📢 Sound, video and game controllers
　　📢 DH-VCS-C3E0-G
　　📢 NVIDIA High Definition Audio
　　📢 NVIDIA Virtual Audio Device (Wave Extensible) (WDM)
　　📢 Realtek High Definition Audio
　　📢 英特尔(R) 显示器音频

• Another way to check whether DH-VCS-C3E0-G is being used on the computer, click the "speaker" icorn, and then it will show as following:

	Open Volume Mixer
	Playback devices
	Recording devices
	Sounds
CH 🖿 ❓ 🔌	Volume control options
	2017/4/14

• Click "audio device" or "display devices", and then it will shows:

Sound

Playback | **Recording** | Sounds | Communications

Select a recording device below to modify its settings:

Microphone
X X X X X
Default Device

Microphone
Realtek High Definition Audio
Not plugged in

Sound

Playback | Recording | Sounds | Communications

Select a playback device below to modify its settings:

Speakers
X X X X X
Default Device

NVIDIA HDMI Output (Port 0)
NVIDIA High Definition Audio

• Check whether the default device is DH-VCS-C3E0-G, if not, select it as the default one and the it can work as normal.

**This operation works under Win 7 and it will be some difference in other operating system.This document can be as a reference . **

• If the color and resolution of video are found to be abnormal, it can be used in camera adjustment special software "Amcap"to check. Check the output size of the white balance and video for the corresponding values.

Check the white balance option with a default value of 4600

Video output size, select 1920*1080

Or change the camera effect to "restore the default effect" in instant messaging software.If it still cannot fix it, please contact our after-sales service .

Specification	Description
Dimension	Camera:104∗139∗124mm Speakerphone:155*148*37mm
Net weight	Camera:500g Speakerphone:337g
Color	Black
Interface	USB 2.0
Battery(speakerphone)	Built-in lithium battery (7-10H)
Lens	1/2.8, fixed focus, 120 degree Angle
Sensor	Full HD CMOS sensor
Voice pickup range	3m max
Video	1920∗1080
Image transmision speed	Up to 30FPS
Aperture coefficient	F2.0
Focus distance	30～300CM(Better distance）
Computer system	Windows ® 7, 10 / Mac OS X 8.1 or 10.7 or higher operating system, etc
Recommended conditions	Humidity：20~85% condensation free Noise level：<48dB Storage temperature：-10°~55° Reverberation time:<0.5 seconds
Certification	CE/FCC

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.