THE BLACK SERIES™

Toy RC Boxing Robots

by shift3®

cyber boxing robots

head-2-head RC boxing

SAFETY PRECAUTIONS.
- Do not use the product near small children or animals, the detachable head can pose a choking hazard.
- Adult supervision is recommended at all times.
- Keep product away from water. Never submerge any portion of the product in water. Avoid water, sand and snow when operating your vehicle.
- Always keep the product away from all heat sources of heat, under direct sunlight or outside operation as this is harmful to internal components.

BATTERY WARNING.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Insert batteries using the correct polarity. Do not short-circuit the supply terminals.
- Remove batteries when not in use. Recycle or dispose of weathered batteries according to federal, state, and local laws. Do not dispose of batteries in a fire.
- Only use manufacturer specified battery(ies), charger(s) and/or adapter.
- Always use, replace, and recharge (if applicable) batteries under adult supervision.
- If applicable, operated by the manufacturer.

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FC

OPERATING INSTRUCTIONS

Each robot requires 3 "AAA" 1.5V batteries (not included). Each remote control requires 1 9V battery (not included). When changing batteries, adult supervision is required. Use alkaline batteries for best performance.

1. Carefully remove items from the package.
2. Locate the battery compartment on the back of each robot, as well as each remote.
3. On robots, loosen the screws and remove battery doors. Slide doors open on RC units.
4. Insert "AAA" batteries inside robots making sure the correct polarity in each compartment (see diagram). Insert one 9V battery into each remote control.
5. Replace battery doors and tighten screws.
6. The power switch is located on the side of the robots.
7. Switch robot and remote control power switches to the "ON" position.

NOTE: Before use, adjust the robots to make sure both have good contact with the ground. Use on a hard, flat surface (not carpet) for best results.

OPERATING CONTROLS
- Turn both units on to move forward
- Push both units down to move backwards
- Push left unit down and right unit up to spin clockwise
- Push right unit down and left unit up to spin counter-clockwise
- Push left unit down and left unit up to move left
- Push right unit down and right unit up to move right

Each robot requires 3 "AAA" 1.5V alkaline batteries (not included).
Each remote control requires 1 9V battery (not included).

Each robot requires 3 "AAA" batteries.

Each remote requires 1 9V battery (not included).

HOW TO PLAY

There are sensors located beneath each robot's chest plate. The object of the game is to knock the opposing bear's head off by making contact with the chest plate directly for robot's head. When the head is knocked off, the power will be cut off. To control the robots, the head has to be attached to the body. To replace the head back to face forward one the neck and gently press down until a click into place.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

©2013 Mattel, Inc. Shift3, The Black Series, the Black Series Shift3, and all associated logos are trademarks of Mattel, Inc. All rights reserved.

Distributed by Mattel, Inc., El Segundo, CA 90245

PATENTS PENDING

For technical support, please visit www.mattelconsumerservices.com or call 1-800-524-2146

The artwork and design of this package are protected by US copyright law and may not be reproduced, distributed, displayed, published or used for any purpose without prior written permission. It is not permitted to alter, remove or reproduce any trademarks or copyright notice from this package.

2903011 (32596)

6 94202 31384 6

Made in China

32.5x22x27cm

WINDOW DIE-CUT

Tray Insert Prints 40C/100Y (Green)

THE BLACK SERIES™
by shift3®

⚠ WARNING!
CHOKING HAZARD - Small parts.
Not suitable for children under 3 years.

THE BLACK SERIES™
by shift3®
cyber boxing robots
head-2-head RC boxing



VERSATILE
OMNI-DIRECTIONAL FUNCTION PROVIDES EASY MANEUVERING DURING PLAY

COMPETITIVE
THROW HOOKS AND JABS IN AN ATTEMPT TO KNOCK OUT YOUR OPPONENT

CORDLESS
OPERATE TWO ROBOTS VIA REMOTE CONTROLS

2 PLAYER ACTION!