RF exposure statement

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.
This equipment meets the exemption from the routine evaluation limits in section 2.5 of RSS-102. It should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

Cet équipement est conforme à l'exemption des limites d'évaluation habituelle de la section 2.5 de la norme RSS-102. Il doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et toute partie de votre corps.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC WARNING

This device contains licence-exempt transmitter(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Quick Start Guide for
Connector Mini Bridge

Product
Cerification
FC ▌✦▐ CE

Mini Bridge allows user to link their motorized shutters, blinds, and curtains into Wi-Fi network, enabling control via smart APP and interaction with other IoT products.

Step 1 Download APP
Please scan below QR code.

**Download on the App Store**

GET IT ON Google Play

Step 2
Please scan below QR code to learn more about link up Mini Bridge with home Wi-Fi router, setup Connector APP, and establish connection with other IoT applications.

WORKS WITH **amazon alexa**

works with the **Google Assistant**

WORKS WITH **IFTTT**

Program Button

Indicator

Program / Pairing:

Press and hold program button for about 2 seconds, then release until the LED blinks purple.

Reset:

Press and hold program button for about 10 seconds, then release until the LED blinks red.

90°

Product Parameter

Indoor use only

Wi-Fi: 2.4GHz (802.11b/g/n)

Power Input:

DC 5V/1A (USB Type-A)

Radio frequency: 433.92MHz

Working temperature: 0°C ~ 40 °C

Dimension(mm): L83.8 * W30.7 * H13.9

Status Indicator

Color	Meaning	Duration
Constant Blue	Working fine	Constant
Slow Flashing Red	Wi-Fi is disconnected	Continuously till status change
Slow Flashing Yellow	Wi-Fi is connected	Continuously till status change
Quick Flashing Red	Bridge reset	5 times
Slow Flashing Purple	Pairing underway	Continuously till status change
Slow Flashing Green	Upgrade in progress	Continuously till status change