客版-瑞诚-2021新版漂移车HQEXB_HoverQuad_BLUE_PKG_OLI拼版（4色）[雅典设计]
咬口 ⚠印前请仔细核对_上机后恕不负责! CMYK #2021/08/17

CAUTION:
- Remove old batteries and replace with new batteries. Be sure t o insert batteries correctly according to (+) and (-) symbols located in the battery compartment.
- Be sure to insert batteries correctly with adult supervision and always follow the toy and battery manufacturer's instructions.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbo-zine), or rechargeable (nickel-cadmium) batteries.
- Rechargeable batteries are to be removed from the toy before being charged.
- Non-rechargeable batteries are not to be recharged
- Do not dispose of batteries in fire
- Batteries should be recycled or disposed of as per state and local guidelines.
- Rechargeable batteries are only to be charged under adult supervision
- Only batteries of the same equivalent type as recommended are to be used.
- The supply terminals are not to be short-circuited.
- Always remove weak or dead batteries from the product.
- Remove batteries if the product will be stored for an extended period of time.
- Please retain these instructions for future reference.
- For best results use alkaline batteries.
- Contains Lithium Ion Battery. Battery must be recycled or disposed properly.

REMOTE BATTERY INTALLATION:
On vehicle, loosen screw to release battery cover (use Phillips head screwdriver, not included). Pull latch down to release.
Remove battery compartment cover. Install 2 x AA 1.5 volt batteries. Follow polarity diagram below.



*BATTERIES ARE NOT INCLUDED

VEHICLE BATTERY INTALLATION:
Loosen screw to release battery cover (use Phillips head screwdriver, not included). Pull latch down to release.
Remove battery compartment cover. Remove battery cartridge Install 6 x AAA 1.5 volt batteries. Follow polarity diagram below.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the
following measures:
•Reorient or relocate the receiving antenna.
•Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help
The device must not be co-located or operating in conjunction with any other antenna or transmitter.

Red	Black	Purple
27 MHz	27 MHz	27 MHz
Blue	**Gold**	**Silver**
49 MHz	49 MHz	49 MHz

ITEM No.: HQEXB

6 03625 83554 7

MINDSCOPE PRODUCTS
MINDSCOPE PRODUCTS
PO BOX 9525, GLENDALE, CA 91266
Tested & Safe for 3+, Fun for 5+
Product and color may vary from images on package
Made in Shantou, Guandong China
BATCH NUMBER: 8021 DCM, 08/08/2021

CAUTION:
- Remove old batteries and replace with new batteries. Be sure t o insert batteries correctly according to (+) and (-) symbols located in the battery compartment.
- Be sure to insert batteries correctly with adult supervision and always follow the toy and battery manufacturer's instructions.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbo-zine), or rechargeable (nickel-cadmium) batteries.
- Rechargeable batteries are to be removed from the toy before being charged.
- Non-rechargeable batteries are not to be recharged
- Do not dispose of batteries in fire
- Batteries should be recycled or disposed of as per state and local guidelines.
- Rechargeable batteries are only to be charged under adult supervision
- Only batteries of the same equivalent type as recommended are to be used.
- The supply terminals are not to be short-circuited.
- Always remove weak or dead batteries from the product.
- Remove batteries if the product will be stored for an extended period of time.
- Please retain these instructions for future reference.
- For best results use alkaline batteries.
- Contains Lithium Ion Battery. Battery must be recycled or disposed properly.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the
following measures:
•Reorient or relocate the receiving antenna.
•Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help
The device must not be co-located or operating in conjunction with any other antenna or transmitter.

REMOTE BATTERY INTALLATION:
On vehicle, loosen screw to release battery cover (use Phillips head screwdriver, not included). Pull latch down to release.
Remove battery compartment cover. Install 2 x AA 1.5 volt batteries. Follow polarity diagram below.

*BATTERIES ARE NOT INCLUDED

Red	Black	Purple
27 MHz	27 MHz	27 MHz
Blue	**Gold**	**Silver**
49 MHz	49 MHz	49 MHz

ITEM No.: HQEXB

6 03625 83554 7

MINDSCOPE PRODUCTS
MINDSCOPE PRODUCTS
PO BOX 9525, GLENDALE, CA 91266
Tested & Safe for 3+, Fun for 5+
Product and color may vary from images on package
Made in Shantou, Guandong China
BATCH NUMBER: 8021 DCM, 08/08/2021

VEHICLE BATTERY INTALLATION:
Loosen screw to release battery cover (use Phillips head screwdriver, not included). Pull latch down to release.
Remove battery compartment cover. Remove battery cartridge install 6 x AAA 1.5 volt batteries. Follow polarity diagram below.