# TONLY

表格编号：TLT-C4-4075001
版本：V 7.5
表格修订日期：2022-10-10

物 料 编 号：720203-020624
基 础 结 构 号：NA
内　　　容：QSG
型　　　号：SV210M-0808
图 纸 版 本 号：V1.0
是否含美国走向：是
日　　　期：2023-10-25
美 工 制 作 人：陈伟

## ART WORK FORM
（密级：C级）

**品牌名称（BRAND NAME）：** VIZIO

## 工艺说明（尺寸单位：毫米（mm））：

08/02/49/54/55/56/57/59/67/79类：

| 工艺、颜色 | |
|---|---|
| 成型及颜色（直接注塑颜色） | N/A |
| 喷油及颜色 | N/A |
| 丝印颜色/移印颜色 | N/A |
| 电镀/真空镀及颜色 | N/A |
| 针对整个工艺栏中涉及到的油漆,油墨,镀层是否需要非导电的要求说明 | 油漆：否 □　是 □ 油漆要求完全绝缘不导电，即阻值无穷大　是 □ 油漆阻值大于＿＿＿<br>油墨：否 □　是 □ 油墨要求完全绝缘不导电，即阻值无穷大　是 □ 油墨阻值大于＿＿＿<br>镀层：否 □　是 □ 镀层要求完全绝缘不导电，即阻值无穷大　是 □ 镀层阻值大于＿＿＿ |
| 镭　雕 | N/A |
| 氧化及颜色 | N/A |
| 其他工艺 | N/A |
| 备　注 | N/A |

74/76/89类：

| 印刷方式 | XXXX |
|---|---|
| 表面工艺 | N/A |
| 样板需求 | 签正式样板 □<br>签彩稿样板 □ 基础机型彩盒样板参考料号：<br>76-XXXXXX-XXXXX |
| 备　注 | N/A |

71类：

| 表纸材质 | 型号：XXXX | 厚度：XXXX |
|---|---|---|
| 胶水材质 | 型号：XXXX | 是否可移：XXXX |
| 尺　寸 | 长：XXXX | 宽：　XXXX |
| 印刷方式 | XXXX | |
| 碳带打印 | 无需打印 □　供应商打印 □　在线打印 □ | |
| 表面工艺 | XXXX | |
| 粘贴位置 | XXXX | |
| 材质库编码 | N/A | |
| 样板需求 | 需要签样 □ | |
| | 不需要签样 □　参考料号：71-XXXXXX-XXXXX | |
| 备　注 | N/A | |

72/99（说明书光盘）类：

| 材　质 | 封面：105g哑粉纸　　内页：105g哑粉纸 |
|---|---|
| 尺　寸 | 折前尺寸：　长：216mm 宽：280mm<br>折后/成品尺寸：长：108mm 宽：140mm |
| 印刷方式 | 单黑双面印刷 |
| 表面工艺 | NA |
| 装订方式 | 先左右对折，再上下对折 |
| 页　数（P数） | 折叠前页数(P数)：2P<br>钉装/胶装页数(P数)：NA |
| 备　注 | N/A |

73类：

| 印刷方式 | 在通力产线镭雕 |
|---|---|
| 备　注 | N/A |

## 制作要求（＊FOR ALL）：

☑ 条码扫描等级达到C级以上；
☑ 美国走向必须满足CP65要求；
☑ 必须满足RoHS2.0、REACH要求；
☑ 必须符合TCL通力《公司环境管理物质标准》要求；
☑ 所有用于包装材料印刷的油墨都禁止含有矿物油；
☑ 中国境内生产和/或使用的涂料、油墨、胶粘剂、清洗剂必须符合中国国标VOC的要求；
☑ QR Code的制作或打印过程中需选择模型2（M2）；
☑ 所用油墨必须达到TCL质量部门检测标准；
☑ 胶袋材质、胶袋上透气孔的大小、位置以结构认可书为准；
☑ PE材质的胶袋其上面的丝印内容整体长度可允许3mm误差；
☑ 珍珠棉等材质的胶袋其上面的丝印内容整体长度可允许5mm误差；

## ＊FOR HUAWEI:

☑ 满足无卤要求；
☑ 满足不含有邻苯二甲酸盐要求。

## ＊FOR SAMSUNG:

☑ VD类产品需满足三星的SS要求，AI类产品需满足三星SA要求。

## ＊FOR SONY:

☑ 禁止使用SS-00259中规定的1级环境管理物质。
☑ 再生树脂、被覆线材必须从索尼的绿色伙伴认定供应商处采购。

# VIZIO

## 1  Position

Position the soundbar (A) and subwoofer (B) as shown in the image below.

A

B

**+**

**Wall mounting your TV?**
The included wall mount template can be used to mount your soundbar directly to the wall if preferred.

## 2  Connect

Connect the soundbar to the HDMI ARC or eARC port on your TV with the included HDMI cable.

HDMI (ARC/eARC)   HDMI   HDMI

TO TV
HDMI (eARC)

## 3  Plug In

Plug in power cables to the soundbar and subwoofer.

720203–020624

A sound will play when the soundbar powers on for the first time and the front LED light will turn on.

## 4  Use your TV remote

Use your existing TV remote to power on your TV. The soundbar will automatically wake from sleep. Your TV remote will now control soundbar volume, mute, and unmute.

Soundbar Volume    30

+

—

**Need more help?**
Scan for additional support and documentation.

## Take control with VIZIO Mobile

The smarter, easier way to control and personalize your soundbar.

*VIZIO Mobile app and VIZIO Account required for control of basic soundbar functionality, settings, and to receive system updates. Scan to download.

Download on the **App Store**

GET IT ON **Google Play**

Before you begin, activate Bluetooth on your phone while standing next to your soundbar.

Adjust soundbar levels such as bass, treble, height, dialogue and more.

Personalize your experience with sound modes for movies, music and more.

9:41

< Audio Settings

LEVELS

Bass Level

Treble Level

## Get to know your soundbar

**Using Bluetooth for app control and music streaming**
After plugging your soundbar into a power outlet, download and open VIZIO Mobile. The app will recognize your soundbar automatically. If you wait too long, you will need to press and hold the Bluetooth button on your soundbar for 5 seconds to reinitiate the mobile app pairing process. Once paired to the soundbar, you may begin streaming music, podcasts and more using the Bluetooth button found within the VIZIO Mobile app.

**Understanding HDMI ARC/eARC**
Your soundbar features HDMI eARC for the highest quality audio formats from your TV. Your TV may have two or more HDMI ports, but only one will be labeled HDMI ARC or HDMI eARC.

**Unlocking the full potential of Dolby Atmos**
Your soundbar supports full-bandwidth Dolby Atmos audio. For optimal performance, be sure that HDMI CEC and eARC are turned on in your TV settings menu. Refer to your TV user guide for details.

**Controlling your soundbar and TV with one remote**
No need for a separate soundbar remote. Simply power on your TV and the soundbar will automatically wake from sleep. Control soundbar volume using the volume and mute buttons on your TV remote.

## Exclusive for VIZIO TV

Simplified setup and control for VIZIO TV owners.

### Audio Control Menu

Press the Settings button ⚙ on your VIZIO TV remote and select ALL SETTINGS > AUDIO to get started.

### VIZIO QuickFit

A proprietary mounting solution that enables elegant, tool-free installation of your soundbar with compatible VIZIO TVs.

Visit **vizio.com/quickfit** to learn more.

< AUDIO

VIZIO SOUNDBAR (HDMI–1)

| | |
|---|---|
| Treble | Medium |
| Bass | Medium |
| Subwoofer ‹ High › | |
| ClearDialog | Medium |
| Virtual: X | On |
| Night Mode | Off |
| Height | Medium |

TV AUDIO

| | |
|---|---|
| TV Speakers | Off |

Select from preset picture modes. Your energy consumption may change based on usage and picture settings.