(Front)

SDR-C
SERVER
Power
Soft Fail
Hard Fail
RSSI
DONOR
ADRF
ADVANCED RF TECHNOLOGIES

(Back)

ON / OFF
WARNING
DO NOT CONNECT
TO AC POWER
AC IN
AC SELECT
115
NMS-PWR-OUT
CELL
Master
Slave
Debug

(Left)

(Lower Side)

(Upper Side)