


SMART WATCH


User Manual

1 Enter pairing mode




- The watch automatically turns on while charging.
- Press and hold the button on the side to power on.

2 Get the TouchLink app




Scan the QR code or search "TouchLink" in the App Store/Google Playstore to download

3 Set up and pair



- Make sure your phone's bluetooth is on.
- Open the "TouchLink " app » me » bind new device» Smart Watch. In your phone's bluetooth menu, under 'nearby devices' look for "Smart Watch_XXXX", or scan the QR code on the watch screen with your phone to start the pairing.
- "XXXX" is the last 4 digits of the bluetooth address, route: Settings » About watch

4 Button actions




Short press

- Wake the watch screen
- Return to the previous screen in an app
- Enter the app list
- Pause or resume workout

Press and hold


- Power on, off or restart
- Press for 10 seconds to force restart

5 On home screen




- Press and hold to change the watch face
- Swipe down to enter shortcut menu
- Swipe up to view messages
- Swipe left to see Switch card
- Swipe right to see Switch card

6 Charger



- Please connect charging cable to the watch as follows
- Use a regular USB charger with output voltage of 5.0V and output current of 200mA or above to connect your charging cable to a power outlet or charging device

7 Changing the wristband



Slide the spring pin and hold it while pulling away from the watch to remove the current wristband. To attach a new band, slide the spring pin across and slot the new band. When both sides of the band are positioned correctly, release the spring pin.



TouchGFX CO.,LTD
 40A, Building H, Baoneng City (East Zone), No.3288,
 Liuxian Road, Fuguang Community, Taoyuan Street,
 Nanshan District, Shenzhen, China
 Made in China

8 FAQ

Issue description	Possible cause	Solution
Incorrect step count	Abnormal wagging or vibration of device	Wear the watch properly to avoid abnormal vibration
	Walked less than 15 steps	Walk more than 15 steps continuously
No display	Sliding or walking in slippers	Walk with normal posture/ wear something other than slippers
	Low battery	Connect to charger to charge the watch
Watch failed to sync data to the App	The connected phone's Bluetooth is off	Turn on the connected phone's Bluetooth
	App is shut down or has crashed	Restart the "TouchLink" App
	Out of Bluetooth signal range	Make sure your watch is in close proximity to the connected phone

9 Specifications

Product Name	Smart Watch
Product Model	TGW028
Storage Environment	Temperature: -20 C to 60 C RelativeHumidity:≤90%RH
Working Temperature	0 C to 45 C
Frequency Range	2402MHz-2480MHz
Bluetooth Transmitting Power	< 1 dBm
Battery Capacity	240mAh
Waterproof rating	IP68 (5 meters)
Charging duration	About 2 hours

10 Features

- Bluetooth BLE5.1
- Full-screen touch
- 1.8" TFT display 240*286 pixel
- Daily Tracking: Active/ Steps / Calories
- SpO2 Blood Oxygen monitoring
- Breathing training
- Sleep monitoring report
- Call notification
- Find your phone
- Music control
- Camera control

11 Regulatory information

Regulatory information Procedure: Settings>>Regulatory information(Label).

12 Warning

Matters needing attention


- The electronic equipment contained in the product, if improperly handled or disposed of, may damage the environment or cause harm:
 - Do not open the shell of the watch.
 - Do not replace the built-in battery by yourself.
 - Do not use corrosive cleaner to clean the product.
 - Do not charge when the product is wet.
 - If the product is not completely dry, do not charge.
 - Do not expose the product to extended periods of direct sunlight.
 - Do not use the product in a sauna or steam room.
 - Do not expose the product to extremely high or low temperatures.
- If the screen or shell is damaged, do not use the product.
- Do not put the product in the dishwasher, washing machine or dryer.
- Do not expose the product to fire, the battery may explode.
- While charging, please make sure the charging cable is correctly connected to the watch and charger, and that the charger is properly connected to the power outlet.
- If the temperature of the product rises sharply during charging, please stop charging and contact our support team for assistance.
- Some users may experience skin irritation due to wearing the product for too long. If you experience redness, swelling, itching, or other negative physical side effects, please consult your doctor.
- Do not interact with the screen while driving, distracted or in otherwise dangerous situations.
- This is not a toy. Do not let children or pets play with the product. Small parts of the product may cause a choking hazard.
- Product functions may be affected by external factors such as interference, and the data is for reference only.
- The product has a heart rate recording function. Wearing the device for a long time may cause skin discomfort or risk of certain diseases for some users. If you have any of the following

- symptoms, please stop using the device and consult your doctor:
 - Epilepsy or sensitivity to light.
 - Poor blood circulation or excess bruising; heart disease or other diseases.
 - You are taking any medicine that may make you sensitive to light.

13 Certification

Medical Disclaimer

Warning: This Smart Watch TGW028 is not a medical device. The Smart Watch TGW028 and its related Apps may not be used to diagnose, treat, or prevent any disease or medical condition. Before performing any exercise, sleep, or nutritional changes, be sure to seek the advice of qualified medical professionals, otherwise serious injury or death may result.



This symbol means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, user has the choice to give his product to a competent recycling organization. Proper recycling of your product will protect human health and the environment.

FCC STATEMENT

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - This device may not cause harmful interference, and
 - This device must accept any interference received, including interference that may cause undesired operation.
 - Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.