

Please read this manual carefully before using the product and keep it properly

# X8 ULTRA SMART WATCH

FCC ID: 2A7G4-X8ULTRA

Wireless charging



## product description

Packing list: watch host (including strap) X1, Wireless Charger X1, Product manual X1



1. Open the package. Follow the steps to connect the strap to the smart watch



2. Wear the smart watch and press and hold the button to turn it on

3. Open Wearfit Pro on your phone to set up the device

To charge, place the back of your watch on the wireless charger



## Product overview



Customize sports function shortcuts

## Buttons and touch



Knob button

1. In the dial page, enter the menu page, short press to return to the dial.  
2. Double press the dial page to enter the App page.  
3. Double click on the dial page to enter the watch face.  
4. Short press on the dial page to return to the dial page.

Switch button

Long press the watch

## Connect the watch



1. Download the "Wearfit Pro" APP to your mobile phone and install it. You can directly search for "Wearfit Pro" in the APP store to download, or scan the following QR code to jump to the link to download (scan code is browser, WeChat, etc.)  
2. Connect the watch  
3. Scan code connection: After the watch is turned on and enter the dial page, slide right to enter the split screen function, click the "scan code connection" shortcut button, the connection QR code will pop up, and you can directly scan the QR code connection in Wearfit Pro.  
4. Manual connection: After the mobile phone turns on Bluetooth, enter the APP to directly search for the device to manually connect.  
5. Connect and call Bluetooth  
6. In the initial state of the watch, the Bluetooth for calls is turned off, and the call and music functions cannot be used at this time. Scroll down to open the shortcut menu, and click the call Bluetooth switch. After turning it on, you can find the call Bluetooth in the mobile phone system (when the mobile phone Bluetooth is turned on, find the corresponding Bluetooth name Watch call watch call, and click connect. After successful connection, you can use the call function and music function.

## Watch operating instructions

- Split screen function: Double-click appear and Click Return
- Dial page: Swipe left to enter the dial page selection, slide left to switch to other dials. Note: The system pre-sets Multiple dial pages, and the last dial is named "Custom". This dial will change with the dial market on the APP side and the download settings of the custom dial.
- Menu page: On the dial page, single press the side key to enter the menu page, after entering the menu page, double press the side key to switch between menus, and single press the side key to return to the main dial page.
- Function page: In the menu page, click each application icon to enter the corresponding function, slide right to return, and press the side button to return to the main dial page.
- Dial page double press the side key to enter the Alipay function.



The watch can present me and TA (positioning health), blood sugar, respiratory rate functions, you can download the APP to the APP market to install the APP, the APP will be transmitted to your watch, you can check the health status and location of your friends anytime and anywhere.

## Features

- Connect: Connect to the mobile phone to synchronize contacts on the mobile phone and set emergency contacts.
- Call record: Connect the mobile phone to dial out, and you can call on the watch side.
- Call record: Record the exercise data of the day, including: calories, activity time, number of activities, steps and distance.
- Blind to WeChat: To receive payment via WeChat QR code.
- Heart rate: Put the watch close to your wrist, and the best place to wear it is a wrist bone above your arm. The red light heart rate can be measured. The normal value of the average person is 60-100 beats/min. The watch records the last 7 measurement records, and records the highest and lowest values.
- Blood pressure: Put the watch close to your wrist, and the best place to wear it is on the upper arm of the wrist bone and above the arm. The blood oxygen value can be measured. The watch records the last 7 measurement records and records the highest and lowest values.
- Alipay: It includes 6 regular sports including indoor running, indoor cycling, sit-ups, push-ups, and free training.
- After you use the watch to wake up the assistant function, you can use the watch assistant to control the Siri function of the mobile phone and operate the mobile phone with Bluetooth binding.
- Alipay can be bound to the watch, and the watch can make offline payment through Alipay's QR code.



Music



Running



Breath training



Calculator



Stresswatch



Met



Pressure



Set up

After connecting the audio Bluetooth, turn on the mobile phone music player, and the watch can play the mobile phone music.  
Includes 7 sports such as outdoor running, outdoor cycling, sit-ups, hiking, mountain climbing, and other sports. 5 major sports data are recorded during exercise: steps, calories, heart rate, cadence, pace, and can set Sports goals, a comprehensive breakdown of your sports details.  
Breath training can quickly relax oneself, relieve stress and quickly replenish oxygen to the body. Three frequency options are provided: slow, normal, and slightly faster, breathing time options: 1-5min.  
You can use the watch to calculate the required data anytime and anywhere.  
The watch turns into a timer every second.  
The watch reduces the function of Met, converts all daily water volume into Met value and displays it on the watch and APP, records the energy metabolism equivalent of one week of exercise, and forms a visual chart for easy understanding of their exercise volume.  
The watch supports continuous pressure monitoring, monitors the user's 24-hour pressure changes, and uses scientific health algorithms to display the pressure as an icon, allowing users to adjust their status at any time. The pressure range shows: 120-92 relaxed, 90-95 normal, 60-79 medium, 60-99 high.  
Including brightness settings, often of screen, raise the wrist to turn on the screen, do not disturb mode, sound and vibration, language switching, phone connection, password, about watch, restart, factory reset, shutdown.

## Message Push V1.1



- Swipe up on the dial interface to enter:
- New push instruction situation: pop-up window at the top
  - Click the "pop-up box" to enter the message details;
  - Red dot description: The dial will display red when there are unread messages.
- Definition of unread message: Click to enter the message details page to view the message content.
- Message pop-up box will be displayed when the user is on the screen, the screen state will be displayed for 5 seconds, and the pop-up box will be hidden if the user does not operate (when the button is clicked); after the screen-off state comes with a message, it will continue to display for 5 seconds after lighting up.
- After the message pops up, (click) slide the screen/Click the button to hide the message;
- Message details: Click to enter the message details page, delete this message;
- On special pages, there is a response to the message pop-up box, and there is no need to enter the message details page (exercise, breathing training, charging, screen lock, bedside clock, stopwatch/timer, dialing/calling).

## Altitude barometer



- Select "altitude barometer" in the device application list to enter this function;
- The watch and the APP are not paired to prompt the pairing interface;
- The watch and APP have been paired for data update;
- Display the current time air pressure value, the highest and lowest air pressure today;
- Display the current time altitude value;
- Histogram, which needs to save the historical data on the hour, to display the historical data of the pressure on the hour today;
- The data of the previous day will be cleared at 00:00 the next day.
- Data synchronization logic: The data update needs to open the APP before it can be updated synchronously. It is necessary to ensure that the APP and the watch are paired and connected normally.

## Nucleic acid code

Requirement description: Nucleic acid code function, only supports domestic use, users can upload common nucleic acid codes through the app, which is suitable for accounting and collection in domestic epidemic environment, convenient and fast, one-click access.



- Shortcut bar: Click the nucleic acid code function entry, the user can go to APP-device-nucleic acid code function upload nucleic acid code;
- Default brightness: Only when the nucleic acid code has been uploaded, the default brightness is 50% when entering;
- Brightness adjustment: Only when the nucleic acid code has been uploaded, it supports sliding up and down and the knob to adjust whole brightness;
- Return: Exit the nucleic acid code interface brightness recovery;

## Body temperature



- The body temperature is present in the watch, and users can go to the APP application market to download and install the application.
- The APP supports uninstalling the corresponding device-side application. After clicking (uninstall), the device-side application icon will be set to Gray, when clicked, it will prompt "Please download this application in APP".
- When the user clicks to download in the APP, the device displays "Downloading" for 3s, and the download is complete. Enter the body temperature interface after re-logging for 1s.
- Hourly automatic measurement + manual detection (the app supports manual recording, and the data collection is based on the app flow).
- The watch side does not save the history record, the data is synchronized with the app, and the APP side can view the history record;

## Recharge

Please put the back of the watch on the wireless charger surface to start charging. The charging instructions are displayed on the watch screen.



## NOTE:

- Do not charge in a humid environment.
- Make sure the back of the watch is in full and clean contact with the wireless charger surface ;
- Clean the back of the watch and the wireless charger regularly with clean flannellette. Make sure the watch is fully in contact with the wireless charger surface to ensure proper charging ;
- This product is not equipped with a power adapter. To ensure the safety of your family and property, you can use a computer USB port or choose a power adapter with an output not exceeding 5V=1A when charging. Please purchase power adapters through formal channels, and avoid using low-quality, fake power adapters to avoid burning or fire.

## Bluetooth data transmission

When connected to a mobile phone, the watch will instantly synchronize some data with the mobile phone via Bluetooth, including weather, notification messages, sports health data, etc. After the connection is disconnected or Bluetooth is turned off, the data will not be synchronized.

## Precautions

- The measurement results of this product are for reference only, not for any medical purposes or basis. Please follow the doctor's instructions and never make self-diagnosis and treatment based on the measurement results.

## Basic parameters

Product name: smart watch  
Bluetooth: Bluetooth5.2  
Equipment requirements: Android 5.0 or iOS 10.0 and above  
Strap material: liquid silicone



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement  
The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.