SMART WATCH Y8 Use guide

1. Appearance description

On the key The horn Heart rate sensor the key Charging a Full touch display On the key the menu to change the style. Click on the non-dial interface to return to the dial interface Long press for 8 seconds to forcibly restart; In the shutdown state, long press for 3 seconds to start up. In the default screen state, click Off. Otherwise, the The key seconds to start up. In the default screen state, click Off. Otherwise, the en is on. Long press for three seconds to bring up the shutdown interface

The microphone Voice transmission function. During a conversation, you speak int microphone, which will convert the sound signal into an electrical For sound output, the horn converts electrical signals The horn

For sound output, the thorn into electrical signals
Measurement of human heart rate and blood oxygen value
(Note: measurement with blood oxygen function) Charging position After the charging cable is connected here, the unit can be charged

2. Charging instructions

Thank you for choosing our smart health watch. Please read it carefully before usin it for the first timeRead the instructions; First, long press the main function button for 3 seconds to start the machine, if the power is low or consumedYes, please charge it firs

After connecting the charging socket, insert the USB interface (such as computer portable power supply, Or a standard power adapter) for charging, requiring an in voltage of SVIA or SV2A.

As shown in the picture below:







3.Install "SZOS" APP

Watch interface can be scanned code dow

5.Connection status

Before using this device, please download the "SZOS" APP on your mobile phone and Do the installation. You can do this by using the "scan" in wechat or browser Function Scan the OR code of "Download APP" on the device and select the corresponding one on the mobile phone The operating system can be downloaded and installed; You can also browse the app in the App, Search "SZOS" in app stores such as Google and AppStore Download and install.



When you finish the appeal operation, slide at the top of the device dial interface, will The "Bluetooth" icon is filled, indicating that the connection is successful. As shown in the picture below:

4.Connect the watch

(1) Scan code connection

After you download the APP, enter the APP and click the upper right corner and select
Select the "sweep" function, press the button on the watch to enter the dial interface,
After swiping to the right on the left side of the dial, click "Connect phone"
Button, the two codes connected to the mobile phone will pop up, and then use the APP to
scanTrace this two-dimensional code and allow pairing. If your mobile phone is ios
unified, after the completion of the step, according to the MAC device in the Bluetooth
Address will classic Bluetooth connection (MAC address available in "Settings - About
Watch".

After Bluetooth is enabled on the phone, enter the app, click the "Device" page, and click Click "Add Device" then click the icon that appears, and finally click "Pair" At this point, the APP will automatically search for nearby devices, you just need to find the place Have the name of the device, click to match.

7.Dial style selection

1, the equipment itself provides a variety of dial for you to choose. When lighting the device, you can long press the dial interface of the device to enter the cutting Change the dial style function, sliding around can feel different dial style, when Once you have selected the dial style you want to use, click on the dial to proceed Replacement; You can also click the "Settings" function on the device and select Select "Screen Display" Select "Change dial" function to replace the dial. 2. The "dial Market" in the APP will give you more choices. When you use the APP to connect to the watch, it is available in the APP's "watch faceMarket" for downloading more types of dial, but also for dial/Delete it.
3. The APP also provides the function of customizing the dial. You can customize the dial in the "Device" function of the APP.

6.language

he equipment is available in many languages acluding:Simplified Chinese, English, French alian Portuguese WesternBania Polish Russian



8. Watch operation instructions

- Sidebar: Slide to the right on the left side of the dial interface to pull out the side Sidebar, provide a variety of shortcut function entry. pull down panel: at the top of the dial interface can slide, you can pull out op - down panel, provides a variety of shortcuts to function entry, and provides time sluetooth connection status, power display.
- Slide the notification up at the bottom of the nourishing surface of the dial to view the receivedNotification message of; Click the corresponding message to view or
- 4. Menu page: press the side key on the dial page to enter the menu page. After entering the menu page, double press the side button to switch the menu style. A one-sided key returns to the main dial page.
- Function page: Click the icon of each application on the menu page to enter the corresponding pageFunction, right slide back single press the side key to return to the main dial.

9. Function introduction Exercise: includes outdoor running, outdoor walking, indoor cycling, indoor running, Indoor walking, free exercise, a total of six routine exercise.

Heart rate: Put the watch close to the wrist, you can measure the real-time heart rate value, historical measurementThe results can be viewed in the APP.

Blood oxygen saturation: the watch close to the wrist, you can measure the bleeding oxygen value, calendarThe historical measurement results can be checked in the APP. Blood pressure: Put the watch against the hand bowl, you can measure the blood pressure

Activity record: Record the movement data of the day, including the number of steps and the time of the activityAnd calories. Sleep: Detect your sleep condition every night, sleep related data can be Check it out in the APP.

Music: Supports mobile phone music. Weather: After connecting the app, you can actually update the weather of the day.

Call History: When connecting a mobile phone, you can synchronize the call history of the mobile phone.

Common contacts: Connect mobile phones to synchronize mobile phone types of exercises.

Payment code: When connecting the mobile phone, click this function to receive other users directlyScan the code to transfer funds.

Take photos: Enter the APP after connecting the app and click the photo function on the watch. The photo taking function of APP side can be evoked to realize remote control of photo taking. Click on the Taking a photo one can evoke the taking hot function of the APP. Click again to take a picture. The photos will be saved to the phone system's album.

Friend Code: When the device is connected to the mobile phone, click this function to sca the code directly"Add friends"

Timer: Supports the countdown of a selected number of minutes and a customized time. Find the phone: When the device is connected to the phone, tap this function to find the hand Operation of the machine.

Common contacts: Connect mobile phones to synchronize mobile phone types of contacts.

Dial: The watch calls when connected to the mobile phone
Al voice: After connecting the APP, the hand can be aroused through the Al voice function of the watch Machine voice assistant.

Settings: including brightness Settings, screen-time, Do not disturb mode, sound Settings, Language switch, phone connection, about the watch, restart, restore factory,
Shut down and other functions.

Calculator: Provide calculation function, convenient and quick.

NFC: An emerging technology. Devices (such as cell phones) that use NFC technology Data exchange can be carried out in close proximity to each other and is made by non-contact shots-Frequency identification (RFD) and interconnect technology integration evolution. Shots-Frequency identification (RFD) and interconnect technology integration evolution: communication on a single chipWith the use of mobile terminals to achieve mobile payment, electronic tickeling, access control, Mobile identity identification, anti-counterfeiting and other applications.

Alipsy: Click the watch Alipsy interface to open, according to the watch binding my Watch interface prompts, complete Alipsy account and watch binding, complete binding After fixed, watch Alipsy account and watch binding, complete binding So, please ask the cashier to scan the payment code, in support of Alipsy apparpment field So, please ask the cashier to scan the payment code, in support of Alipsy apparpment field So, please ask the cashier to scan the payment code, you can complete the payment.

configurations, some do not have local music player, Alipay,
Friend code sharing, NFC, blood pressure, blood oxygen function, please refer to the actual configuration!

10. Instructions for adding/deleting/playing music 11. Precautions

- 1. First, you need to connect to the mobile APP.

 2. Add music. Click the APP to enter the "Music" function interface and click the lower left corner"Add Music", select music in "Local Music" or "Cloud Music", clickThe check mark in the upper right corner will download the selected music to the deviceYou can view it in the "Music" function of the device (required in the "Music" function Select "Watch Mode" in the lower right corner of the function interface).

 3. Delete music. In the "Music" interface of the APP, select the one you want to deleteAfter music. click "Delete music" in
- the one you want to deleteAfter music, click "Delete music" in
- the one you want to delete ther music, click Delete music in the lower right corner.

 4. Play music. The device provides two modes: Watch mode and Mobile modeln the lower right corner of the music function screen of the device, select the playing modeClick Play. Bluetooth headphone mode is also available.

shock station

1. Do not severely impact the host.

4. Keep away from direct light or heating appliances.

2. Do not touch benzene, diluent and other chemicals. Please keep away from strong magnetic field and electric

- 5. Do not disassemble, repair or transform by yourself.
- 6. Waste packaging, batteries and old electronic products should be sorted and properly disposed of.
- 7. Do not wear it in the shower. (Temperature shall not exceed 45 °C)

Note: According to the configuration, do not carry this function ignore!

12. Frequently Asked Questions and Answers

Why does blood pressure value have deviation with sphygmomanometer?

The deviation between the watch and the sphygmomanometer is due to a number of factors. Sphygmomanometer measurement site is in the cerebral artery, the watch measurement site is in the arteriolesThe two main branches, normal acritic blood pressure measurements and microarterial blood Pressure measurements can vary by three to forty; if you use a watch and a blood pressure monitor at the same time To measure, because the blood is flowing in the artery in the direction of centrifugation, a sphygmomanometerWhen measuring, the band puts pressure on your elbow below the center, temporarily bleedin The fluid does not flow smoothly to the underlying branches of the arteries; increased vascular tension, Will make the upper and lower blood pressure measurement value deviation will be greater.

Why not wear a watch to take a hot bath?

The temperature of the bath water is relatively high, which produces a lot of steam, andAnd water vapor is gas phase, its molecular radius is small, easy to watch the shell emptyThe gap seeps in, and when the temperature drops, it recondenses into liquid droplest,Easy to cause the watch internal circuit short circuit, damage to the watch circuit board, and damageA watch.

Why can't the watch receive notifications?

Android phone Settings: 1. Ensure that the message push function is enabled on the mobile client

1. Ensure that the message push function is enabled on the mobile client.
2. The confirmation message is displayed normally in the notification bar of the mobile phone and is pushed to the watchli is pushed by reading the notification message on the mobile phone. If the notification bar does not exist Message, the watch will not be able to receive push. (You need to find Tong in your phone's Settingsknow the Settings, turn on the notification switch of weehat, QO, phone, SMB and mobile phone client)
3. Open the auxiliary function Settings of the wristband client (find the auxiliary function in the mobile phone Settings). Function, open the function setting of the bracelet client)

Iphone Settings:

1. Ensure that the message push function is enabled on the mobile client

- 2. The confirmation message gas can be displayed in the notification bar of the mobile phone Normal display, (need to find the notification Settlings in the phone Settlings, open micro Notification switch for letter, QQ, phone, SMS, mobile phone client)



Warranty card

Product Name: Model and Specification:

Name of Customer:

Contact Number: Address:

Distribution Unit:

Contact Number:

Date of Sale: Address:

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- •Reorient or relocate the receiving antenna.
- •Increase the separation between the equipment and receiver.
- •Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- •Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.