英文

S50 User Manual



Microphone •

2. Charging Instructions Thank you for purchasing our smart health watch. Please read the instruction manual carefully when using it for the first time; first press and hold the main button of the watch for 5 seconds to turn it on. If the battery is low or exhausted, please charge it first.After connecting the charging cable, plug the USB interface into (such as a computer host, mobile power supply, or standard power adapter) for charging. The input voltage is required to be 5V1A or 5V2A.

3. APP Download and Wireless Pairing

1: APP Wireless Pairing
1. New users use the device for the first time, he/she needs to download and install the APP, launch the APP and register as required; after registration is completed, enter the account number and password to log in.
2. Turn on the wireless on your mobile phone, then connect the watch on the APP to complete the pairing. Step 2: Audio Wireless Pairing
Complete the audio wireless pairing, the steps are shown in the figure below.



4. Change Dial



Upper Button:
1.Long Press - Turn on/off the smart watch.
2.Short Press - Light up the screen/Enter the secondary menu. **Custom buttons:** 1. Short press to light up the screen; 2. Long press to enter the custom function interface. Swipe to Left: Move to the next interface.

5. Operating Method

Slide Up: Slide up the home screen to view the message.

6.Product Information

Chip: RTL8763EWE
Screen: 2.02" TFT Color Screen
Resolution: 320*390 Pixels
Waterproof Standard: 3ATM
Heart Rate Sensor: HX3918
Compatibility: for iOS 12.0/Android 9.0
and above

Battery Capacity: 400mAh
Working Time: 5-7 Days
Connection Method: Wireless 5.2
Material of Strap: Silicone
Working Temperature: -10°~50°C
Package Included: Smart Watch Body,
Charging Cable, Strap, User's Manual

7. Supported Languages

Languages Supported by the Smart Watch: Simplified Chinese, English, Russian, Spanish, German, Italian, French, Portuguese, Turkish, Hebrew, Arabic, Vietnamese, Thai, Farsi, Malaysian, and factory default English. Languages Supported by APP: English, Chinese Simplified, Chinese Traditional, German, French, Arabic, Czech, Greek, Spanish, Japanese, Farsi, Italian, Korean, Dutch, Polish, Portuguese, Russian, Finnish, Swedish, Thai, Hungarian, Slovak, Croatian, Albanian, Turkish, Ukrainian, Hindi, Malaysian, and more languages will be added continuously.

8.Main Functions

↑ Time ↑ Timer ↑ Sedentary Reminder ↑ Physiological Cycle ↑ Steps ↓ Find Your Phone ↓ Wireless Calling ☐ Calculator

↓ Distance ↑ Multiple National Languages ↑ Calories ↑ Heart Rate Monitor ☐ Play Music ☐ Drinking Water Reminder

↓ Siepe Tracker ↑ Multiple Sports Modes ↑ Breathing Training ↑ Compass ↑ Blood Oxygen Monitor ↑ Blood Oxygen Monitor

9. Precautionary Note

1. Prevent the watch from severe hit.
2. Prevent the watch from contacting chemicals such as benzene, thinner etc.
3. Prevent the watch from approaching strong magnetic field, electric shock station.
4. Prevent the watch from direct light or heat generating appliances.
5. Do not disassemble, repair or remodel by yourself.
6. Please properly classify and dispose the waste packaging, batteries and old electronic 7. Not suitable for bath taking wearing. (Temperature can not exceed 45 °C)

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.