

User Manual

2 Coils Fast Wireless Charger

Product Introduction

This standing wireless charger with simple design works with Qi standard mobile phone and devices.

There is no plug on the charging devices, which is more convenient and efficient.



Applicable Devices

• Compatible with phones:

Samsung: Note5, Note8, S6, S6 edge, S6 edge plus, S7, S7 edge, S8, S8 plus, S9, S9 plus

Apple: iPhone 8, iPhone 8 Plus, iPhone X

LG: G3, G5, G6, G6 plus

Lenovo: Moto Z

Nokia: Lumia830, Lumia920, Lumia1020, Lumia1520, Lumia930

Yota: Yota phone2

Google: Nexus4, Nexus5, Nexus6

Instructions

1. Charge the device with USB cable and QC3.0 or QC2.0 power adapter (adapter is not included).



NOTE: Our wireless charger can also connect to laptop and desktop motherboard USB port for normal charging, but only by using QI quick charge adaptor can supply quick wireless charging.

2. Place the phone with wireless receiver built-in on the wireless charger, the LED indicator will light on (begin the light is blue, during charge the light turn red) Light turn off wen full battery. But when charge for iPhone, light will not turn off when full battery.



Product Specification

Input: 12V-1.5A / 5V-2A

Output: 9V-1A / 5V-1A

Charging Efficiency: 75%

Standard Accessories

Wireless Charger

USB Cable

User Manual

NOTE: Power adapter is not included, please purchase separately.

Attention

1. If you need to clean the charger, please make sure it is not connected power supply.
2. Using Environment temperature remains -20~45°C

3. Do not squeeze or collisions.
4. Do not disassemble or throw into fire or water, to avoid causing a short circuit leakage.
5. Do not use wireless charger in severely hot, humid or corrosive environment, to avoid circuit damage and occurs leakage phenomenon.
6. Do not place it too close with magnetic strip or chip card such as ID card, bank cards to avoid magnetic failure.
7. Please keep the distance at least 20cm between implantable medical devices (pacemakers, implantable cochlear, etc.) and the wireless charger, to avoid potential interference with the medical device.
8. Please make ensure children won't play the wireless charger as a toy, to avoid unnecessary accidents.

ZOEVIEW

E-Mail: support@zoeview.com

CE **FC** **RoHS**
COMPLIANT



MADE IN CHINA

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.