

## Ensuring the Sensor is Clean

- Clean the Sensor with a damp cloth, baby wipe or alcohol wipe regularly.
  - Ensure that the clear windows at the back of the Sensor are free from dirt to enable it to function well.
- ⚠ Warning: Do not submerge in water.**



## Important Safety, Compliance and Warranty Information

Please read in full before product use.



### Safe Usage Guidelines

- This product is suitable to use from birth to 12 months of age.
- This product is not a substitute for adult supervision and is not a Medical Device.
- Do not submerge this product in water. Clean only with a damp cloth, baby wipe or alcohol wipe.
- **CAUTION:** This product is not a toy and should be placed and used only as intended. Do not allow children to handle or play with this product. To prevent mouthing or chewing, keep out of reach of children.
- This product contains a non-replaceable and non-rechargeable battery. Do not attempt to open this product and to remove or replace the battery. When the product no longer operates, please dispose in accordance with the local waste and recycling guidelines in your city or municipality.
- **⚠ WARNING:** This product contains a Button or a Coin Cell Battery. A swallowed Button or Coin Cell Battery can cause internal chemical burns in as little as two hours and lead to death. Dispose of this product when it no longer operates immediately. Keep new and used batteries away from

children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

- Do not press on or bend the product with excessive force.

### IP Rating (per IEC 60529): IPX4

### Disposal of waste batteries.

This product contains a battery, do not dispose this device with other household waste. Instead, hand over to the appropriate collection point for recycling in accordance with local and municipality disposal and recycling guidelines.

### Disposal of Electrical & Electronic Equipment.

This symbol indicates that this product should not be treated as household waste. Instead hand it over to the appropriate collection point for the recycling of electrical and electronic equipment which will conserve natural resources. Ensuring proper product disposal prevents potential negative consequences for the environment and human health, which may be caused by inappropriate handling. For more information, contact your city or your local household waste disposal service.

### FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### FCC Caution

- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- The antenna(s) used for this transmitter must not be co-located or operate in conjunction with any other antenna or transmitter.

### Limited Hardware Product Warranty – A Summary

The limited warranty only covers product defects caused by workmanship or build materials. The duration of this warranty is within one year from date of purchase.

See [www.lumibypampers.com/warranty](http://www.lumibypampers.com/warranty) or call us at 1-833-Lumi4Me (833-586-4463) for additional warranty information about your product including procedures to act on a warranty claim.

Procter & Gamble's entire liability and your exclusive remedy for any breach of warranty shall be, at Procter & Gamble's option, to repair or replace a functional equivalent of the product, or to refund the price paid, if the hardware is returned with the original packaging and original receipt to an address to be defined by our customer service agents available at 1-833-Lumi4Me (833-586-4463).

### Need Assistance?

Visit us at [www.lumibypampers.com/](http://www.lumibypampers.com/) help or call us at 1-833-Lumi4Me (833-586-4463).

© 2019. The Lumi by Pampers™ name and logo and the Lumi bunny™ logo are trademarks of Procter & Gamble. TestFlight® is a registered trademark of Apple Inc.

Designed in San Francisco. Distributed by Procter & Gamble, Cincinnati, OH 45202, United States of America Made in CHINA.



## Soft Touch Sensor Quick Start Guide



## Welcome to the Connected Care System



Getting started is quick and easy.

1. Download the TestFlight® app from your TestFlight e-mail invitation.
2. From the TestFlight app, install the Lumi by Pampers™ app.
3. Open the Lumi by Pampers™ app and follow the on-screen set-up instructions.

## What's in the Box



1 Soft Touch Sensor

Each Sensor's battery is designed to last around 3 months. You can view the status of the battery in the app.

**⚠ Warning: Battery is non-replaceable and non-rechargeable. Do not attempt to open this product.**

## Features

The Soft Touch Sensor works exclusively with the unique Lumi by Pampers™ diapers to automatically track:



Wet diapers



Sleep

## How to Attach the Sensor

- With each diaper change, attach the back (white side) of the Soft Touch Sensor on the dotted outline on the Lumi by Pampers diaper. Make sure the Lumi bunny is upright.



- Gently press the Sensor onto the diaper to ensure it is attached properly. We recommend to attach the sensor before putting the diaper on your baby.
- Move the Sensor to a new diaper with every diaper change. Remove it by gently peeling it off the diaper.
- Use only with Lumi by Pampers™ diapers and only as intended.

## Need Assistance?

Visit us at [www.lumibypampers.com/help](http://www.lumibypampers.com/help) or call us at 1-833-Lumi4Me (833-586-4463).

90516156

lumi  
by Pampers™  
connected care system

## Welcome to the Connected Care System



Getting started is quick and easy.

1. Download the TestFlight® app from your TestFlight e-mail invitation.
2. From the TestFlight app, install the Lumi by Pampers™ app.
3. Open the Lumi by Pampers™ app and follow the on-screen set-up instructions.

## What's in the Box



2 Soft Touch Sensors

Each Sensor's battery is designed to last around 3 months. You can view the status of the battery in the app.

**⚠ Warning: Battery is non-replaceable and non-rechargeable. Do not attempt to open this product.**

## Features

The Soft Touch Sensor works exclusively with the unique Lumi by Pampers™ diapers to automatically track:



Wet diapers



Sleep

## How to Attach the Sensor

- With each diaper change, attach the back (white side) of the Soft Touch Sensor on the dotted outline on the Lumi by Pampers diaper. Make sure the Lumi bunny is upright.



- Gently press the Sensor onto the diaper to ensure it is attached properly. We recommend to attach the sensor before putting the diaper on your baby.
- Move the Sensor to a new diaper with every diaper change. Remove it by gently peeling it off the diaper.
- Use only with Lumi by Pampers™ diapers and only as intended.

## Need Assistance?

Visit us at [www.lumibypampers.com/help](http://www.lumibypampers.com/help) or call us at 1-833-Lumi4Me (833-586-4463).

lumi  
by Pampers™  
connected care system

91334897