

Fitkid lift

FK-TWJ1510D

FCC ID:2AGF7FK-TWJ1510D

Smart mate for kid, more intelligent & healthier

- Preparation: Take out square magnet and oval magnetic bracket, download 'Fitkid' APP.
- First starting up: Press the square magnet for once, green light is on, that is, complete manual starting up for the first time.
- Auto start-stop: After the completion of manual starting up for the first time, the machine enters into auto on and auto sleep mode without manual starting up and shutdown again.
- Step 1: Wear on the 1cm below the collarbone (if adults, about 2 cm), square magnet is adhered outside clothes, and oval magnetic bracket is next to the skin inward and absorbed to surface of clothes.
- Step 2: Open the APP, match hardware according to system prompt until successful connection.
- Wearing clothes matched is suggested to be little flexible underclothes, then monitoring effectiveness will be the best.
- Adsorbed to loose clothing, not being absorbed to human body, not

being adsorbed to the correct position and not getting correct posture are likely to affect monitoring accuracy.

- In the APP-settings, complete personal settings and equipment settings.
- In the APP-settings, set class schedule, that is, children's work and rest time. According to your setting, it is automatically monitoring posture mode by default during class time, and will automatically switch to step calculation mode at other time.
- In the APP-settings, set remind cycle, namely, it will remind the wearer to adjust posture at regular intervals by means of vibration.
- Ensure that the above steps have been completed.
- Maintain ideal posture.
- Continuously press the square magnet for 2 times, then completing sitting posture calibration.
- If needing to adjust posture accordingly because of scene changes, then sitting posture calibration should be carried out again.
- In the APP-settings, can query battery remaining capacity.
- If needing to charge, please charge by putting the oval magnetic bracket on charging bracket, contact direction is as shown in the picture.
- When charging, red light is on, charging is completed, and then green

light is on.

Welcome to follow our official after-sales, so that you can get our information of presents for sharing, upgrade free, credits exchange, free trial and new product release, etc.



Official website: www.o2omama.com

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.