

 Real time vehicle & maintenance notifications

 GPS enabled to locate your car

 Easy

STEP 1



Download The Motion App

The Motion app is available for free on the Apple App Store and on Google Play. Search for **'Motion by Mojo'** in your app store or

visit www.moj.io/getmotion

Tip: Make sure you are running the latest version of your operating system and that your phone meets the technical requirements.

STEP 2



Create Your Account

Run the Motion app on your smartphone, press 'Sign Up' on the home screen, and follow the prompts to create your new Mojio account.

You will be asked to verify your mobile phone number via SMS. The app will walk you through the rest of the steps.

Tip: To create a new account, go to the Mojio app and select "Create New Account".

STEP 3

account creation. The app will walk you through the rest of the steps.

create



Insert The Micro-SIM Card

Use the included tool to eject the tray for the SIM from the the SyncUP DRIVE™ device. Position the micro-SIM card in the tray so that itsits flush and insert the tray.

STEP 4



Scan The IMEI Barcode

Your SyncUP DRIVE™ device has a unique 15 digit code called the IMEI. The code is shown as a barcode on a sticker on the device. You will find the IMEI on the sticker on your device .

When prompted, use the Motion app to scan

the barcode or manually enter the IMEI code.

STEP 5

Tip:
unti

ir car



Locate Your OBD Port

The OBD (On Board Diagnostics) port is usually located underneath the driver's side dashboard, often within 18 inches of the steering wheel.

If you are having trouble locating your car's OBDport, the Motion app can help you find it.

STEP 6

Tip: Plug the device into the Motion app to ensure a proper connection when s



...in the Motion app's flashlight port.

Install Your Device

Now that you've found your OBD port, you are ready to install the device.

Align your device with the port and firmly plug the device in. It should fit snugly.

Tip: To ensure a snug connection, be sure to properly align the device with your OBD port before plugging it in.

STEP 7

Go For A Drive

The device needs to establish its cellular connection and generate a GPS lock.

Go for a 10 minute drive to finish setting up your device. Motion will notify you once a successful connection is established.

Distracted driving is never OK. Do not use your phone while driving.

Tip: Do not unplug the device within the first 24 hours after installation



Understanding Your OBD-II Device

- 1 Device reset hole
- 2 Micro-SIM card slot
- 3 Restart key
- 4 LED 1

5 LED 2

6 OBD-II interface

LED Status Lights

LED INDICATOR


LED STATUS

 LED 1 (Power) Green blinking


The device is being powered by the internal battery

 LED 1 (Power) Green solid

The device is being powered by the vehicle

 LED 2 (Signal) Red solid

The device is on but is not connected to the cellular network

 LED 2 (Signal) Green solid

The device is connected to the 4G network but no data is being transferred



LED 2 (Signal)

Green blinking

The device is connected to the 4G LTE network and data is being transferred

Legal

Copyright © 2020 GoSunCN CORPORATION. All rights reserved.

No part of this publication may be excerpted, reproduced, translated or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of GoSunCN Corporation.

The manual is published by GoSunCN Corporation. We reserve the right to make modifications on print errors or update specifications without

prior notice.

Mojio, Mojio Motion, Made for Mojio, Powered by Mojio, and the Mojio logo are trademarks and registered trademarks of Moj.io Inc. Moj.io attributes © 2016 Moj.io Inc. All Rights Reserved.

See www.moj.io for additional information, including privacy policy and terms and conditions of use.

Support

Need more help? Get in touch with Mojio General Customer Care & Technical Support. Customer Care representatives are available daily from 3:00am to 10:00pm PT.

Here's how to reach us:

If you are calling about a technical issue with your Mojio service, please call from a different phone so that we can troubleshoot with you.

Call Us - TTY

TTY service is available for the hearing and speech impaired. Hours are 5:00am to 10:00pm PT, daily.

Call us via TTY toll free at 1-877-296-1018

For access to our Mojo Support Community, visit:
<https://support.Mojio.com>

Start Guide

