# Artificial intelligence

## simultaneous instant translation machine

is born for the exchange of translation [It's easier to communicate without language barriers] MODEL: GAZEGOT-1 FCC ID: 2ARHJ-GAZEGOT



趣科技 凝



Because of intelligence, we not only break through, but also broaden our vision, so we create a more convenient cross-boundary communication tool, "a tool to translate the language as soon as we speak", without the need to type, just to say what you want to say, it is so easy.

### Product features

- Intellectual property patent voice-translation system and processing device, market exclusive applications
- ·Instant visual interface design, easy to operation
- •Press the up or down key to translate the language,Press the down key to translate own language.Press the up key to translate the other language
- •The translation language and grammar database keeps updating, keeping pace with The Times and enjoying free language upgrading

·Supports 38 languages and continues:

Arabic, Polish, Danish, German, Russian, French, Canadian, French, Korean, Dutch, Czech, Romanian, Portuguese, Japanese, Portuguese, Brazil, Swedish, Thai, South American, Spanish, Greek, Spanish, Hungarian, Italian, English, Chinese traditional, Chinese simplified, Chinese Hong Kong cantonese, Indonesian, English, Australian English, Indian, Catalan, English, American, Hebrew, Hindi, Norway, Slovakia, Finland,Vietnamese, Malay, Turkish



#### Basic use guide

·Switch machine

Changan power supply key 2s. The screen lights up the power drawing, until the standby page can be used normally.

Turn off the machine and press the power button for more than 2s.

·Display Screen

Touch screen operation to enter the next menu or select the translation language.

The WIFI network is displayed when the data card is not inserted

Over the top of the screen, the wifi is displayed when the network is connected, , which shows that the power is presented by the battery pattern

Lock

Press the power button to lock the machine, and press unlock again. The translation machine is not operated (time based on user's custom) for a certain amount of time.

·Automatic translation

Press the button below, listen to the prompt and enter the first language of speech. After release, you can play the second choice of language translation results.

Press the button on the top, listen to the prompt and enter the second select language, then play the first choice of language translation results.

Touch screen selection, the left side is the first choice language, the right side is the second choice language, the double arrow in the screen clicks the first second language switch.

·The volume button

Side keys adjust volume, click the volume to reduce the key to the minimum silent mode. •Reset

At the same time, press the power button and the volume reduction button, and the interpreter restart.



## Product parameters

The	WIFI	USB	Micro 5Pin USB(Support 1.5A
wireless			fast charge)
network			
bugle	2030BOX	battery	1300 mAh
The	5V/1A		
adapter			

Software Support

Ningqu Technology



### Safety precautions:

battery:

Translator battery only accepts Contruction Technology or Cocoa Technology authorized service providers to replace, do not disassemble, replace or change without authorization.

Operation:

The product components contain metal, plastic and internal sensitive electronic components. If it is thrown, burned, pierced, squeezed or exposed to chemical liquids, it can lead to damage.

maintenance:

Please do not disassemble the interpreter and try to repair it on its own. If there is any damage, failure or contact with liquid, please contact customer service.

Using the environment:

Avoid using a translator in an environment of too high or too low temperature to avoid prolonged exposure to the sun. Please keep the interpreter and power adapter in a well-ventilated environment to avoid metal corrosion.

charging:

Using a cable and power adapter; Or in line with the national 3C certification input:  $100-240v \sim 50/60hz0.2a$  output Qutput:5V== a standard of power supply. Please check the power adapter manufacturer carefully to find out if it meets the requirements.

Operating temperature:

Translation machine is suitable for the temperature between 55 ° to 10 °  $\sim$  work environment, if working environment over the temperature range, translation machine may lead to failure, and shorten the battery life, please avoid direct sunlight, heat, cold, damp environment use.



### Precautions for use:

To ensure the quality of translation and the integrity of the sentences, press the translation key and then, after 1 second, you will be asked to translate the sentence.Please use normal speed to speak coherently, please do not stop many times during the speech, or two sentences and say that the above situation is easy to cause the translation is not allowed, please try to avoid.Try to avoid catchphrases or local slang.

After talking, you can check what you have said through the text displayed on the screen. When using a translator for charging, the heat of the machine is normal.

If you choose Chinese recognition, but the translation is not accurate, you can try to change another expression.



## Common problems

1、 The product can't	•Check whether the electromagnetic charge is on commission and insert charging line to charge the product.
start?	<ul> <li>Press the power button and release it to determine whether the boot screen is open normally.</li> </ul>
2. Voice recognition is	<ul> <li>Please press the button to hear the prompt and then speak. After that, please release the key.</li> <li>please speak standard language and avoid using</li> </ul>
not accurate?	dialect or slang. · speak in a coherent, clear, natural way and avoid multiple pauses or merging statements₀
3、 Unable to connect	<ul> <li>Make sure to connect to WIFI properly and enter the correct password.</li> <li>currently, there is no support for the WIFI source that</li> </ul>
to WIFI?	needs to be logged in, such as hotels, airports and public places.
4 Can't normal	<ul> <li>Check for the correct matching power adapter.</li> <li>check whether the wires and interfaces are properly connected.</li> </ul>
charge?	
5. How to maintain the	press the shutdown key to disable the machine when not in use. , avoid - 10 $^{\circ}$ ~ 55 $^{\circ}$ outside the temperature range of use.

	$\cdot$ this product is not waterproof, please do not put the
product properly?	product into the water.



## FCC ID: 2ARHJ-GAZEGOT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter

