



Instructions

1、Press and hold the function button for 1 second to start the machine and enter the Bluetooth matching mode, Press and hold the function button for 2 second to shut down. Before using this product, please ensure that your matching tablet is in normal working power state.

2、The connection free stylus can be used immediately.

Function keys and Bluetooth

1、On the tablet, click [Settings] - [Bluetooth] - turn on the Bluetooth switch - [Find Other Devices] and find the name Click [Pencil] device adaptation.

- Single click: Return to the background
- Double click: Current screen shot
- Clicks three times: Using remote shutter in camera mode

Power management plan

●If the device is stationary for more than five minutes, it will automatically shut down.

Warranty terms

- 1、This product is guaranteed for 12 months.
- 2、The dealer or sales channel can be consulted for assistance in the delivery of insurance.

Adapting equipment

Compatible with all iP tablets manufactured in or after 2018.

Matters needing attention

- 1、Do not use this product on other surfaces other than the screen to avoid damage to the screen caused by the wear of the pen tip.
- 2、Please keep the pen tip clean when using, dust or particles may affect the touch effect.
- 3、The nib will wear out due to long-term use and friction, please replace the nib regularly to avoid damage to the screen.
- 4、Please keep the pen out of the reach of children or pets to avoid other injuries caused by accidental swallowing by children or pets.
- 5、The pen contains sensitive electronic components (including batteries), please be careful when using it. If you accidentally drop, burn, bend, destructively squeeze or come into contact with liquids, it may cause damage to the product or cause personal injury, such as the product damaged, do not use.

- 6、Do not use any solution or liquid to clean this product, so as to avoid the solution or liquid flowing into the product during cleaning, which will cause the product to get wet or damage the internal components.
- 7、Some screen stickers may affect the writing experience.
- 8、Radio frequency radiation from electronic equipment may adversely affect the operation of other electronic devices, resulting in device failure. Personnel carrying implanted or external electronic therapy equipment are prohibited from using it.
- 9、The touch pen is not used for a long time, it is recommended to charge it once a month

关于指示灯 About the indicator

红灯闪烁（低压保护） Red light flashing (low-voltage protection)
红灯常亮（充电提示） The red light is always on (charging prompt)
蓝光闪烁（蓝牙适配状态） Blue light flashing (Bluetooth matching status)
绿灯常亮（正常工作状态） The green light is always on (normal working state)

产品规格 Product Parameters

产品型号 Product Model	AC10 - S AC10 - S
电池容量 Battery Capacity	130mAh 130mAh
充电时间 Charging Time	≤14 分钟 ≤14 mins
工作时间 Working Time	≥10 小时 ≥10 hours
配件内容 Product List	电容笔 Stylus Pen 充电线 Charging cable 替换笔尖 Replacement Nib 说明书 Instruction Manual



使用说明

- 1、长按功能键1秒开机且进入蓝牙匹配状态，长按功能键2秒关机。在使用本产品之前请确保您所匹配的IP平板电脑处于正常可工作电量状态。
- 2、无需驱动，开机可立即使用。

功能键和蓝牙连接

- 1、在平板电脑依次点击【设置】-【蓝牙】- 打开蓝牙开关 - 【查找其他设备】并且找到名称为【Pencil】的设备点击适配。
- 单击：返回后台
 - 双击：当前屏幕截图
 - 三击：相机模式下使用遥控快门
- 2、通过蓝牙连接设备可在小组件中设置并查看【Pencil】电量。

电源管理方案

- 5分钟静置不使用自动关机。

保修条款

- 1、购买本产品享有12个月非人为质量保修。
- 2、送保可寻求经销商或销售渠道进行协助。

适配设备

兼容2018年（包含2018年）或之后上市的所有IP平板电脑。

注意事项

- 1、切勿在屏幕以外的其他表面使用本产品，以免笔尖磨损导致损坏屏幕。
- 2、使用时请保持笔尖干净，灰尘或微粒可能会影响触碰效果。
- 3、因长期使用摩擦会导致笔尖磨损，请定期更换笔尖以免损坏屏幕。
- 4、请将笔放置在儿童或宠物接触不到的地方，避免儿童或宠物误吞或导致其他伤害。
- 5、笔内包含敏感电子元件（含电池），使用时请小心，若不慎跌落、焚烧、弯曲、破坏性挤压或接触到液体，可能会对本产品造成损坏或导致人身伤害，如产品破损，请勿使用。
- 6、请勿使用任何溶液或者液体清洁本产品，以免溶液或液体流入产品内部导致产品受潮或损坏内部元件。
- 7、部分屏幕贴膜可能会影响书写体验。
- 8、电子设备的射频辐射可能对其他电子装置作业产生不利影响，导致装置出现故障。携带植入或外置电子治疗仪器人员禁止使用。
- 9、触控笔长时间未使用，建议一个月充一次电

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.