Quick Guide

Function Introduction



Sport

Enter the sports mode selection interface, and click again to start the corresponding sports mode data detection: sports time, distance, calories, heart rate and other data.



Breathing training

You can set the time and rhythm of breathing training, and then click to start breathing training

Smart Watch



Count the activity data of the day. The number of steps per day can be set in the APP to reach the standard value, and the watch also has a prompt of reaching the



Stopwatch

Start and end the stopwatch.



Dial

Connect the mobile phone with Bluetooth to dial out, and you can make a call at the watch end.



Calculator

Numeric calculations are possible.

Please read this manual carefully and reserve it for use

03

Touch and key



Sliding: control panel Slide up: SMS notification Right slide: custom card Left slide: shortcut function

Short press: light the screen, return to the dial interface, and enter the menu interface Long press: enter the system menu



Heart rate

wear it is on the wrist bone above the arm. The real-time heart rate value can be measured. The normal value of the average person is 60-100 times/minute. You can also view the heart rate record.

Put the watch close to the wrist, and the best place to wear it is above the wrist bone and arm. Real-time blood pressure can be measured. Adult diastolic blood

pressure: 60~80 (mmHg), adult systolic blood pressure:



Music

It can control the playback of music in the phone,



Voice Assistant

When connecting the mobile phone Bluetooth, click to talk to realize remote control



You can customize the alarm clock and delete it.



Alarm



Including dial switch, brightness adjustment, language setting, password lock and other functions.



Blood oxygen

Blood pressure

Put the watch close to the wrist, and the best wearing position is above the wrist bone and the arm. The real-time blood oxygen value can be measured, and the normal range of the value is generally 95% to 100%



06

If the power-on fails after pressing the power button for 3 seconds, please try again after charging.

Connect to phone



You need to download and install the CO-FIT PRO application on your phone. CO-FIT APP supports iOS 11.0 and Android 5.0.

- 1. Open the mobile phone Bluetooth, open the app registration login to enter
- 2. Pair the watch with the APP. When pairing, please ensure that the watch and the APP can communicate with each other (synchronize data); Open
- 3. In the search binding list, select the HK89 with the strongest signal and click Pair. At this time, the Bluetooth icon on the watch is blue, indicating that you

4. Bluetooth 3.0 connection mode:

- IPhone users support Bluetooth 5.0+3.0 dual Bluetooth one-button link (follow the system prompt box when matching)
- 1. The Android user system will pop up Bluetooth pairing request, check the prompt permission, and click "pairing" to complete Bluetooth 5.0+3.0
- If the Android user system does not pop up a Bluetooth pairing request, you need to click "unbind" in the "call service pairing option" in the Bluetooth pairing prompt interface, and then follow the interface operation prompts to complete the Bluetooth. Subsequent links to the mobile phone will generate memory for the watch 3.0 Bluetooth, so as to realize the double Bluetooth one-button link (if Bluetooth 3.0 is not automatically connected, please manually search the Bluetooth watch model "HK89" on the mobile



It can push the content of real messages, such as SMS, QQ, WeChat, etc. (the system above IOS12 will block the SMS reminder by default).



Sleep

Turn on sleep detection to detect sleep quality during sleep, and view data such as sleep duration, deep sleep and light sleep.



If the APP is not connected, enter the weather display prompt, and the current weather temperature will be displayed after connecting the APP.



calendar

View the calendar.

Matters needing attention

- Do not disassemble, repair, or modify the product without authorization.
- Do not violently bump the product, so as not to cause damage to the product.
- Please avoid strong magnetic field, direct light or high temperature environment.
- This product is not used for disease diagnosis, treatment and prevention purposes.
- The waterproof rating of this product is IP68, avoid prolonged immersion in water.
- Please avoid wearing the watch strap too tightly and keep the place where the watch comes in contact with the skin clean.
- Children please use this product under the guidance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

— Reorient or relocate the receiving antenna.

— Increase the separation between the equipment and receiver.

— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

— Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Radiation Exposure Statement

The devices has been evaluated to meet general RF exposure requirement, the devicecan be used in portable exposure condition without restriction.