

Advisory

Important Information

Read the following information carefully before using this product. This adjustable base and pump has been quality-engineered with design features to optimize your comfort and safety when operated properly.

Product Ratings

The bed lift motors are not designed for continuous use. Reliable operation and full life expectancy will be realized as long as the lift motors do not operate any more than 2 minutes within a 20 minute period, or approximately 10% duty cycle.

Any attempt to circumvent or exceed product ratings will shorten the life expectancy of the product and may void the warranty. The recommended weight restrictions for FlexFit adjustable bases are as follows: DC equipped- 600 lb all sizes. The bed will structurally support the recommended weights distributed evenly across the head and foot sections. This product is not designed to support or lift this amount in the head or foot sections alone. Note: Exceeding the recommended weight restrictions could damage the adjustable bed and void the warranty. For best performance, consumers should enter and exit the adjustable bed with the base in the flat (horizontal) position.

Caution: DO NOT SIT ON THE HEAD OR FOOT SECTIONS WHILE IN THE RAISED POSITION.

Operation Information

- After bed assembly is complete, operate remote to ensure proper bed functions
- Keep moving parts free of obstruction (including sheets, clothing, tubing, wiring and products using electric power cords) during operation.
- Distribute body weight evenly over bed surface. Do not place entire weight on raised head or foot sections of the bed, including during repositioning and entering or exiting bed.

Small Children/Pets Warning

CAUTION: Immediately dispose of packaging materials as it can suffocate small children and pets. To avoid injury, children or pets should not be allowed to play under or on the bed. Children should not operate this bed without adult supervision. Keep bed in sight during operation to ensure safety and avoid injury.

FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any attempt to make changes or modifications to the product (e.g., an intentional radiator) could void the user's authority to operate this product according to FCC certification.

Hospital Use Disclaimer

Caution: This base is designed for in-home use only. It is not approved for hospital use and does not comply with hospital standards. Do not use this base with the tent-type oxygen therapy equipment or near explosive gases.

Service Requirements

NOTE: Service technicians are not responsible for moving furniture, removing headboards and footboards or any items required to perform maintenance on the adjustable bed. In the event the technician is unable to perform service due to lack of accessibility, the service call will be billed to the purchaser and the service will have to be rescheduled.