

# Hearing Aid Compatibility

## *HAC information.*

Your phone is designed for Hearing Aid Compatibility (HAC) and uses many settings for optimized use with hearing aids.

### *To choose HAC setting*

Choose the setting in the phone to match the setting in your hearing aid before making or receiving calls in HAC operation.

► **Settings ► the General tab ► HAC** and choose an option:

- **T-coil Mode** – optimize phone to hearing aid set in T-coil mode.
- **Mic. Mode** – optimize phone to hearing aid set in Microphone mode.
- **Off** – turns off HAC operation.

# Calling

*Calls, contacts, voice control, call options.*

## **Making and receiving calls**

Before you can make or receive any calls, you must turn on your phone and be within range of a network ► **6 Turning on your phone.**

### **Networks**

When you turn on the phone, it automatically selects your home network if this is within range. If it is not within range, you may use another network, provided your network operator has an agreement that allows you to do so. This is called roaming.

Select the network to use, or you can add a network to your preferred networks. You can also change the order in which networks are selected during an automatic search.

### **To view available network options**

► **Settings ► the Connectivity tab ► Mobile Networks.**

Some network operators allow you to switch networks manually, as searching for unavailable networks consumes battery power.