

Anthony
catrv 8/02/01



home

Many households will need emergency services at some time. Finding a location at night can be difficult because houses and apartments are sometimes poorly numbered or hard to see in the dark. Doctors emphasize that in an emergency seconds count. The sooner an EMT arrives in a medical emergency, the sooner the victim can be helped. When someone is hurt or needs emergency attention, it is important that they are not left alone while the family member stands outside trying to direct the EMT to the victim. With the Emergency Locator Light, a family member or friend can stay with the victim to offer help and comfort instead of directing the emergency vehicle to the location of the victim.

The Emergency Locator Light is the Easy & Affordable Solution!

Instructions for use:

Batteries:

1. For the Locator Unit: insert 1C battery (powers the light), and 2AA batteries (power for the remote control receiver).
2. Note: All batteries must be installed for unit to operate.
3. For the Remote Control: 1 12v battery is already installed in the unit.
4. Note: As with any battery powered unit, it is important to change the batteries frequently.

Choose a location:

1. Be sure to mount the locator to a window that is easily seen from the street and is not hidden by trees, bushes or other obstructions.
2. Clean window surface. Pull down suction cup lever located above the red triangle button; firmly press the suction cup to window and close lever.

Remote Control:

1. Keep the remote control in an easy to reach place, for instance near a phone. The remote control is designed to work a distance of 35 feet from the Locator unit. Because all homes are different, it is recommended to test the remote control from various locations in your home to confirm that the unit will turn on.
2. To activate with the remote control, simply press the red triangle button on the remote control unit.
3. To activate manually, press the red triangle button on the locator unit.
4. To turn the unit off, press the red triangle button on the locator unit.
5. Note: The remote control will only turn the unit on, you must turn the unit off by pressing the red triangle button on the locator unit.

Questions: call 1-877-273-7225

INSTRUCTION TO THE USER

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- * Reorient or relocate the receiving antenna.
- * Increase the separation between the equipment and receiver.
- * Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- * Consult the dealer or an experienced radio/TV technician for help.

In order to maintain compliance with FCC regulations, shielded cables must be used with this equipment. Operation with non-approved equipment or unshielded cables is likely to result in interference to radio and TV reception. The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.