

USER GUIDE

para español, flip over

CONTENTS

FARADAY ANATOMY	Page 4
POWER UP	6
1 GET COMFORTABLE	8
2 GET CONNECTED	11
3 GET TALKING & MORE	14
4 GET APPS & UPDATES	17
SAFETY INFORMATION	19

VISIT JAWBONE.COM/SUPPORT FOR TUTORIAL VIDEOS AND DOCUMENTATION IN OTHER LANGUAGES

FARADAY ANATOMY

HARDWARE

TALK BUTTON

MICRO USB

LED RING

ON/OFF SWITCH

VOICE ACTIVITY SENSOR

IF THE LED RING IS . . .

FLASHING WHITE

Jawbone is trying to connect to your phone.

FLASHING RED

Battery is low. Power up!

FLASHING RED + WHITE

Jawbone is in pairing mode and ready to connect to your phone. Go to your phone's Bluetooth® settings to connect.

POWER UP

GET JUICED

Your Jawbone is partially charged and ready to use right out of the box.

FOR A FULL CHARGE

Plug it into your wall charger or a USB port on your computer.

格式化：字型：(英文)新細明體，(中文)新細明體

格式化：字型：(英文)新細明體，(中文)新細明體，12 點

TO HEAR REMAINING BATTERY LIFE

Press the **TALK BUTTON** when not on a call.

LED RING

WHEN BATTERY IS LOW

The **LED RING** flashes **RED**.

WHEN FULLY CHARGED

The **LED RING** turns **WHITE**.

NOTE It takes [27](#) minutes to get your Jawbone 80% charged [in Fast Charge Mode](#). A full charge takes [60](#) minutes [in Fast Charge Mode](#).

TECH SPECS

TALK TIME Up to 4.5 hours

STANDBY More than [8](#) days

RANGE 33 feet (10 meters)

1 GET COMFORTABLE

1.1 FIND YOUR FIT

Mix and match to select the most comfortable and secure fit option. **EARLOOP** OPTIONAL

1.2 DROP, TWIST, & POINT

1 For the most secure fit, place your Jawbone in your ear pointing down.

2 Then, twist it upwards so it points directly at your mouth.

1.3 ENSURE BEST QUALITY

Jawbone works regardless of position, but you will get the best performance if the Voice Activity Sensor physically touches your cheek and points directly at your mouth.

VOICE ACTIVITY SENSOR

Watch video tutorials at JAWBONE.COM/FIT

2 GET CONNECTED

2.1 PREPARE YOUR JAWBONE

1 Press & hold the **TALK BUTTON**

2 Slide the **POWER SWITCH** on

3 Wait for the **LED RING** to flash red & white

4 Release the **TALK BUTTON**

2.2 PREPARE YOUR PHONE

Turn on Bluetooth®.

ON AN IPHONE®

Go to **SETTINGS > GENERAL >** and enable **BLUETOOTH ON A BLACKBERRY®**

Go to **SETTINGS/OPTIONS > BLUETOOTH** and enable **BLUETOOTH OTHER CELL PHONES**

Go to **JAWBONE.COM/PAIRING** or review the instruction manual that came with your phone.

2.3 MAKE THE CONNECTION

Go to your phone's Bluetooth® settings.

ADD OR SEARCH FOR DEVICES

When "Jawbone FARADAY" appears, select it.

IF ASKED FOR A PASSCODE

Enter "0000"

This is a one-time event per phone. To pair your Jawbone headset to another phone, repeat steps 2.1 to 2.3.

3 GET TALKING & MORE

3.1 ANSWER/END A CALL

Press the **TALK BUTTON** on your Jawbone to both answer and end a call.

DECLINE AN INCOMING CALL

Hold the **TALK BUTTON** for 2 seconds.

3.2 MAKE A CALL

Use your phone to dial as usual. Listen and talk through your Jawbone.

ACTIVATE VOICE DIALING

Hold the **TALK BUTTON** until you hear a beep, then release and follow the voice prompts.

REDIAL LAST NUMBER

Press the **TALK BUTTON** twice.

3.3 SIMULTANEOUS CALLS

To switch between calls, press the **TALK BUTTON**. To end one call and switch to the other, press the **TALK BUTTON** twice.

3.4 ADJUST THE VOLUME

Use the volume control on your phone. Or, while on a call or listening to music, **PRESS + HOLD** the **TALK BUTTON** and the volume level will cycle up and down. When you find the most comfortable volume level, release the button and your volume will be set.

3.5 MUSIC & MORE

STREAM AUDIO WITH A2DP

Use your FARADAY to listen to your music, podcasts, turn-by-turn directions and other audio on A2DP-enabled phones.

4 GET APPS & MORE

Jawbone [MYTALK™](#) lets you personalize and update your Jawbone FARADAY via the web.

Visit [MYTALK.JAWBONE.COM](#)

PERSONALIZE

AUDIO APPS

Change the voice that tells you information such as battery life and caller ID.

DIAL APPS

Customize your **TALK BUTTON** to speed dial your favorite number, or link directly to 411, voice-to-text, and other voice services.

INNOVATIONS

Try our newest software creations designed exclusively for your Jawbone FARADAY.

UPDATES

SOFTWARE

Make sure you are using the latest version of the Jawbone FARADAY software by logging on to

[MYTALK.JAWBONE.COM](#)

EXTRAS

Extras is a repository of helpful Apps that can enhance your FARADAY experience. We don't endorse or certify these services - but they might just change the way you use your FARADAY.

- Do not use the Jawbone® headset in a sauna or steam room.
- Do not keep your Jawbone® headset near a sink or other wet areas.

< IC RSS-GEN 7.1.5>

This device complies with RSS 210 of Industry Canada.

"Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device."

< FCC 15.19, 15.21 and RF Exposure >

FCC Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

FCC / IC Caution

-Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

-This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.