





HYPEREV

GearUP HYPEREV
Quick Start Guide


Configuring Ports and Setup

Thank you for choosing HYPEREV




1. Setup

Connect the provided power and network cables to the HYPEREV. A red light indicates that it is powered. Once the device detected an internet connection, the light will turn blue.



2. Connect to Wi-Fi

Use your mobile device's wireless connection settings to search for and connect to the HYPEREV Wi-Fi network. You will be able to locate the SSID and password on the back label.



3. GearUP Console Booster App


Find and download the GearUP Console Booster App on the App Store or Google Play Store. You can also scan the QR code below to download the app and complete the setup. With the app, you can boost your consoles and manage various configurations.




Scan the QR code above with your mobile phone and download the APP "GearUP Console Booster"

4. Connect to HYPEREV


Using either an ethernet or Wi-Fi connection, connect your console(s) to the HYPEREV device. You can then use the app to browse and select it. Once you log in, you can choose which games you want to improve their network performance by pressing the “Boost” button.




5. Start your game and play to win!



6. Supported consoles and titles



7. Status Light Indications



Red

Steady illuminate: Powered,
but no Internet connection



Green

Steady illuminate: Powered,
with Internet connection
Blinking: Entering boosting



Blue

Steady illuminate: Powered,
Internet connection and boosting console(s)

8. Membership and Legal Information

Thank you for your interest in HYPEREV, the hardware product from GearUp Portal Pte Ltd.

As you may know, HYPEREV requires a membership to unlock all of its features. Without a membership, you will only be able to access the router-related features and take advantage of the limited free game boosting services.

For more information about our membership, please visit booster.gearupglobal.com.

FCCID:2A98H-WH01

This device complies with Part 15 of the FCC rules. Operation is subjected to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

The device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems:

This device contains licence-exempt transmitter(s) /receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. The distance between user and products should be no less than 20cm.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.