



GPS MANUAL  
LEZYNE

MINI  
MACRO  
MICRO  
SUPER  
MICRO C

## Information

For more information on Lezyne products, visit: <http://lezyne.com>

### WEEE Notice & Product Disposal:

The symbol of the crossed waste container means that, in accordance with 2002/96/EC Waste Electrical and Electronic Equipment Directive (WEEE), once the product reaches the end of its lifecycle, in the European Union it is subject to special waste disposal. In addition to the present device, this rule is also applied to all items carrying such a symbol. Do not dispose of these products as undifferentiated urban waste but put away for material differentiated recycling.

CE RF Compliance—Meets the EU Requirements:

The equipment complies with the RF Exposure Requirement 1999/519/EC, Council Recommendation of 12 July 1999 on the limitation of exposure of the general public to electromagnetic fields (0–300 GHz). Changes or modifications to this product not authorized by the manufacturer could void the EMC compliance and negate your authority to operate the product. This product has demonstrated EMC compliance under conditions that included the use of compliant peripheral devices and shielded cables between system components. It is important that you use compliant peripheral devices and shielded cables between system components to reduce the possibility of causing interference to radios, televisions, and other electronic devices. We, hereby, declare that this cellular, Wi-Fi radio is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. Products with CE marking comply with the EMC Directive (2004/108/EC) and the Low Voltage Directive (2006/95/EC) issued by the Commission of the European Community. Compliance with these directives implies conformity to the following European Norms (in parentheses are the equivalent international standards). FCC & IC User Warning Notice:

Any changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

### Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### Labeling Requirement Notice:

Any Changes or modifications not expressly approved by the grantee of this device could void the users authority to operate the equipment

This device complies with Part 15 of the FCC Rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

#### Canada, Industry Canada (IC) Notices:

This device complies with Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Canada, avis d'Industry Canada (IC)

Cet appareil est conforme avec Industrie Canada exceptées de licence RSS standard(s). Son fonctionnement est soumis aux deux conditions suivantes: (1) cet appareil ne doit pas causer d'interférence et (2) cet appareil doit accepter toute interférence, notamment les interférences qui peuvent affecter son fonctionnement.

#### Radio Frequency (RF) Exposure Information

The radiated output power of the Wireless Device is below the Industry Canada (IC) radio frequency exposure limits.

The Wireless Device should be used in such a manner such that the potential for human contact during normal operation is minimized.

This device has also been evaluated and shown compliant with the IC RF Exposure limits under mobile exposure conditions. (antennas are greater than 20cm from a person's body).

#### Informations concernant l'exposition aux fréquences radio (RF)

La puissance de sortie émise par l'appareil de sans fil est inférieure à la limite d'exposition aux fréquences radio d'Industry Canada (IC).

Utilisez l'appareil de sans fil de façon à minimiser les contacts humains lors du fonctionnement normal. Ce périphérique a également été évalué et démontré conforme aux limites d'exposition aux RF d'IC dans des conditions d'exposition à des appareils mobiles (antennes sont supérieures à 20 cm à partir du corps d'une personne).

#### SIMPLIFIED EU DECLARATION OF CONFORMITY

The simplified EU declaration of conformity referred to in Article 10(9) shall be provided as follows: Hereby, Lezyne declares that the radio equipment of type, Information Technology Equipment, is in compliance with Directive 2014/53/EU.

#### FCC RF EXPOSURE MPE WARNING

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

Do not operate or store the GPS unit below -20° Celsius (-4° Fahrenheit) or above 60° Celsius (140° Fahrenheit). Storing the GPS unit in the direct sunlight or inside a parked vehicle can violate the temperature maximums. Battery life and battery health may be adversely affected at temperature extremes.

#### FCC ID / IC LABEL

The equipment E-label access : Go to device MENU > Info > FCC ID / IC

Lezyne is a trademark of Lezyne USA, Inc. and registered both in the United States and internationally Any unauthorized use is expressly prohibited

Bluetooth ® is a trademark of Bluetooth SIG, Inc,

ANT+™ is a trademark of Dynastream Innovations, Inc.

The term Strava, the Strava logos and product and service names are the exclusive trademarks of, and are owned by, Strava Inc

Shimano ™ is a trademark of Shimano Inc

Training Peaks™ is a trademark of Training Peaks, LLC

Today's Plan is owned and operated by Today's Plan Pty Ltd, ACN 169 177 431

## Warranty

Lezyne GPS devices carry a one (1) year warranty from the original purchase date to the original owner (proof of purchase is required.) This warranty covers materials and manufacturing defects on the GPS housing, electronics, and the mounting bracket supplied. Issues not covered by the warranty include normal wear and tear, consumable parts, such as batteries, unless product damage has occurred due to defect in material or manufacturing, improper installation, attempting to access electronics, modifying electronics, damage or failure due to accident, misuse, abuse, or neglect.

Because of possible user resealing error of the USB port, this product is not warranted against water in the housing from improper sealing or any resulting damage. Please review and follow the instructions carefully when sealing the housing.

This product is intended to be used only as a cycling aid and must not be used for any purpose requiring precise measurement of direction, distance, location or topography. Lezyne makes no warranty as to the accuracy or completeness of map data in this product.

In no event shall Lezyne be liable for incidental or consequential damages for any traffic fines or citations, relating to or resulting from the use of this product or any of its parts. Lezyne assumes no liability for any accident, injury, death, loss, or other claim related to or resulting from the use of this product.

## Important

Do not become distracted by the device—always operate vehicles in a safe manner.

Lezyne USA, Inc. does not accept any liability for injuries or other damages resulting from the use of this product in any circumstances.

## DO NOT SUBMERGE UNDER WATER

Lezyne GPS devices are water resistant under normal conditions, but are not waterproof. If moisture gets inside device body, air-out until completely dry.

## DO NOT ATTEMPT TO REMOVE ELECTRONICS

Doing so will void warranty.

Do not operate or store outside of temperature range (-20–60° C). Battery life may be affected at temperature extremes.

Location and surroundings may affect GPS signal. For best results, use the device outdoors with an unobstructed view of the sky. It may take up to 60 seconds to acquire GPS signals.

This GPS device is not a calibrated measuring tool. It should not be used for surveying purposes. GPS based elevation measurements may vary.

Calorie readings are an estimation for reference only.

### CA PROPOSITION 65 WARNING:

This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm (California law requires this warning to be given to customers in the State of California).

For more info: [www.lezyne.com/prop65](http://www.lezyne.com/prop65)

# Table of Contents

• <a href="#">Getting Started</a>	page.5	• <a href="#">Bike Set up</a>	page.40
– Buttons		– Wheel Circumference	
– Screen Icons		– Bike Weight	
– Charging GPS			
– Installing GPS		• <a href="#">Personal Set up</a>	page.41
– Turning on GPS		– Sport Type	
– GPS Satellite Signal		– Language*	
– Starting a Ride		– Age*	
– Ending a Ride		– Weight*	
– Uploading a Ride to your Computer		– Height*	
		– Gender*	
• <a href="#">Screen Set up</a>	page. 12	• <a href="#">Auto/Preset Notification Set up</a>	page.44
– Layout		– Scroll	
– Fields		– Pause	
– Unit Format		– Lap	
– Brightness (Backlight)		– Light (Backlight)	
• <a href="#">Time Set up</a>	page.16	• <a href="#">Alert Set up</a>	page.47
– Time Format		– Ride Distance	
– Time Zone*		– Ride Time	
– Daylight Saving*		– Calories	
• <a href="#">Phone Pairing - Ally App</a>	page.18	• <a href="#">Records</a>	page.50
– Pairing to the Phone		– Erase All	
– Setup Support		– Erase Oldest	
– GPS Settings		– Memory	
– General Setup		– Reset Trip 1	
– Bike and Screen Setup		– Reset Trip 2	
– Notification Set up		– Reset Odo (Odometer)	
• <a href="#">Navigation</a>	page.25	• <a href="#">Info</a>	page.53
– Navigation Setup		– Device	
– GPS Root		– Firmware	
– Mapping		– GPS	
• <a href="#">Tracking/Training</a>	page.30	– Sats	
– Strava and Strava Live Segments		• <a href="#">Specifications</a>	page.57
– Training Peaks™		• <a href="#">Data Metrics Explained</a>	page.58
– Lezyne Track		• <a href="#">Troubleshooting</a>	page.59
– Training Program Set up		– Updating Software	
• <a href="#">Sensor Pairing</a>	page.38	– Support	
– Heart Rate Monitor Set up		– Resetting the Device	
– Speed Monitor Set up			
– Cadence Monitor Set up			
– Power Meter Set up			
– Shifting Set up			










GPS  
LEZYNE

MINI  
MACRO  
MICRO  
SUPER  
MICRO C

# Getting Started

## Buttons


 	Press for Back button function Hold for 2 seconds to turn ON/OFF the device Press to Scroll left through pages
<b>ENTER</b> 	Press to ENTER a selection in the menu screen Press to turn Backlight ON/OFF
<b>MENU</b>  	Hold to access the MENU screen Press to move UP in the menu screen Press to Scroll right through pages
<b>LAP</b>  	Press to start a ride Hold to end a ride Press to move DOWN in the menu screen During a ride, Press to mark a LAP

## Ride Screen Button Functions








# Getting Started

## Menu and Pause Screen Button Functions



## Screen Icons



 ON	Lezyne Track
	Power Sensor
	Heart Rate Sensor
	Cadence Sensor
	Speed Sensor
Di2	Shifting Sensor

# Getting Started

---


## Charging

---

Before using your Lezyne GPS device for the first time, fully charge battery and it is also recommended to visit [lezyne.com/gpsroot](http://lezyne.com/gpsroot) and update your GPS device to the latest software.

1. Remove exterior moisture.
2. Open USB cover.
3. Connect micro USB cable and device to powered USB port.  
For best results, use the supplied Lezyne cable.

If device does not display charging symbol when plugged in, selected USB port may not be powered – try another USB port.



## Mounting


---

To attach the X-Lock mount:

1. Align the shim with the bottom of the mount.
2. Attach the X-Lock mount securely using the two bands that best fit your mounting location.

To connect the device to the X-Lock mount:

1. Align the tabs on the back of the device with the mount.
2. Press down and turn the device until it locks into place.





# Getting Started

---

## Turning on the GPS

---

Turn on your GPS by holding the left  button.

Press and hold  for 2 seconds to turn on



## GPS Satellite Signal

---

Before a ride can start there must be status of a GPS signal present. This can take 30 to 90 seconds. For best results:

1. Go outside to open clear area.
2. Place the GPS device so it's not obstructed to the sky.
3. Wait for a GPS status dot to fill in.

\*a pop up notice will appear if you try to start a ride before a GPS signal is present.

GPS Signal





# Getting Started

---

## Starting a Ride

---

1. Wait for a GPS signal.
2. Start recording by pressing the bottom right ► button.
3. Ride data is recorded when the timer is running. A recording indicator will blink in the upper right corner.
4. Press the top right button ◻ or top left button ◀ to scroll through pages showing ride metrics.



Press to start recording a ride

## Ending a Ride

---

Enter the pause menu by holding the bottom right ► button. To continue recording, select the option **RESUME** or choose to **SAVE** or **DISCARD** your ride.



Press and hold to end ride



# Getting Started

---

## Uploading a Ride to a computer

---

1. Remove the USB port seal.
2. Connect your GPS to a computer via Micro USB cable.
3. The GPS will read like a USB drive with included folders.
4. Within the Lezyne GPS folder find your .Fit ride files in the Activities folder to upload and share at [www.lezyne.com/gpsroot](http://www.lezyne.com/gpsroot)



## USB Seal

---

Its important to re-install the USB seal between the two seal locks to maintain a good seal against the weather.

USB SEAL



## GPS Device updates

---


Software updates for your GPS device can be found at <http://www.lezyne.com/support-downloads.php>

# Menu Options

---

## Menu Screen

---

Hold the top right button  to enter the **MENU** screen  
Menu options include:

- Alert
- Auto
- Bike
- Personal
- Records
- Personal
- Records
- Records
- Records
- Personal
- Records
- Records
- Records
- Screen
- Time
- Info
- Strava\*

\*only appears if segments have been saved on the device



## Screen Setup

---

The GPS device can be set up manually on the device or through the **Ally Phone APP**.

See the Phone Pairing instructions to sync your phone first and then you can proceed to set up the device with the [Ally App](#)

## Screen Display

---

Up to 5 Data pages can be created and customized to show different data fields.

Access the **Screen** menu

1. When in the **Menu** screen scroll to **Screen** and press the left **ENTER** button,



## Data Pages

---

### Data Pages

1. Press the **ENTER** button and you can set up how many pages you want to see



## Page Setup

---

There are ten display options for each page:

- 2 Lines of Data and up to 8 Lines of Data

To change the Layout,

1. Scroll up or down to the page number you want to change and press the left **ENTER** button.
2. In the **No. of fields** press enter and use the right buttons to scroll up and down until it lists the desired lines of data to display.
3. Press **ENTER** to select.



## Data Selection Display

---

In **Fields** you can choose what data metrics to display on each data line.  
Move **Up** or **Down** to the line you want to change and Press **ENTER**.  
Scroll **Up** or **Down** to make the change and Press **ENTER**.



### Adjustable Data

Distance  
Speed  
Avg Speed  
Max Speed  
Trip 1  
Trip 2  
Odometer  
Time  
Clock  
Elevation  
Grade  
Ascent  
Descent  
Temperature

Calories  
\*Heart Rate  
\*Avg Heart Rate  
\*Max Heart Rate  
\*Cadence  
\*Avg Cadence  
\*Power  
\*Avg Power  
\*3s Power  
\*10s Power  
\*Average Power  
\*Power Balance  
\*Left/Right Smoothness  
\*Left/Right Torque Efficiency

Lap Distance  
Lap Speed  
\*Lap Power  
\*Lap Heart Rate  
\*Lap Cadence  
Lap Time  
\*\*Di2 Shifting  
\*Shifting  
Bike Selection  
GPS

[Data Definitions Found Here](#)

## Units Format Display

---

In **Units** you can choose between Miles or Kilometers format.

And Temperature in °F or °C

Press **ENTER** and toggle up or down, press **ENTER** to select the setting.



## Background Display

---

In **Background** you can choose to have it set to **WHITE** or **BLACK**. Press **ENTER** and use the right buttons to make the selection. When done press the **BACK** button.



## Backlight Display

---

In **Backlight** you can choose what percentage of light that is displayed from the backlight. Press **ENTER** and use the right buttons to **INCREASE** or **DECREASE**. Use the **ENTER** button to make the adjustments. When done press the **BACK** button.



## Contrast Display

---

In **Contrast** you can choose the percentage of contrast that is displayed from the screen. Press **ENTER** and use the right buttons to **INCREASE** or **DECREASE**. Use the **ENTER** button to make the adjustments. When done press the **BACK** button.



### Notification Font Size

---

In **Notification** you can choose Large font or Small font size for displayed notifications. Press **ENTER** and use the right buttons to select size. Use the **ENTER** button to make the selection.



## Time Set up

---

### Time Format

---

**Time Format** adjusts time display from **12hr** to **24hr** format. Press **ENTER** and use the right buttons to select **12 hr** or **24 hr**. Press **ENTER** to make the selection.





## Time Zone

---

**Time Zone** adjusts time based on your closest location. Press **ENTER** and use the right buttons to select. Press **ENTER** to make the selection.



## Daylight Savings





---

**Daylight Savings** adjusts time accordingly if it applies to your location. Press **ENTER** and use the right buttons to select. Press **ENTER** to make the selection.



## Pairing to the Phone

1. Download the free **Lezyne GPS Ally App v2** to your phone.
  - Google Play for Android or App Store for iPhone.
2. Open the App to the **Device** tab and tap **Scan for Device**.
3. On your Lezyne GPS device, go into the **Menu** to **Phone** and press **ENTER**.
4. In **Phone**, select either **iPhone** or **Android** using the arrow buttons and press **ENTER**, this will make the device visible to the phone.
5. The **GPS Ally** App will show the Lezyne device you are looking to pair. Select the device and a pop up should ask if you want to **Pair**. Select **Pair**.
  - You will be prompted a code from the device to enter in the App.



## Phone Pairing Reset

---


If issues occur pairing a phone or if it's pairing to a phone you don't want it to anymore then you reset the phone pairing. This will clear the stored phone info.

1. In **Phone**, select **Reset** using the arrow buttons and press **Enter** to make the selection.




## Setup Support

Anytime you need more assistance in setup, Tap on the **More** option and go to **Support** for linked video tutorials.




Tap here to begin



## GPS Settings (Device Setup)

Once the Ally App is installed on your phone and the phone is paired to the GPS device you can proceed to use the App to setup the GPS device. Tap on the **More** option and go to **GPS Settings**.



Tap here to begin

## General Setup

---

In General Setup you can adjust settings for Alert, Auto, Personal, Navigation, Screen, Time and Strava.



### General setup


Edit GPS settings that are not specific to bike and screen layout



### Bike and Screen setup

Configure the details of your bikes and how you want the data fields displayed.

← Tap here to begin



Alert



Auto



Personal



Navigation



Screen





Time







Strava

## Bike and Screen Setup

In Bike and Screen Setup you can create up to 5 Bike profiles. And then customize the screen set up for each bike profile. Set the bike profile by Name, Sport Type, Wheel Circumference, Bike Weight, and the Odometer.



← Tap here to begin




Select the number of fields on this screen, then tap on the field above to set which data fields are displayed

## Screen Setup

In Screen Setup you can create up to 5 pages and have them customized with 2 to 8 fields of data.

1. Simply tap on the number field to change data fields
2. Tap to select the data field to be changed
3. Make the selection of which metric you want to see
4. Hit OK.





## Notifications Set up

When the Lezyne GPS devices are paired with the **Lezyne GPS Ally App v2** they can display **Text, Email, Call Notifications and many more**. See your phone settings for more on messages.

\* To enable this feature you must first make sure your phone notifications are turned on for Text and Email. See your phone instructions for details.

1. In **Lezyne GPS Ally App v2**, go to the **Settings** tab and turn on **Notifications**.





## Navigation Set up

When the Lezyne GPS devices are paired with the **Lezyne GPS Ally App v2** they work together to display **Turn by Turn directions**.




In the **Lezyne GPS Ally App v2**, on the **Navigation** tab, you can search by:

- Viewing the map and tapping a location where you want to go.
- Typing in an address in the search box.
- Typing the name of the location in the search box.

Once the location is determined, multiple route options are available.

- Choose your desired course and tap **GO**.

The directions will be pushed to the device along with a route map.



Route Options


Distance for Selected Route

Elevation for Selected Route

Displayed Turn Directions



Displayed Route Map





## Navigation Custom Routes

Custom routes can also be created with the **Ally V2 App** when your phone is paired with your GPS device.



In the **Lezyne GPS Ally App v2**, on the **Navigation** tab, you can search by:

- Viewing the map and tapping a location where you want to start.
  - Begin tapping along points where you want the route to go.
- \*TIP: for a quick set up, just tap on general location and the routing will fill in a recommended course
- Once your route is complete, hit **Save**, and it will be available in your **Saved Routes**.

Tap here for Route Options



Select Create Routes to start



## Navigation Set up

---

The Lezyne GPS devices are capable of communicating your location to the Lezyne GPS Ally App v2 to assist in navigation. If you were to get off course an automatic **Rerouting** would take place within the Lezyne GPS Ally App v2 that would send new directions to your GPS device.

If you don't want **Rerouting** to happen during your directions and to keep the same route, the **Rerouting** feature can be turned off. If you have sent directions to the device but want to cancel them, you can select **Cancel** in the same menu location.

Press **ENTER** on **Navigation**.

You can choose to turn Navigation **Rerouting On** or **Off**


1. Press **Enter** to Select.
2. Arrow **Up** or **Down** with right side buttons to select **On** or **Off**.

When Turn by Turn Navigation has been sent to the device, you have the option to **Cancel** the route without accessing your phone.

Press **ENTER** on **Navigation**

1. Arrow **Up** or **Down** with the right side buttons to **Cancel**.
2. Press **ENTER** to select and the Navigation Route will be canceled.

**Popup Mode** will allow **Navigation** notifications to **Popup** on data screens when the next turn point is approaching.






## Navigation GPS Root

In the [Lezyne GPS Root](#) website, on the **Routes** tab, you can create Routes. Routes can be based on Cycling, Hiking/Walking, or Driving specifics.

**Saved Route** can be accessed from the **Lezyne Ally** and pushed to GPS devices for **Turn by Turn** directions.


- **Location Searches** can be done by the address, name, or clicking on map locations
1. Once a location is created, start to finish points set, hit calculate and choose your Route Option.
  2. Save the Route by naming it.
- **Multiple Destination Routes** can be created by:
    1. Clicking the map to create points.
      - Create Start, End, and Waypoints to create a desired route
      - Waypoints can be rearrange in a specific order.
    2. Calculate the Route.



## Breadcrumb Mapping

---

Once set to record, the Lezyne GPS will record a **Breadcrumb Map** displaying where you have been.

1. Press the lower right record button  and the breadcrumb map will begin to display.



## Route Mapping

---

When **Navigation** is being used, a **Route Map** will show the start, finish, and real time location on that route.



## Strava Sync Set up - App

In the **Lezyne GPS Root** website or in the **Lezyne GPS Ally App v2**, you can sync your activities to [Strava](#), the popular social network.




Activities can be set to sync automatically when uploaded or one at a time

While in the Ally App set your account to sync with Strava simply by logging in through the **Settings** tab in the Ally App and GPS Root website.


### Lezyne GPS Ally App v2 Sync

1. Go into the **App Settings** in the **More** tab.
2. Tap on **Connect with Strava**.
3. You'll have to have a Strava account in order to sync with the Ally App.
4. Log into your Strava account to confirm.
5. Once the connection is made you can now set the Ally App to auto sync your activities as they are uploaded or you can sync them one at a time.

Tap to Enter Settings



Tap to Share on Strava




## Strava Sync Set up - Website


Strava sync setup can be done on either the Lezyne Ally V2 App or Lezyne GPS Root website.

### Lezyne GPS Root Sync -


1. Click on **Settings** to Sync with Strava.
2. Click on **Connect with Strava** button.
3. You'll be asked to log into to Strava.
4. A page will appear to confirm the connection. Click on **Authorize** to confirm.
5. You can set rides to auto sync as you upload them or upload one at time when viewing the ride.



### Authorize Lezyne GPSROOT to connect to Strava



Once logged into Strava you'll be asked to confirm the connection



## Strava Segments Set up *\*STRAVA Premium Membership Needed\**

In the **Lezyne GPS Root** website or in the **Lezyne GPS Ally App v2**, you can sync **Strava Segments** from the popular social network. [strava.com/premium](http://strava.com/premium)


While in the GPS Root or Ally App set your account to sync with Strava simply by logging in through the **Settings** tab in the Ally App and GPS Root website.

If you are a Strava Premium member, you can Sync Strava Live Segments to your device to get a real time estimate of how you compare to either your PR or the segment's KOM time





*\*All Strava Segments are managed on the Strava Site and only synced to Lezyne GPS Root and Ally App.*



1. Star the **Segments** on the **Strava Website** or within the **Strava App**.
2. Open the **Lezyne GPS Ally App v2**.
3. Make sure you are paired to a **Lezyne GPS Device**.
4. Tap the **More** Tab, and tap **Strava Segments**.
5. **Swipe Down** to refresh data
6. Tap **Sync** and the **Segments** will be pushed to your Lezyne GPS device.



Tap to Sync Segments to GPS



Manage Segment List in your Strava Account Refresh to make sure all Segments are up to date



## Training Peaks™ Set up

**Training Peaks** is a way to track your ride data and much more.




- Speed
- Distance
- And any sensor information that you are connected to

\*An Account with Training Peaks will need to be set up before you can sync.

### Lezyne GPS Root/Ally App Sync

1. Click on **Settings** to Sync with Training Peaks.
2. Click on **Connect with Training Peaks** button.
3. You'll be asked to log into Training Peaks.
4. And then a page will appear to confirm the connection. Click on **Authorize** to confirm.
5. You can set rides to auto sync as you upload them or upload one at time when viewing the ride.

Tap to Enter Feature



## Lezyne Track Set up

**Lezyne Track** is a way to share your ride information in real-time with friends, family, or whomever you decide to include. They will be sent an email with a hyperlink that will send them to a map showing your:

- Location
- Speed
- Distance
- And any sensor information that you are connected to

All you need is their email address to create a contact list and when you hit record on the Lezyne GPS device a message will be sent letting them know you're out on a ride.

1. Download the **Lezyne GPS Ally App v2**.
2. Tap the **More** Tab in the **Ally App** to find **Lezyne Track**.
3. Turn on **Lezyne Track**.
4. Type in or search through your contacts to add people to your email contact list
5. Once you hit record on your **Lezyne GPS** a notice will be sent to the people in your selected contact list.

Tap to Enter Feature

Tap to Turn On and Enable

Create Email Contact List

LEZYNE TRACK			
RIDE DATA			
Time	00:28:13	Elevation	145.6
Elapsed Time	00:28:13	Avg Elevation	822.6
Timer Time	00:28:13	Max Elevation	2.1
Distance	28.84 mi	Avg Temperature	73.7 F
Speed	15.06 mph	Max Temperature	77.2 F
Avg Speed	14.78 mph	Data Points	1000 rows

TRACKING MAP			
Map	Google	Map	Google

GRAPH			
Time	00:28:13	Elevation	145.6
Elapsed Time	00:28:13	Avg Elevation	822.6
Timer Time	00:28:13	Max Elevation	2.1
Distance	28.84 mi	Avg Temperature	73.7 F
Speed	15.06 mph	Max Temperature	77.2 F
Avg Speed	14.78 mph	Data Points	1000 rows

## Training Program Set up

Lezyne GPS computers can sync with [Training Peaks™](#) and [Today's Plan](#) to import workouts into the device. See websites for account details and creating work outs.

1. Open the **Lezyne GPS Ally** App
2. Tap the **More** Tab in the **Ally** App to find **Training Programs**.
3. Tap on either **Training Peaks** or **Today's Plan** in order to login and sync
4. Once logged in and back in the Ally App, swipe down to refresh the page. If a workout is scheduled for the current day it will appear at the bottom. Tap to sync to device
5. **Setup Zone** gives you the option to setup a workout with either Heart Rate or Power zones
6. These zones can be setup manually or sync with **Training Peaks** or **Todays Plan**

Tap to Enter Feature

Tap to Either Site to Sync

Tap to sync with programs

Type in manually to create zones

Today's Workout

Heart Rate (bpm)	Percentage (%)	Zone
185	100	Zone 5
167	90	Zone 5
148	80	Zone 4
139	75	Zone 3
111	60	Zone 2
93	50	Zone 1

## Training Program Set up

---

1. Once the scheduled workout is sync to a GPS device, a command prompt will appear on the device screen.
2. **Training Start Now?** Will appear on the screen. Select **Yes** to begin or **No** to begin workout later during your ride
3. If **No** was selected, to start the workout mid-ride, Hold the **LAP ►** button for 2 seconds to begin



Press and Hold for 2 Seconds  
to Begin Workout Mid-Ride



## Training Program Set up

Recorded rides and rides with workouts can sync with the training programs if the Auto Sync features are turned on.

### GPS Root/Ally App Sync

1. Click on **Settings** to Sync with a selected program.
2. If you click on a program that is not setup, a login screen will appear for that site.
3. Once logged in you'll need to **Authorize** to complete the setup.
4. Now when a ride is uploaded to the GPS Root/Ally App it will automatically sync with the selected programs

Tap to Enter Feature



Tap to Turn On Auto Sync

# Sensor Pairing


## Sensor Set up

The Lezyne Mini and Macro GPS can pair with only Bluetooth Heart Rate Monitors.  
The Micro, Micro C, and Super GPS can pair to both Bluetooth® and ANT+™

\* Before you pair your Sensors, see the manufactures' instructions on how to pair with devices.

1. In **Sensors**, press **ENTER** to access. Choose the sensor type you want to pair and press **ENTER**.

- Heart Rate
- Speed
- Cadence
- Speed & Cadence
- Power
- Shifting



2. Depending on your device type select either Bluetooth® or ANT+™

3. Select the sensor you are trying to pair

\* This could take a couple minutes\*

Once paired the GPS device will read **Paired**, and the icon will show on the Home screen



## Power Meter Set up

\* Before you pair your Power meter, see the manufactures instructions on how to set up, pair, and calibrate the meter with devices.

1. In **Power**, press **ENTER** to **Pair**. The device will search for Power sensors in range.

\*This could take a couple minutes\*

2. Select the sensor you are trying to pair.

\*(See name or ID numbers that match your device)

When complete, the GPS device will read **Paired**.

3. Once paired you can:

- Calibrate\*
- Auto Zero \*(ANT+ versions only)
- Set Crank Arm length

\*See manufactures instructions on how to **Calibrate** and **Auto Zero**



## Wheel Circ (Circumference) Set up

**Wheel Circumference** calibrates the speed sensor to accurately display your speed based on the size of your wheel. This is needed if using a speed sensor.

\*Paired Speed Sensors will take over recording speed and distance and no longer use information from the GPS.

Press **ENTER** and use the right buttons to **INCREASE** or **DECREASE**. Use the **ENTER** button to make the adjustments. When done select **BACK** or press the **ENTER** button.



### Wheel Size and Circumference

The wheel size can be found on the side of the tire. This is not an exact list but a general guide. More specific wheel calculators can be found online. Or you can manually measure

[http://www.bikecalc.com/wheel\\_size\\_math](http://www.bikecalc.com/wheel_size_math)

Wheel	Tire	CM		Wheel	Tire	CM		Wheel	Tire	CM
700c/29er	20 mm	208.0		650b/27.5	2.125 inch	217.4		26inch mtb	2.10 inch	209.1
700c/29er	23 mm	209.9		650b/27.5	2.20 inch	218.6		26inch mtb	2.125 inch	209.5
700c/29er	25 mm	211.1		650b/27.5	2.25 inch	219.4		26inch mtb	2.20 inch	210.7
700c/29er	28 mm	213.0		650b/27.5	2.30 inch	220.2		26inch mtb	2.25 inch	211.5
650b/27.5	20 mm	196.0		650b/27.5	2.35 inch	221.0		26inch mtb	2.30 inch	212.3
650b/27.5	23 mm	197.9		650b/27.5	2.40 inch	221.6		26inch mtb	2.35 inch	213.1
650b/27.5	25 mm	199.2		650c	20 mm	192.0		26inch mtb	2.40 inch	213.7
650b/27.5	28 mm	201.1		650c	23 mm	193.8		20inch Recumbent	20 mm	154.3
650b/27.5	32 mm	203.6		650c	25 mm	195.1		20inch Recumbent	23 mm	156.1
650b/27.5	35 mm	205.5		650c	28 mm	197.0		20inch Recumbent	25 mm	157.4
650b/27.5	38 mm	207.3		26inch mtb	35 mm	197.6		20inch Recumbent	28 mm	159.3
650b/27.5	44 mm	211.1		26inch mtb	38 mm	199.5		20inch Recumbent	32 mm	161.8
650b/27.5	50 mm	214.9		26inch mtb	44 mm	203.3		20inch Recumbent	35 mm	163.7
650b/27.5	56 mm	218.7		26inch mtb	50 mm	207.0		20inch Recumbent	1.00 inch	157.6
650b/27.5	1.00 inch	199.4		26inch mtb	56 mm	210.8		20inch Recumbent	1.25 inch	161.6
650b/27.5	1.25 inch	203.4		26inch mtb	1.00 inch	191.6		20inch Recumbent	1.5 inch	165.6
650b/27.5	1.5 inch	207.4		26inch mtb	1.25 inch	195.6		20inch Recumbent	1.75 inch	169.6
650b/27.5	1.75 inch	211.4		26inch mtb	1.5 inch	199.6		20inch Recumbent	1.90 inch	172.0
650b/27.5	1.90 inch	213.8		26inch mtb	1.75 inch	203.5		20inch Recumbent	1.95 inch	172.8
650b/27.5	1.95 inch	214.6		26inch mtb	1.90 inch	205.9		20inch Recumbent	2.00 inch	173.6
650b/27.5	2.00 inch	215.4		26inch mtb	1.95 inch	206.7				
650b/27.5	2.10 inch	217.0		26inch mtb	2.00 inch	207.5				



## Sport Type

---

Sport Type gives you the option to choose what best suits your type of activity and how it should be categorized for downloads.

Press **ENTER** and use the right buttons to select. Press **ENTER** to make the selection.



## Language Setting

---

Sets your desired language.

Press **ENTER** and use the right buttons to select. Press **ENTER** to make the selection.



## Age Setting

---

Setting your age assists in calorie calculations.

Press **ENTER** and use the right buttons to select **INCREASE** or **DECREASE**. Use the **ENTER** button to make the adjustments. When done select **BACK** or press the **BACK** button



## Weight Setting

---

Setting your weight assists in calorie calculations.

Press **ENTER** and use the right buttons to **INCREASE** or **DECREASE**. Use the **ENTER** button to make the adjustments. When done press **ENTER** or press the **BACK** button.



## Height Setting

---

Setting your Height assists in calorie calculations.

Press **ENTER** and use the right buttons to **INCREASE** or **DECREASE**. Use the **ENTER** button to make the selection.



## Gender Setting

---

Setting your gender assists in calorie calculations. Set your gender to **Male** or **Female**.

Press **ENTER** and use the right buttons to select. Press **ENTER** to make the selection.



## Scroll Setting

---

Automatic **Scroll** through the pages on the device while recording.  
Press **ENTER** and use the right buttons to select **On** or **Off**. Press **ENTER** to make the selection.



## Sync Mode Setting

---

This will automatically **Sync** the ride data to the phone when you stop the ride. Which can then be sent to GPS Root or other 3<sup>rd</sup> party sites set up.  
Press **ENTER** and use the right buttons to select **On** or **Off**. Press **ENTER** to make the selection.



## Start/Stop (Pause) Setting

---

The **Pause** setting is an automatic Start/Stop feature that controls recording of the ride if you stop for a period of time and will start back up once you begin to move. Press **ENTER** and use the right buttons to select **On** or **Off**. Press **ENTER** to make the selection.



# Auto/Preset Notification Set up

---

## Lap Preset Notification Set up

---

Lap preset allows you to set a notification pop up based on **Time** or **Distance** goals and stores the data in your .fit file.

Press **ENTER** and use the right buttons to select **Time** or **Distance**. Press **ENTER** to make the selection and use the right buttons to **INCREASE** or **DECREASE**. When done press the **ENTER** button. To reset, select **Off** and repeat the steps for set up.



## Light Setting

---

The **Light** setting set **ON** automatically turns the backlight on when any button is pressed. And will automatically shut off after 10 seconds. Set to **OFF** you'll need to use the light button

Press **ENTER** and use the right buttons to select **On** or **Off**. Press **ENTER** to make the selection.



## Ride Distance Alert Set up

---

**Ride Distance** alert gives you a pop up alert when you complete a set distance goal. Press **ENTER** and use the right buttons to **INCREASE** or **DECREASE**. When done press the **ENTER** button. To reset, select **Off** and repeat the steps for set up.



## Ride Time Alert Set up

---

**Ride Time** alert gives you a pop up alert when you complete a set goal for an amount of time. Press **ENTER** and use the right buttons to **INCREASE** or **DECREASE**. When done press the **ENTER** button. To reset, select **Off** and repeat the steps for set up.



## Calories Alert Set up

---

**Calories** alert gives you a pop up alert when you complete a set goal. Press **ENTER** and use the right buttons to **INCREASE** or **DECREASE**. When done press the **ENTER** button. To reset, select **Off** and repeat the steps for set up.



## Minimum HR (Heart Rate) Alert Set up

---

**Minimum Heart Rate** alert gives you a pop up alert when you hit a set minimum limit. Press **ENTER** and use the right buttons to **INCREASE** or **DECREASE**. When done press the **ENTER** button.





## Maximum HR (Heart Rate) Alert Set up

---

**Maximum Heart Rate** alert gives you a pop up alert when you hit a set maximum limit. Press **ENTER** and use the right buttons to **INCREASE** or **DECREASE**. When done press the **ENTER** button. To reset, select **Off** and repeat the steps for set up.



## Speaker Set up \*(Super GPS only)

---

The **Speaker** setting turns it on when ever a button is pressed. Press **ENTER** and use the right buttons to select **On** or **Off**. Press **ENTER** to make the selection.



# Records

---

## Review

---

**Review** lets you see the details of stored rides on the device.

Press **ENTER** and use the right buttons to select the ride you want to see by date and time. Press **ENTER** to make the selection.



## Erase All

---

**Erase All** will delete all rides recorded and stored on the device.

Press **ENTER** and use the right buttons to select **Yes** or **No**. Press **ENTER** to make the selection.



# Records

---

## Erase Oldest

---

**Erase Oldest** will delete the oldest ride recorded and stored on the device. This is for when you need more room for recording and know the oldest file is not important but want to keep other rides.

Press **ENTER** and use the right buttons to select **Yes** or **No**. Press **ENTER** to make the selection.



## Memory

---

This lets you know how many hours of recording time you have remaining.



# Records

---

## Reset Trip 1

---

This allows you to delete the recorded distance in **Trip 1**. Press **ENTER** and use the right buttons to select **Yes** or **No**. Press **ENTER** to make the selection.



## Reset Trip 2

---

This allows you to delete the recorded distance in **Trip 2**. Press **ENTER** and use the right buttons to select **Yes** or **No**. Press **ENTER** to make the selection.



## Reset Odo (Odometer)

---



This allows you to delete the accumulated miles on the **Odometer**.

Press **ENTER** and use the right buttons to select **Yes** or **No**. Press **ENTER** to make the selection.

## Info

---

### Device

---



This indicates the device type.

### Firmware

---



The numbers in Firmware indicates which version is currently being used on the device.

## GPS (Adaptive / 1 Second)

---



This is where you can select the GPS chip to run GPS at 1 second intervals or run Adaptive. Adaptive bases signal request based on the GPS movement and can increase the runtime of the device.



## GPS (Reset)

---



When the GPS is first set up, it stores satellite location information for quicker start ups. If you travel long distances, to different states or to other countries, and experience slow start ups, a reset will clear out all stored location data and start it fresh.

## Sats (Satellites)

---



This is the current number of satellites the device is using.

## HDOP, VDOP

---

This is the quality of the GPS data.  
Horizontal Dilution of Precession.  
Vertical Dilution of Precession.



## Battery

---

The current battery voltage.



## **FCC ID**

---

FCC certification number for the device

## **IC**

---

Industry Canada certification number

## **RCM**

---

The three existing compliance marks (C-Tick, A-Tick and RCM) are being consolidated into a single compliance mark—the RCM

## **Bluetooth LE**

---

Software version of Bluetooth LE

## **ANT+™**

---

Software version of ANT+™



## **Specifications – Mini GPS, Micro GPS, Micro C GPS**

---

Battery Type	Rechargeable Lithium polymer, 280 mAh
Battery Life	Up to 14hrs
Memory Size	Up to 100hrs (Mini GPS) 150hrs (Micro GPS)
Operating Temperature Range	-20°C to 60°C (-4°F to 140°F)
Charging Temperature Range	0°C to 45°C (32°F to 113°F)
Water Rating	IPX7 *tested in water 1m for 30min
Weight	76g

## **Specifications - Macro GPS, Super GPS**

---

Battery Type	Rechargeable Lithium polymer, 850 mAh
Battery Life	Up to 32hrs
Memory Size	Up to 100hrs (Macro GPS) Up to 400hrs (Super GPS)
Operating Temperature Range	-20°C to 60°C (-4°F to 140°F)
Charging Temperature Range	0°C to 45°C (32°F to 113°F)
Water Rating	IPX7 *tested in water 1m for 30min
Weight	76g

## Data Metrics Explained

---

**Ascent:** The total measurement of elevation gained that current ride

**Auto Scroll:** Page scroll changes to show different information.  
Example: Avg Speed, Elevation, Temperature

**Auto Start/Stop:** This will automatically pause the timer when you stop, and start when you begin to move. This is used to not record time during stops or rest periods

**Avg Speed:** The average speed of the current ride

**\*Cadence - Avg Cad:** The average revolutions of the crank arm per minute

**\*Cadence:** The revolution of the crank arms per minute

**Calories Alert:** A pop up notification when you hit a set calorie goal

**Calories:** The amount of calories burned that current ride.

This information is calculated based on your personal settings

**Clock:** The current time of day

**Descent:** The total measurement of elevation lost that current ride

**Distance:** The distance of the current ride

**Elevation:** The current measurement of height above sea level based on your location

**\*Heart Rate - Avg HR:** The average heart rate during that current ride

**\*Heart Rate - Max HR:** The max heart rate during that current ride

**\*Heart Rate:** Your heart rate in beats per minute (bpm)

**Lap Preset:** An automatic notification to mark a lap based on a preset you set for distance or time.

**Odometer:** Accumulative recording of distance between rides

**\*Power - 10s Power:** A 10 second average output of watts

**\*Power - 3s Power:** A 3 second average output of watts

**\*Power - L/R % Smoothness:** The measure of how evenly power is being applied to the left and right through the pedal stroke

**\*Power - L/R % Tq Efficiency:** The measure of efficiency in pedaling from left to right

**\*Power Balance:** The balance of power between left/right

**\*Power:** The output of watts

**Ride Distance Alert:** A pop up notification when you hit a set distance goal

**Ride Time Alert:** A pop up notification when you hit a set time goal

**Speed - Avg Speed:** The average speed during that ride

**Speed - Max Speed:** The maximum speed during that ride

**Speed:** The current rate of speed

**Temperature:** The current measurement of hot and cold

**Timer:** Is a stop watch of the current ride

**Trip 1:** The distance of a trip. Accumulative recording of distance between rides

**Trip 2:** The distance of a trip. Accumulative recording of distance between rides

## Updating Software

---

Software updates/manuals can be found at <http://www.lezyne.com/support-downloads.php>

1. Connect your device to your computer with the supplied USB cable.
2. Go to the GPS Root website Download page and choose the software update that works with your computer.
3. Allow the program to download and run on your computer.
4. Follow the on screen instructions and do not disconnect your computer until its complete.

\***Info – Firmware** will let you know which version of software is currently on your device.

## Support

---

How to videos, manuals , FAQ can be found on the Support tab at <http://www.lezyne.com/support-gps.php>




- Videos describing and explaining the device
- FAQ – Frequently Asked Questions related to the device
- Downloads – manuals and software updates
- Contact US

## Resetting the Device

---

If the device stops responding to button functions a simple reset could correct the issue.

\*Resetting the device could delete settings and files

- Hold **ENTER** and **MENU**  for 30 seconds
- The device will shut off
- Hold   for 2 seconds to turn device back on

## Resetting with Bootloader

---

When the application that runs the GPS becomes corrupted somehow and won't allow the GPS to start up, Bootloader will force the GPS into an update mode so that the GPS can be repaired. There might not be anything wrong with the device except that it won't connect to a computer. That's usually when you'll need to use the bootloader.

\*Resetting the device with bootloader could delete settings and files.

1. GPS power off and unplugged from a computer.
2. Open the updater software <http://www.lezyne.com/support-downloads.php>
3. Super/Macro GPS – hold down the LAP and ENTER buttons
  - Mini/Micro – hold down the MENU and ENTER buttons
4. While holding the buttons down, plug in the USB cable
5. The updater program will immediately start the update
6. Please allow for the updater to run to completion. Once complete, please wait 15 seconds before removing the USB cable to allow for any background processes to finish.

## Resetting to Factory Default

---

Resetting to factory default will erase stored info on the GPS device and restore it to factory start up settings.

1. Open the updater software <http://www.lezyne.com/support-downloads.php>
2. Plug GPS device into computer
3. In the upper left corner of the updater program – click on the words “Lezyne GPS Firmware Programmer
4. A pull down box will show and option for “Restore device to factory defaults”, click on this to start the process