USER MANUAL OF smart kit





CS374U-APP(OSK102) 16122000002774

CONTENTS

1 DECLARATION OF CONFORMITY	1
2 SPECIFICATION	1
3 PRECAUTIONS	1
4 TECHNICAL SOLUTION	2
5 OPERATION INSTRUCTION	4
6 HOW TO USE APP1	1
SPECIAL FUNCTIONS	3

FCC ID:2ADQOMDNA15 IC:12575A-MDNA15

1 DECLARATION OF CONFORMITY

Hereby, we declare that this smart kit is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity may be consulted with sales agent.

2 SPECIFICATION

Model: OSK102 Standard: IEEE 802.11b/g/n Antenna Type: Wxternal omnidirectional Antenna, Frequency: WIFI: 2.4G Maximum Transmitted Power: 15dBm Max Dimension:55*24*8(mm) Operation Temperature:0°C~45°C/32°F~113°F. Operation Humidity:10%~85% Power Input:DC 5V/300mA

3 PRECAUTIONS

- Applicable system :IOS, Android.
 (Suggest:IOS 7.0 or later Android 4.0 or later) Please check the service website for more applicable devices.
- Disclaimer:Due to the special situation existed during App use, we explicitly claim as bellow: Not all of the Android and IOS systems are compatible with the APP. We will not be responsible for any issue as a result of the incompatibility
 SMART KIT wireless safety strategy.
- SMART KIT wireless safety strategy. Smart kit Only support WPA-PSK/WPA2-PSK encryption and none encryption. WPA-PSK/WPA2-PSK encryption is recommended.

4 TECHNICAL SOLUTION

1. WIFI Router Home Control Mode.

A WIFI router is needed at this mode. Smart phone and connect to the AC through the WIFI router conditioner. 1) Smart Phone

- 2) Smart Air conditioner
- 3) WIFI Router



2. How to install the smart kit

① Remove the protective cap of the smart kit



- ② Open the front panel and insert the smart kit into the reserved port
- ③ Attach the QR code packed with SMART KIT to the side panel of the machine, ensure it is convenience to be scanned by the mobile phohe.



0

5 OPERATION INSTRUCTION

1.Install App

- 1).**Iphone Users:**scan QR Code or go to App Store and search for 'NetHome Plus' app and download it.
- Android Phone users:scan QR Code or go to google play, search for 'NetHome Plus' app and download it

2.How to reset the WIFI to defaults?

When you first time use WIFI function, it is necessary to make the Air Conditioner(AC) to enter the WIFI Network Setting Mode to do settings. The procedure includes the following steps:

- 1) Press the "LED" or "DO NOT DISTURB " or "" button (depending on the remote controller) seven times, the AC will enter AP mode. If it does not work, disconnect and then connect the power supply of the AC, and try it again within 3 minutes.
- When the AC displays' AP', it means that the AC WIFI has already entered into the WIFI Network Setting Mode.
- 3) When the AC WIFI entered into WIFI Network Setting Mode, the Air-conditioning remote control can't open the AC. It needs to wait 3-5 minutes or when the AC finishes the WIFI Network Setting Mode, then the Air-conditioning remote control can control AC normally.
- 4) If there is no set operation under WIFI Network setting mode, AC will quit this mode automatically 8 minutes later, and then the user can control the AC normally.

3.User Registration and Network Configuration Please ensure both your mobile device and air conditioner are connected to the Internet during

the registration process.



address and password, and then click 'Registration'.

4

Using Android device to do Network configuration



③ Press '+ Add Device' ④ Scan QR Code



© Enter your own WiFi router password and click OK;

6

Using IOS device to do Network configuration



③ Press '+ Add Device' ④ Scan QR Code



8



Configuration Success, you can see the device on the list.

6 HOW TO USE APP

Please ensure both your mobile device and air conditioner are connected to the Internet before using app to control the air conditioner via internet, please follow the next steps:



Ð

into the main control interface.

Ð



3 Thus, user can control air conditioners on/off status, operation mode, temperature, fan speed and so on.

7 SPECIAL FUNCTIONS

Including: Timer on, Timer off, 8°C Heat, Sleep, Energy, Check.

Timer on/ Timer off

Weekly, user can make an appointment to turn on or off AC on specific time. User also can choose circulation to keep the AC under schedule control every week.

8:00		Tana (to	201202	
			(8:00	
2:00	0	Timer Off	02:00	0
4	0	Sheep	-1/-	0.
	0	6'Neut		0
		Criwngy		3
	- 0	Check		2
	4	4 O O ·	April 2	Contraction Contra

Ð

B

09	49
10	50
.11	.81
ie peut	weaks 2

< ma	9
Monday	0
Taristay	0
Mediaestay	
Thur scley	
Feday	
Estunday	
Satday	

■ 8°CHeat

User can let the AC run under 8°C Heat by one-click. When people go outisde, this function can protect your furniture from frost damage.

<	Tunction	•
Timer On	18:00	
Timer Off	02:00	Ø
Sleep	*	0
8'Heat		0
Energy		2
Check		>

14

Ð

Sleep

User can customize their own comfortable sleep by setting target temperature.

¢	Function	•	 2 200
Timer On	18:00		i la la la la
Timer 0#	02:00	0	
Skeep	de	0	
0'Test		0	eti 🖸
(rwg/		1	young
Check		1	Béer
			Children

■ Check User can simply check the AC running status with this function. When finishing this procedure, it can display the normal items, abnormal items, and detail information.



6

Ð

 Abnormal: 0 	1
~ Normal: 96	
Compressor frequen	ю
Compressor current	
oetdoor machine cu	ment
Evaporator temperat	wite .
Condenser Tempera	6.00
Exhaust temperature	,
outdoor temperature	
indoor temperature	
Outside machine vo	haqe

CAUTIONS

• This device complies with Part 15 of the FCC Rules and RSS 247 of Industry & Science Canada. Operation is subject to the following two conditions: (1) this

dévice may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired • operation.

- Only operate the device in accordance with the instructions supplied. This device complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC and IC radio frequency exposure limits, human proximity to the
- antenna shall not be less than 20cm (8 inches) during normal operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.