User Manual

Using method:


Install the battery:

1.put the battery on the bottom of the robot.

2.connect the battery.

Download APP:

1. Search for "Ganker" on APP store.



2.Download "Ganker" APP.

Matching method:

1.Turn on Ganker Robot.



2.Switch to left.

Using:



- 1.Wait for 20 seconds.
- 2.Connect the "Ganker" WiFi.
- 3. Open the App, choose mode what you want .
- 4. When the heading light turn blue, you can start.

Attention:
On the uneven surface may affect the use of robots
Do not disassemble the robot personally
Clean robot, please use dry, soft cotton fabric
The battery quality affect the service life of the robot, please use the right battery
About the use of batteries:
Do not throw the battery at will or throw into the fire
When replacing the battery, please put the old battery in the battery recycling box

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.