AEROLINK AL 3.0



Operating Manual



Hing audio AL 3.0 Aerolink Bluetooth® Receiver

Thank you for purchasing the Aerolink by Fitness Audio. This product is easy to install by anyone one who is familiar with setting up sound systems. It is now available in 1 of 4 separate IDs: Aerolink1, Aerolink2, Aerolink3 and Aerolink4. They can be identified in 3 ways - 1) A Blue Dot on the Silver Label on the side of the carton is the first indication of the id number; 2) you will see a black number in a white circle on the right hand side of the front panel once you have unpacked the unit; and 3) the Bluetooth Device signature for the product when you pair it with your smartphone, pc or tablet. The 4 separate id versions can all be used under the same roof in adjacent rooms without any conflict in pairing - you will be pairing with the one who's number is shown on the front panel you are looking at.

1. Powering It Up.

The Aerolink can be powered from any 12V500mA already in use in the audio system like those that power the Wireless Mic Receiver using the DC "Y" Cable supplied. Alternatively, if you purchased the unit with an optional 12V DC Power Supply then please plug that into a GPO and DC connector into the Power In socket (1).

2. Connecting to a Mixer.


Connect using either the Stereo (TRS) Line Out Jack (3) or the 2 RCA sockets(2) to your mixer's matching Line Input sockets. A standard 2RCA to 2RCA Cable is provided.


3. Turn it on and linking up.

When you turn it on, the blue Power-on light in the switch illuminates and the 2 blue LEDs will start flashing once you have pushed the Blue LINK button (6). The first, "SCAN" LED(4) is searching for a smartphone or player to pair with, so, open your smartphone, go to Settings, select Bluetooth, turn Bluetooth on and watch it search for devices. After a few seconds the words Aerolink1 will appear and Not Connected will soon change to Connected and the SCAN LED will stop flashing. The second, "LOCK LED"(5) will continue to flash confirming the link is good. Go to your music file on the device and select the Playlist you want to use and press Play. If the sound system is turned on and the Aerolink has been selected then you will hear the music so set the volume and you are all done. Please note that the Volume Control (7) on the front Panel of the Aerolink is a "Turn Down" Attenuator so should always be on MAX unless a better cleaner sound with the Mixer or Amp input you are using is achieved with it set at the 12 o'clock position.

4. Re-setting the Link

Once you take the linked device out of the range of the receiver (around 8 meters or 25 feet) you will need to re-scan and connect again. Press the Blue Button to break a link and to start a new linking process again.





Key To Illustration:

- 1. DC Input
- 2. RCA Outputs
- 3. ¼" Stereo Jack Output
- 4. SCAN LED
- 5. LOCK LED
- 6. LINK button
- 7. ID Number
- 8. Volume Control

Fitness Audio products are distributed worldwide by Fitness Audio Network. They are manufactured to our specifications. Your Fitness Audio Aerolink is covered against manufacturing defects by a 12 month warranty commencing at the date of purchase.

Distributed in Europe by Knud Danielsen A/S Denmark www.fitnessaudio.dk and in the USA by Fitness Audio, LLC Santa Cruz, Ca. www.fitaud.com

Your comments are welcome. Email to: info@fitnessaudio.net.au

Warranty information for service claims	۶.
(Please retain for your records.)	

This product was purchased by:
(Business Name)
on (date) / / rom (Supplier)
of (address)
Serial Number

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- . Reorient or relocate the receiving antenna.
- . Increase the separation between the equipment and receiver.
- . Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- . Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



Do not remove lids No user serviceable parts inside Do not place liquid containers on unit Do not expose to moisture or rain This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Fitness Audio Network P/L
PO Box 321
Alexandria NSW 1435
AUSTRALIA
Www.fitnessaudio.net.au