

Theater Solutions by Goldwood™

Contents:


1 x Luminous Speaker
1 x fastener for lantern
4 x poles
1 x Spike
1 x USB charging cable
1 x User manual

Construction:

Put all the parts together and fasten the luminous speaker on the upper part of the fastener. Then connect the poles and the spike by means of a turn. After that you can push the ground spike into the ground.

Product Operation Panel:

Top of speaker:



Bluetooth ON/OFF button
Light ON button
USB Charge Port

Specifications:

-Ambient temperature for operation: 7° F to 95° F
-Charge time: 5 hours
-Charge duration (depending on lighting and sound intensity):
Light only: around 20 hours
60% Volume+Light: around 6-7 hours
Max Volume+Light: around 5 hours
-IP Class: IP44
-Power: 60W Total system Power
-Sensitivity: 90
-Frequency Response: 70Hz – 20kHz
-Bluetooth Name: UUFFOO

Features:

- Weatherproof against rain, snow, ice, salt, pool chemicals, etc.
- Built In Bluetooth Receiver
- Butyl Rubber Surrounds
- Voiced for Outdoor Performance
- 2- Way Design and Functionality



Battery Operation:

1. Please charge the battery fully before first use.
 2. Connect the USB adapter to the speaker using the charge port. While battery is charging the indicator will be red.
 3. Charge the battery until the indicator light is green.
 4. After the battery has been charged, turn on the speaker by pressing the **Bluetooth ON/OFF** button. The indicator light will be blue. Press (and hold for about 2 seconds) the **Light ON/OFF** button at the top of the speaker to turn on or off the light. Press the **Light ON/OFF** button a 2nd time to have the light enter flickering flame mode. Then follow the Bluetooth Function instructions.
- Note:** The built-in battery is not replaceable. Please do not remove or replace it in the trash. If you must dispose of this speaker, bring it to your local recycling center.

Bluetooth Function (Initial Setup):

1. Make sure battery is fully charged before attempting to connect the first time.
2. Starting with the 1st Tiki Torch, press the Bluetooth ON/OFF button on the top of the speaker. There will be an audible activation beep and the indicator light will flash blue.
3. On your phone, turn Bluetooth to "ON" and select "**UUFFOO**" in your Bluetooth device list. Once the device is connected you will hear a second audible beep from the speaker and the indicator light will be solid blue.
4. **PAIRING:** To connect additional speakers, first turn on the additional speaker by pressing the **Bluetooth ON/OFF** button (the indicator will flash blue). After the speaker is on, press and hold (for about 3 seconds) the **Bluetooth ON/OFF** button on each additional speaker. You will hear a beep sound from the additional speakers and the indicator light will flash green momentarily. The indicator light on the 1st/main speaker will remain green and the indicators on the additional speakers will turn off. To cancel the pairing, press and hold (for about 3 seconds) the **Bluetooth On/OFF** button.
5. To turn off the Bluetooth function, press the **Bluetooth ON/OFF** button.
6. For subsequent use simply turn on the 1st/main speaker, connect to your Bluetooth device then turn on the additional speakers. You will now hear music from all the speakers. If one of the additional speakers does not connect, press and hold the **Bluetooth ON/OFF** button (for about 3 seconds) to re-pair with the main speaker.

Bluetooth Weather Resistant Tiki Torch

Congratulations on your purchase and welcome to the world's finest brand of audio equipment. If you ever have questions on your product, please contact your authorized dealer and their highly experienced staff will be more than willing to help. Please read the following manual carefully before installing, connecting or adjusting your new speaker.

Precautions:

- The USB Cable is not waterproof, please only charge the battery indoors.
- this product should never be submerged in water
- disconnect the power adaptor from the outlet when not in use
- do not stand or jump on this product
- keep this product away from chemicals and high heat
- do not attempt to disassemble the speaker
- do not use this product outdoors if they are cracked or damaged

Troubleshooting:

1. If the additional speakers do not connect to the 1st speaker or you do not hear an audible beep sound when pairing the additional speakers, please press and hold(3s) the ON/OFF button on the additional speakers again.
2. Make sure only 1 “UUFFOO” record is in the device list, otherwise, you will not be able to pair. To fix this, simply have your device “Forget this Device” on any additional “UUFFOO” devices leaving only 1.
3. This product has a memory storage function (if the batteries are not fully exhausted), when you turn on speaker, the light and speaker will maintain the same settings and pairing as the last time used. If the battery is exhausted there will be no memory storage function and you will need to pair the 1st speaker with the additional speakers.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.Responsible for compliance could void the user's authority to operate this equipment.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement. The device can ben used inthe portable exposure condition without restiction

Made in China