















- a. The earbuts can be used individually (each earbut pairs to sparatise collision). Before using as angle earbut desparate pairing, all the previous. TOP plants growth need to be enable of the collision of the
- Default Setting recovery



Basic Parameter

Product Name: G5 Charging time: 1.5 hours Music Time: 7 hours Battery Type: Polymer Li-Ion Battery Operation range : 10m Charging Input: 5V === 1A Earbud weight: 6g+6g

Important Notice

- Please make sure the product is fully charged before initial use.
- Please use the brand adaptor complying safety requirements to charge
- . If your cellphone can not find "G5", please double check if your cellphone Bluetooth is at "Equipment visible mode". After initial pairing, the earbuds will be automatically paired for repeat use. If no use for a long time, need to follow up pairing procedures to pair with the cellphone
- . If there is only one earbud has sound while in music mode, please restart the earbuds or manually recover the default setting.

Security warning

service center

D.Charging USB Port E.Status LED F.Lanyard Hole

- Please use the product in the temperature between 0 ℃-45 ℃. When the environment temperature is too high or low, it may cause the product malfunction
- · Please keep the product dry, do not contact water or humidity environment
- Please do not drop, throw, pull/drag the product to prevent damage.
- Please power off before clean the product. Please use the product at proper volume while listenning music or answering call, long time at high volume usage could lead to
- permanent hearing loss. The built in battery is not dismountable, please do not replace by yourself. If it's really necessary, please ask help from authorized
- Please dispose the product according to local law, can not treat it as domestic garbage.
- Without adult supervision, please keep the product out of reach of children, the swallow of small components included may cause asphyxia.

Warranty

- This product is covered under warranty for a period of one year from the date of purchase limited to normal use and maintenance of the machine parts, materials and functions. Problems and failures verified upon further identification, will be provided free repair and replacement parts
- Excluding the following: A. Headset is beyond the warranty period;
- B. User does not follow the instructions, so that the headphone wire and earplug broken.
- C. Without the authorization to dismount, repair, alteration structures;
- D. Can't provide proof of purchase.
- E. Man made damage.
- F. Due to natural disasters and other force majeure (such as earthquakes, fires) product failure of damage causes;

Use Us Dealer's telephone#

Model #	
Inspector	
Date	

Warranty Card	
User's name	
User's telephone#	
User's Add	
Data of a service of	

Dealer's name Dealer's Add __

QC Report info

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction