

MONSTER®

CLARITY | AIRLINKS

Model No.:MH21904

FCC ID:2AVD2-MH21904

Quick Start Guide

Please read this Quick Start Guide carefully and keep it for future use.




Product Overview

In-ear Earphone x 2 (left & right)

Charging Case

USB-C Charging Cable

Quick Start Guide and Warranty Letter



1. Microphones
2. Multi Function Button (MFB) & Indicator Light
3. Optical Sensor
4. Charging Contacts
5. Charging Case Indicator Light
6. USB-C Charging Port
7. Wireless Charging Area

Power On/Off

Open the charging case, take out the earphones, it will automatically turn on. To turn off the earphones, put back to the charging case and close. Earphones will be turned off and start charging.

Wired/Wireless Charging Case Charging

Besides using the included USB-C charging cable to charge the charging case, the charging case can be charged by compatible wireless charging device.

After charging case is fully charged, charging case indicator light will remain on for around 5 minutes then turn off.

Pairing

Open the charging case, take out the earphones, it will automatically turn on. left and right earphones will be connected automatically within few seconds. Then “pairing” voice prompt will be heard. For new device connection, go to the Bluetooth settings on your mobile device and set it to search for new devices (new Monster device). Once the earphones are paired to the designated device, you will hear “connected”.

Volume Control

Volume down: quickly double press the MFB on the left earphone during music streaming.

Volume up: quickly double press the MFB on the right earphone during music streaming.

Calling

Answer / End a call: Click the MFB touch button.

Reject the call: Press and hold the MFB touch button for about 2 seconds.

Music

Play/Pause music:

- short press the MFB button.
- built-in optical sensor, smart in-ear detection.
 - pauses the music when earphone is taken off.
 - plays the music when earphone is put on.

Previous song: Press and hold the MFB button on the left earphone for about 2 seconds.

Next song: Press and hold the MFB button on the right earphone for about 2 seconds.

Voice Control

After connecting to the phone, quickly double press the MFB to activate the voice assistant.

LED Indicator Guide

Mode	Description	Voice prompts
Power On	White LED indicator light stays on about 1 second	"Power On"
Power Off	Red LED indicator light stays on about 1 second	"Power Off "
Pairing	White LED indicator light flashes quickly	"Pairing"
Connected	Indicator light goes off	"Connected"
Earphone charging	Red LED indicator light stays on	-
Charging case	Charging case indicator light flashes while charging. When charging case indicator light is off, it is fully charged.	-

Note:

- * After removing the headset from the charging box, without pressing any buttons, the left and right headsets will automatically connect and enter pairing mode automatically.
- * Please put the earphone in the correct position to charge.
- * If the battery is not replaced properly, there is a danger of explosion. The battery can only be replaced with batteries of the same type or equivalent. It is not recommended to replace the battery without permission, but it can be returned to the manufacturer for replacement.
- * Battery [battery pack or battery combination] must not be exposed to lighting, baking or similar overheating environment.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.