

6CT LED PATHWAY MARKERS  
ITM. / ART. 1487571

# IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic precautions should always be followed including the following:

## READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

- a) Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
- b) This seasonal use product is not intended for permanent installation or use.
- c) Do not mount or place near gas or electric heaters, fireplaces, candles or other similar sources of heat.
- d) Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- e) Do not let lamps rest on the supply cord or on any wire.
- f) Unplug the product when leaving the house, when retiring for the night, or if left unattended.
- g) This is an electric product-not a toy! To avoid risk of fire, burns, personal injury and electric shock it should not be played with or placed where small children can reach it.
- h) Do not use this product for other than its intended use.
- i) Do not hang ornaments or other objects from cord, wire, or light string.
- j) Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
- k) Do not cover the product with cloth, paper or any material not part of the product when in use.
- l) This product is equipped with push-in type LED lamps. Do not twist lamps.
- m) This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Also unplug any additional strings or products that may be attached to the product. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded.
- n) Read and follow all instructions that are on the product or provided with the product.

**WARNING:** This product is powered by a lithium battery. Due to their small size, lithium batteries can easily be swallowed by children. Ingestion of such batteries has been known to cause death.

## SAVE THESE INSTRUCTIONS

**CAUTION:** To reduce the risk of fire and electric shock: a) Do not install on trees having needles, leaves or branch coverings of metal or materials which look like metal. b) Do not mount on support strings in manner that can cut or damage wire insulation.

## USE AND CARE INSTRUCTIONS

- a) When the product is placed on live a tree, the tree should be well maintained and fresh. Do not place on live trees in which the needles are brown or break off easily. Keep the tree holder filled with water.
- b) If the product is placed on a tree, the tree should be well secured and stable.
- c) Before using or reusing, inspect product carefully. Discard any products that have cut, damaged, or frayed wire insulation or cords, cracks in the lampholders or enclosures, loose connections, or exposed copper wire.
- d) When storing the product, carefully remove the product from wherever it is placed, including trees, branches, or bushes, to avoid any undue strain or stress on the product conductors, connections, and wires.
- e) When not in use, store neatly in a cool, dry location protected from sunlight.
- f) The LED lamp has polarity. Do not deliberately change the direction of the LED lamp in the lampholder.

## USER SERVICING INSTRUCTIONS

To replace the fuse:

- a) Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
- b) Open fuse cover. Slide open fuse access cover on top of attachment plug towards blades.
- c) Remove fuse carefully. Turn plug over to remove fuse.
- d) **RISK OF FIRE.** Replace fuse only with 3 Amp, 125Volt fuse provided with product.
- e) Close fuse cover. Slide closed the fuse access cover on top of attachment plug.
- f) **RISK OF FIRE.** Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged.

To replace a lamp:

- a) Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
  - b) Be sure to pull lamp and plastic base straight out of lampholder.
  - c) Replace lamp with only 3.2 volts, 0.064 watts LED type lamps provided with this product.
- If the new lamp base does not fit in lamp holder, follow the step below before Step c. NOTE - Be careful when exchanging the lamp base on the new lamp with the old one or the LED wires may break if leads are bent too many times.

1. Remove the base or burned out LED lamp by carefully straightening lamp leads and gently pull lamp out.
2. Thread leads of new LED lamp through holes in old base with one lead in each hole.
3. After lamp is fully inserted into base, bend each lead up, like other LED lamps in the light set so that the leads will touch the contacts inside the lamp holder.

**NOTE – To avoid damage to the set:** 1. Do not deliberately change the direction of the LED lamp in the lampholder.

2. Use only the included spare LED bulbs for replacements, and only replace with the same color LED bulbs.
3. Do not switch the order of the colors of the bulbs or interchange bulbs from different sets and only use the same lamp base colors for replacements.



Connecting Sets End to End:

## CAUTION:

This string is rated 14.4 Watts (0.12Amps), do not overload. Connect other Lighting Strings or decorative outfits end-to-end up to a maximum of 3 sets (34W) total. DO NOT EXCEED THE SETS PERMITTED BY THE MARKINGS!

## CAUTION:

- a) Risk of fire. This product does not contain lamp shunts, which allow the product to operate if one lamp burns out. Replace lamps only with the spare lamps provided with this product
- b) Replace lamps only with 3.2 volts, 0.064 watts spare LED lamps provided with this product.

Do not connect more than 3 sets of products of the same model number end-to-end.

NOTES:

1. The height of the lettering in the text in the instructions specified below shall be as follows (VENDOR MUST CHECK before printing):

a) UPPER CASE LETTERS shall not be less than 1/12 inch (2.1 mm) in height.

b) lower case letters shall not be less than 1/16 inch (1.6 mm) in height.

c) The phrases or word below shall be ALL UPPER CASE (as shown) and the letters must not be less than 3/16 inch (4.8 mm) in height:

"IMPORTANT SAFETY INSTRUCTIONS"

"READ AND FOLLOW ALL SAFETY INSTRUCTIONS"

"SAVE THESE INSTRUCTIONS"

"CAUTION:"

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.