



We sincerely thank you for choosing XbotGo!


To better use this product, please carefully read the instructions before use and keep this manual for future reference. If you have any questions, feel free to contact us. Our professionals will be happy to answer your questions and help. We wish you a pleasant experience.

Warning:
Please read all safety warnings and instructions carefully. Failure to comply may result in fire, electric shock, or other serious injuries. Please keep all warnings and instructions for future reference.

Environmental Protection Instructions:
• Comply with the waste disposal laws and regulations of relevant countries. Electronic devices should not be disposed of as household waste. Devices, accessories, and packaging should be recyclable.
• Do not litter electronic wastes at will.


Remote Controller Specifications

Model:	XbotGo RC1
Battery Model:	CR2032
Signal Coverage Range:	10m
Temperature:	-5°C ~ 60°C (23°F ~ 140°F)




Quick Start Guide

- A. Open the battery compartment cover, then remove the insulating plastic sheet from the bottom of the battery and close the battery compartment cover.
- B. Press and hold the power button for 3 seconds to turn on/off the remote controller.
- C. After turning on, press the function selection button to switch functions.
- D. Bluetooth pairing is required before the first use.
- Press and hold the remote controller's power button. After the remote controller is powered on, the phone connection indicator flashes red.




- Open XbotGo APP on your phone and select XbotR-XXXX in the XbotGo APP for pairing. After the connection is established, the phone connection indicator on the remote controller will turn into a solid blue.
- E. Exceed the signal range (10 meters):
The red menu indicator light and the circular ring light on the remote control are flashing, indicating that the remote controller has been disconnected from the APP. If it returns to the reception range in less than 1 minute, the remote controller's blue light will turn on, and the connection will be automatically restored.



- F. Sleep mode and Shutdowns:
The RS remote controller enters the dormant state without any operation. In the dormant state, press any button on the remote controller to enter the connected state. After sleeping for more than five minutes, the remote control will automatically shut down, press the power button, and then close the device again after turning on to reconnect.

Note:
The disconnection of the remote controller during use will not affect the APP running on the phone. If the APP cannot find the remote controller during use, you can reset the remote controller by pressing the power button for 3 seconds, then perform the pairing again.

XbotGo RC1 Remote Controller



- A. Power Button
B. Function Selection Button
C. Confirm Button
D. Directional Buttons (Circular Disk)
E. Battery Compartment

Buttons and Functions

Before you use it, get familiar with the remote controller.

Camera Function


Press the Function Selection button to switch to camera mode; press the confirm button in camera mode to control the shooting states.

- On the remote controller:
 - A "beep" sound will appear, indicating entry into camera mode.
 - Two consecutive "beep-beep" sounds indicate that the camera is paused or not activated at this time.
- On the APP side:
 - A blue mask will prompt on screen for 3 seconds and will automatically disappear after 3 seconds. At this point, it is in camera mode, and you can check the status with corresponding operational commands.




Photo Function

- Press the Function Selection button to switch to the photo mode;
- In photo mode, press the confirm button to take photos.



Steering Function


- Press the Function Selection button to switch to the steering mode;
- Press the up, down, left, and right directional buttons to rotate the gimbal in the corresponding direction.



Mark Function (Available only during camera function mode)

Manually mark the highlight moments during the game. It will for generating produce a highlight video of the game automatically online and upload to the cloud.


Pressing the confirm button on the remote controller, XbotGo APP will record video segments before and after the marked moment. When the marking button is pressed, the blue circular ring light will flash, indicating successful marking.



Highlights can be viewed in XbotGo App/Cloud Management/Cloud Drive.

Note

If the remote controller's red breathing light flashes, the buzzer alerts, or if the APP displays errors, command execution failures, please follow the prompts on the APP side for operation.




Battery

The remote controller is equipped with a CR2032 button battery.

Notes

- For optimal product performance:
- Please do not use different types of batteries.
 - If you do not intend to use the device for more than two months, please do not leave the battery in the remote controller.
- Battery Disposal:
- Do not dispose of batteries as unsorted municipal waste. Please refer to local regulations for proper battery disposal.



Notes on Remote Controller

- The remote controller must be used within a range of 10 meters from the device.
- When the remote control signal is received, the App will provide pairing prompts.



尊敬的用户，首先衷心感谢您选择 XbotGo！


为了更好的使用本产品，请您务必在使用之前仔细阅读使用说明书，并保留本手册以供日后查阅。若意在使用过程中有任何问题，请及时和我们取得联系，我们有专业人员为您解答疑惑，祝您使用愉快。

警告：
请仔细阅读所有安全警告和使用说明，不遵守相关警告和说明可能会导致触电、火灾或其他严重伤害。请保留所有警告和说明事项，以备日后参考。

环境保护说明：
认真遵守相关法律法规，电子产品不能按生活垃圾的方式处理。设备、附件和包装应为可回收物。
• 禁止随意丢弃废旧的机器设备。


遥控器规格

型 号	XbotGo RC1
电池型号	CR2032
信号接收范围	10m
使用环境	-5°C ~ 60°C (23°F ~ 140°F)



快速入门指南

- A. 打开电池仓盖，掀掉电池底部的绝缘塑料片，关闭电池仓盖。
- B. 长按电源键3S开/关遥控器。
- C. 开机后，点击功能选择键，进行功能选择切换。
- D. 首次使用前请进行蓝牙配对。
- 长按遥控器电源键，遥控器开机后，“手机连接指示灯”为红色闪烁；
 - 完成蓝牙开机的设备后，在XbotGo APP中选择XbotR-XXXX，点击进行配对，连接完成后，手机连接指示灯蓝色亮起。



- E. 超出信号范围：
遥控器上出现红色菜单指示灯和圆环灯闪烁，此时遥控器断连断开，一分钟内重新进入可接收范围遥控器指示灯亮起会自动恢复连接。
- F. 休眠与关机：
休眠：遥控器无任何操作进入休眠状态，在休眠状态下按下遥控器任意按键可进入到连接状态，3S后超过五分钟遥控器自动关机，按下机身键，开机后再次靠近设备后可重新连接。



注意事项

在使用过程中如APP无反应请联系遥控器本身的使用，并中不影响当前正在运行的程序。如在使用过程中出现APP无法连接遥控器，可长按电源键三秒重置遥控器，重新进行配对连接操作后即可恢复使用。

XbotGo RC1 遥控器



- A. 电源键
B. 功能选择键
C. 确认键
D. 方向键(圆盘)
E. 电池仓


按钮和功能

在开始使用之前，请务必熟悉遥控器。

摄像功能


按压功能选择键，切换至摄像功能；在摄像功能模式下按下确认键，对拍摄状态进行控制。

- 遥控器端：
 - A. 出现一下“滴”声，进入摄像状态。
 - B. 出现连续两下“滴滴”声，提示此时摄像暂停或摄像未开启。
- APP端：
 - 3S后画面变黑，3S后画面自动消失，此时已进入摄像状态，可对应操作指令查看拍摄状态。




拍照功能

- 按压功能选择键，切换至拍照功能；
- 在拍照模式下，按下确认键自动拍摄照片。



转向功能

- 按压功能选择键，切换至转向功能；
- 按压上、下、左、右方向键，镜头相应操作转动方向。




打点功能（仅在摄像时可用）

按下手动标记拍摄过程的精确时刻，自动生成精彩集锦视频。

按下遥控器上的确认键，XbotGo APP会记录下打点时刻前后的视频片段。按下打点键时，蓝色圆环灯闪烁，打点成功。

精彩片段可在 XbotGo App/云管理/云盘 查看。



注意

遥控器出现红色呼吸灯闪烁，蜂鸣器提醒，及APP出现提醒、指令执行失败或等异常反馈，请对照APP端提示进行修复。



电池

遥控器内置有CR2032纽扣电池。

注意事项

- 最高的产品性能获得のために：
- 異なるタイプの電池を使用しないでください。
 - 2ヶ月以上ディスプレイを使用するつもりがない場合は、リモートコントローラーに電池を入れたままにしないでください。
- 電池の処分：
- 電池を未分別の市町村みとして処分しないでください。電池の適切な処分方法については、地域の規則を参照してください。



リモートコントローラーの注意事項

- リモートコントローラーはディスプレイから10メートルの範囲内で使用する必要があります。
- リモートコントローラーは無線信号を受信すると、アプリがペアリングのアイコンを表示します。



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.