




1. Fan/light switch, short press to turn on the fan power switch, the fan will start to rotate, long press to turn on the light, long press again to turn off the light.

7. Fan stop button, short press to stop the fan, press again to turn on the fan.

2/3/4/8/9/10. Fan gear button, press different numbers to correspond to different wind speeds.

5/11。 - /+ key is to control the brightness of the light. Short press once and the brightness of the light changes once.。

6. 1H/4H/8HIt is a fan timing switch. Short press once to set the timer for 1 hour, and the second time to set the timer for 4 hours. The third time is 8 hours.。

12. Fan reversal switch, press it briefly and the fan will reverse once, press it again and it will reverse again.。

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.