TOSHIBA Wireless LAN Card Installation

This sheet provides information on installing the Wireless LAN card in the PORTÉGÉ M200.

CAUTION: This sheet is for information only. The Wireless LAN card must be installed by dealers of TOSHIBA or TOSHIBA OEM products.

NOTE: The Wireless LAN card is a wireless network card that complies with the IEEE 802.11 standard for Wireless LANs (Revision B.)

Installing the Wireless LAN card

- 1. Discharge static electricity from your body by touching a metal object, before you handle the card.
- 2. Turn off the power and disconnect the AC adaptor.
- 3. Lay the computer upside down.
- 4. Remove the battery pack from the computer. For instructions on removing the battery pack, refer to Chapter 6 in the online manual.

5. Remove twenty screws securing computer's under cover. (One screw is situated under the battery pack.)

NOTE: Use a point size 0 Phillips screwdriver.



Figure 1 Removing twenty screws

- 6. Loosen one screw securing the memory module cover and lift off the cover. Remove the memory module. Refer to Chapter 8 in the online manual for details.
- 7. Loosen one screw securing the HDD cover and lift off the cover.



Figure 2 Removing the memory module cover and HDD cover

8. Slide the HDD and remove it.



Figure 3 Removing the HDD

9. Disconnect the VGA fan cable under the memory module.



Figure 4 Removing the VGA fan cable

10. Remove the computer's under cover.



Figure 5 Removing the computer's under cover

11. Remove flat-head two screws and the metal cover.



Figure 6 Removing two screws and the metal cover

12. Connect the antenna cables to the proper connectors on the Wireless LAN card. The cables are color coded white and black. Refer to figure 7 to see for which color to goes to which connector.

CAUTION: Be careful not to apply pressure to the ICs on the Wireless LAN card.

- 13. Hold the card at about a 45 degree angle, fit it into the computer's connector and press carefully to ensure firm contact.
- 14. Gently, push the card down until latches on either side engage the card to hold it in place.



Figure 7 Installing the Wireless LAN card

15. Route the cable as shown below and secure it with tape.



Figure 8 Routing the Wireless LAN cable

- 16. Seat the metal cover on the Wireless LAN card and secure it with flat-head two screws.
- 17. Seat the computer's under cover.
- 18. Connect the VGA fan cable under the memory module.
- 19. Seat the memory module. Refer to Chapter 8 in the online manual for details.
- 20. Seat the memory module cover and secure it with one screw.
- 21. Install the HDD.
- 22. Seat the HDD cover and secure it with one screw.
- 23. Secure twenty screws.
- 24. Turn the computer upside down.

Applying labels

The figure below shows the locations of labels . The letters A, B, C and D correspond to labels identified in later illustrations. The applied labels will vary according to your computer's configuration.



Figure 9 Label positions

New labels

Refer to figures above and below when you apply new labels.

- 1. Remove the battery pack. Refer to Chapter 6 in the online manual for details.
- 2. Apply the following Wireless LAN label to position A, if the space is empty.
- If your computer has the Bluetooth label at position A, apply the Wircless LAN label to position B.



Figure 10 Wireless LAN label



Figure 11 Bluetooth label

4. Apply the following barcode label to position C.

Wire	iess LAN	1234567	7890AB

Figure 12 Barcode label

5. Apply the following Singapore Regulatory label to position D. If your computer already has the Singapore Regulatory label, you do not need to apply a new label.

Approved by IDA for		
use in Singapore		
DA101747		

Figure 13 Singapore Regulatory label