TROUBLE SHOOTING & SUPPORT

Problem - Vehicle does not move or moves slowly.

- Make certain there are fresh alkaline batteries in the transmitter and that they have been installed in the correct position.
- Are the (+) and (-) markings on the alkaline batteries in the same position as the (+) and (-) markings in the Transmitter Battery Compartment?
- Has the internal battery in the vehicle been charged?
- Are the metal contact tabs touching, rusty or dirty in the transmitter?
- Make certain that the vehicle ON/OFF switch is in the "ON" position.

Problem - Vehicle moves by itself or exhibits reduced range from the transmitter.

 Make certain there is no outside radio interference in your area. The best way to test this is to take the vehicle as far away from radio towers, electrical lines or tall buildings as possible to ensure no further radio interference will occur.

Always remove Batteries from transmitter when not in use.

Do not dispose batteries in fire. Leakage, explosion and personal injury may occur.

Do not attempt jumps or tricks with this vehicle.

Do not attempt to remove internal battery.

Adult supervision recommended.

PROPER USE, PRECAUTIONS & CARE



Switch vehicle OFF when not in use.



dirt aets trapped.















F.C.C. CAUTION:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However. there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



OWNER'S MANUAL

Please read and understand all precautions prior to use.

Thank you for choosing a premium New Bright product.

USA & Canada 30-Day Limited Warranty

New Bright Industries warrants to the original purchaser that this product will be free of defects in materials and workmanship for thirty (30) days from the date of purchase. In the event of such defect within the warranty period, New Bright will repair or replace the product at our sole discretion. This warranty does not cover damage resulting from unauthorized modifications, accident, misuse or abuse.

Should your item have a defect covered under this warranty, first call the toll free number listed below. Most problems can be resolved in this manner. If necessary, you will be issued a Return Authorization number (RA) and instructions on how to obtain a Product Return Form. The Product Return Form is to be used when returning a product to us (postage pre-paid and insured by the consumer).

When returning a defective product, please package the product, the Product Return Form and a copy of the dated sales receipt as proof of purchase. Be sure to mark the RA number on the Product Return Form, If the product is returned without a dated sales receipt, it will be excluded from coverage under this warranty. Please allow 4 to 6 weeks for delivery of repaired or replacement vehicles (depending on your location).

New Bright Industries' liability for defects in materials and workmanship under this warranty shall be limited to repair or replacement at our sole discretion. In no event shall we be responsible for incidental, consequential or contingent damages (except in those states that do not allow this exclusion or limitation).

Valid only in the USA & Canada.


Contact New Bright Industries Customer Service Toll Free at: 1-877-NBI-TOYS (1-877-624-8697) Monday through Friday, 8:00 AM to 5:00 PM Eastern Time

> U.S. Toy Sales and Marketing Co. Inc. 30260 Oak Creek Drive - 2nd Floor

Wixom MI 48393 1-877-624-8697 http://www.newbright.com/

JN145-20

TRANSMITTER BATTERY INSTALLATION



Note: When replacing batteries:

Use alkaline batteries only.

Do not mix old and new batteries.

Do not mix alkaline, standard or rechargeable batteries.


TRANSMITTER FUNCTIONS & HOW TO DRIVE

Auto pairing:


- Install alkaline batteries in transmitter.
- 2. Turn vehicle ON/FF switch to the ON position.
- Indicator light on transmitter will flash for pairing.
- When indicator light stops flashing pairing is complete. You are now ready to play.

Mote

Vehicle has working lights. When driving forward or reverse the lights will turn on.



VEHICLE FUNCTIONS



Steering Trim:

If the vehicle veers to the left or right, adjust steering trim on underside of vehicle until the desire alignment is reached.

CHARGING INSTRUCTIONS

Operation:

- Move switch on bottom of vehicle to the "OFF" position.
- 2. Raise charging plug at top of controller.
- 3. Align vehicle as shown.
- Plug the charging stick into the charging port on the underside of the vehicle.
- Press any joystick on the controller to begin charging. The charging indicator light on the controller will turn on.
- When charging is completed, in approximately 8-10 minutes, the charging indicator light will turn off.

