ASKEY WIFI Module WLU6120-D01(RoHS) WLU6121-D01(RoHS) OPERATION MANUAL

DRAFT_V01


1. Product Spec.

I. Floudet Spec.	
Chip Set	Atheros AR9271
Operation Voltage	3.3V
Network Standards	IEEE802.11b, IEEE802.11g and IEEE802.11n
Modulation Techniques	BPSK, QPSK, CCK, DBPSK, DQPSK, 16QAM, 64QAM
Modulation Technology	OFDM, CCK, DSSS, MIMO(1T1R)
Data Rate	802.11b: 11, 5.5, 2, 1 Mbps 802.11g: 54, 48, 36, 24, 18, 12, 9, 6Mbps 802.11n: HT20: 65, 58.5, 52, 39, 26, 19.5, 13, 6.5Mbps(MCS7-0) HT40: 135, 121.5, 108, 81, 54, 40.5, 27, 13.5Mbps(MCS7-0)
Network Architectures	Infrastructure and Ad Hoc
Operating Frequencies	2.412~2.462 GHz
Antenna Type	Antenna 1: RF chain 0 for transmit and receive Antenna 2: RF chain 1 diversity antenna for receive
RF output power	11b: 16dBm 11g: 16dBm , 15dBm@54M 11n HT20: 16dBm, 13dBm@MCS6, 12dBm@MCS7 HT40:16dBm, 15dBm@MCS5, 11dBm@MCS6, 10dBm@MCS7
Receiver sensitivity (PER<10%)	802.11b: -82dBm@11Mbps and PER<8% 802.11g: -65dBm@54Mbps and PER<10% 802.11n: HT20-654dBm, HT40:-62dBm
Power Consumption	Tx: 1115mW continuous transmitter 11b @2.4GHz;(1M, 18dBm, 1TX, IEEE802.11b) Tx: 1181mW continuous transmitter 11g @2.4GHz;(6M, 18dBm, 1TX, IEEE802.11g) Tx: 1184mW continuous transmitter 11n @2.4GHz;(MCS0, 20MHz, IEEE802.11n) Tx: 1207mW continuous transmitter 11nb @2.4GHz;(MCS0, 40MHz, 1TX, IEEE802.11n) Rx: 376mW continuous transmitter 11g @2.4GHz;(1M, IEEE802.11b) Rx: 376mW continuous transmitter 11g @2.4GHz;(6M, IEEE802.11b) Rx: 376mW continuous transmitter 11g @2.4GHz;(6M, IEEE802.11g) Rx: 376mW continuous transmitter 11n @2.4GHz;(MCS0, 20MHz, IEEE802.11n) Tx: 475mW continuous transmitter 11nb @2.4GHz;(MCS0, 40MHz, 1TX, IEEE802.11n)
Temperatures(AMBIENT)	Operation: 0~60 , Storage:-20~70
Humidity(non-condensing)	0~95%RH
Antenna	Ant1: PCB Antenna/ Gain:2.86 Ant2: PCB Antenna/ Gain:2.74 Ant3: PCB Antenna/ Gain:2.19 Ant4: PCB Antenna/ Gain:2.50 Ant5: PCB Antenna/ Gain:0.77


2. Setup Operation

- A. Install WLU6120-D01(RoHS) / WLU6121-D01(RoHS) into the system.
- B. Setup Driver as blow windows:





ease choose your search and installation options.	
⊙ <u>S</u> earch fo	r the best driver in these locations.
	heck boxes below to limit or expand the default search, which includes local removable media. The best driver found will be installed.
🗌 Se	arch removable media (floppy, CD-ROM)
🔽 Inc	lude this location in the search:
.0	0.143_AWiC1.1.0.39_INSTALL7.7.0.88bin\ndis5x 🖌 🛛 Browse
0.0	rch. I will choose the driver to install.
O Dont sea	ICN. 1 WIII CHOOSE THE GRIVER TO INSTAIL.
	you choose will be the best match for your hardware.
Hardwa	<pre>re Installation</pre>
Hardwa	< <u>B</u> ack <u>N</u> ext > Cance
Hardwa	< <u>Back</u> <u>Next</u> >Cance
Hardwa	<u>Reack Next</u> Cance Installation The software you are installing for this hardware: Atheros AR9271 Wireless Network Adapter
Hardwa	K Next > Cance Installation The software you are installing for this hardware:



USA - Federal Communications Commission (FCC)

FCC Radiation Exposure Statement

• The radiated output power of WiFi Module 802.11bgn devices is far below the FCC radio frequency exposure limits. Nevertheless, WiFi Module 802.11bgn devices should be used in such a manner that the potential for human contact during normal operation is minimized. To avoid the possibility of exceeding the FCC radio frequency exposure limits, you should keep a distance of at least 20 cm between you (or any other person in the vicinity) and the antenna that is built into the notebook.

Interference Statement

These devices comply with Part 15 of the FCC Rules. Operation of the devices is subject to the following two conditions: (1) The devices may not cause harmful interference, and (2) The devices must accept any interference that might cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If the equipment is not installed and used in accordance with the instructions, the equipment might cause harmful interference to radio communications. There is no guarantee, however, that such interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception (which can be determined by turning the equipment off and on), the user is encouraged to try to correct the interference by taking one or more of the following measures:

- Relocate this device.
- Increase the separation between the device and the receiver.
- Connect the device into an outlet on a circuit different from that of other electronics.
- Consult the dealer or an experienced radio technician for help.



. • WiFi Module 802.11bgn must be installed and used in strict accordance with the manufacturer's instructions as described in the user documentation that comes with the product. Any other installation or use will violate FCC Part 15 regulations. Modifications not expressly approved by ASKEY could void your authority to operate the equipment.

• The devices must not be co-located or operating in conjunction with any other antenna or transmitter.

Canada. Industry Canada (IC)

This device complies with RSS210 of Industry Canada.

CAUTION: Exposure to Radio Frequency Radiation. The installer of this radio equipment must ensure that the antenna is located or pointed such that it does not emit RF field in excess of Health Canada limits for the general population. Consult Safety Code 6, obtainable from health Canada's website www.hc-sc.ca/rpb.

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

2. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

3. Any changes or modifications (including the antennas) made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment. This device is intended only form OEM integrators under the following conditions:

1) The transmitter module may not be co-located with any other transmitter or antenna.

IMPORTANT NOTE: In the event that these conditions can not be met (for example certain laptop configurations or co-location with another transmitter), then the FCC authorization is no longer considered valid and the FCC ID can not be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate FCC authorization.

End Product Labeling

The final end product must be labeled in visible area with the following: Contains TX FCC ID: H8N-WLU6120; IC: 1353A-WLU6120

End Product Manual Information

The user manual for end users must include the following information in a prominent location "IMPORTANT NOTE: To comply with FCC RF exposure compliance requirements, the antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.