Lenovo IdeaPad S10-3 User Guide v1.0

New World. New Thinking.[™] www.lenovo.com



lenovo.

geapad

Notes

- Before using this information and the product it supports, be sure to read Important safety information on page iii and Notices in Appendix E first.
- Some instructions in this guide may assume that you are using Windows® 7. If you are using
 other Windows operating system, some operations may be slightly different. If you are using
 other operating systems, some operations may not apply to you, but it won't substantially affect
 your use of this computer.
- The features described in this guide are common to most models. Some features may not be
 available on your computer and/or your computer may include features that are not described in
 this user guide.

First Edition (November 2009)

© Copyright Lenovo 2009.

LENOVO products, data, computer software, and services have been developed exclusively at private expense and are sold to governmental entities as commercial items as defined by 48 C.F.R. 2.101 with limited and restricted rights to use, reproduction and disclosure. LIMITED AND RESTRICTED RIGHTS NOTICE: If products, data, computer software, or services are delivered pursuant a General Services Administration "GSA" contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

lenovo




If your product is not working correctly, DO NOT RETURN IT TO THE STORE.

For technical assistance, contact a Lenovo support specialist 24 hours a day by calling toll free **1-877-4 LENOVO** (1-877-453-6686).

Additionally, you can find support information and updates on the Lenovo Web site located at http://consumersupport.lenovo.com.

^{*} Only for the users from the United States.



Dear user,


Thank you for purchasing your new Lenovo notebook computer! Before using this product, make sure to read this user guide carefully.


We are pleased that you have chosen Lenovo for your mobile computing needs. To help you master the usage of your new computer quickly, we have prepared this user guide. In this manual you will find information on the system configuration, basic operating instructions, and important notices. We have done our best to avoid any errors in making sure that the information provided in this manual is accurate and reliable. However, due to the short length of the user guide it is impossible to cover all topics in great depth. For this reason, we apologize for any omissions you might find.


Lenovo is always trying to improve the performance and reliability of its products. For that reason, the hardware and software components shown within the user guide might not perfectly match those of your system.

However, any inconsistencies between what is described in the user guide and the operations of your computer should not substantially affect your use.

Thank you for your cooperation.









Explanation of hard disk capacity


Dear user,


While using your computer, you may find that the nominal hard disk capacity indicated is somewhat different from the disk capacity displayed by the operating system. For example, a nominal 40GB hard disk will appear as less than 40GB in the operating system. This discrepancy is not an error in hard disk installation nor any other problem, but a normal phenomenon of computers. This phenomenon is primarily due to the following reasons:

I. Different standards used by the manufacturer and operating system when calculating hard disk capacity

Hard disk manufacturers use a radix of 1000, i.e., 1G = 1,000MB, 1MB = 1,000KB, 1KB = 1,000 bytes. However, when identifying hard disk capacity, operating systems use a radix of 1024, i.e., 1GB = 1,024MB, 1MB = 1,024KB, 1KB = 1,024 bytes. The standard adopted by your computer is that of the hard disk manufacturers. Since the standards adopted by the hard disk manufacturer and operating system are different, the hard disk capacity displayed by the operating system will be different from the nominal hard disk capacity.

For example, if the hard disk is nominally X G, even when it is completely empty, the capacity displayed by the operating system will be: $X \times 1000 \times 1000 \times 1000 / (1024 \times 1024 \times 1024) \approx X \times 0.931$ G








In addition, if a portion of the hard disk space has been used for some specific purpose, then the capacity indicated by the operating system will be even less than $X \times 0.931$ G.


II. A portion of the hard disk space is used for specific purposes


Lenovo computers may come with preinstalled OneKey Rescue system, so the hard disk has a special portion partitioned before delivery, which is used to store hard disk mirror and OneKey Rescue system program files. The size of the reserved space for this partition varies according to the model, operating system and software of the computer. For the sake of safety, this partition is not apparent, which is commonly referred to as a "hidden partition".


In addition, after the hard disk is partitioned or formatted, the system will assign a certain amount of hard disk space for the system files.

For the above reasons, the available hard disk space indicated by the operating system is always less than the computer's nominal hard disk capacity.























Contents

Important safety information iii Important safety informationiii
Chapter 1. Getting to know your
computer1
Top view1
Left-side view3
Right-side view4
Bottom view5
Chapter 2. Learning the
basics 7
First use7
Using AC adapter and
battery10
Using the touchpad13
Using the keyboard14
Special buttons17
System status indicators19
Securing your computer20
Connecting external devices 22
Using Lenovo Quick Start
(select models only)25
Chapter 3. Using the Internet 27
Wired connection27
Wireless connection29

Chapter 4. OneKey Rescue	
system34	1
OneKey Rescue system34	
Chapter 5. Troubleshooting37	7
Frequently asked questions37	7
Troubleshooting40)
Chapter 6. Upgrading and	
replacing devices48	3
Replacing the battery48	
Replacing the hard disk drive50	
Replacing memory54	ł
Appendix A. Getting help and	
service58	3
Getting help on the Web59	
Calling the customer support	
center59	a
	,
Getting help around the	
world62	_
Lenovo warranty service	
telephone numbers62	2
Appendix B. Use, and care	
Information63	3
Caring your computer63	3
Accessibility and comfort69	
Maintenance71	

















Contents

Appendix C. Lenovo limited
warranty 76
Warranty information 86
Appendix D. Customer replaceable units (CRUs)90
Appendix E. Notices92
Notices92
ENERGY STAR model
information95
Wireless related information 97
Electronic emissions notices 101
WEEE and recycling
statements108
Turkish statement of
compliance108
EU WEEE statements 109
Japan recycling statements 110
Notice for users in the
U.S.A 112
Notice on deleting data from your
hard disk 112

Appendix F. Features and	
specifications	114
Trademarks	116
Index	117














This information can help you safely use your notebook personal computer. Follow and retain all information included with your computer. The information in this document does not alter the terms of your purchase agreement or the Lenovo Limited Warranty. For more information, see "Appendix C. Lenovo limited warranty" on page 76.

Read this first

Personal computers are electronic devices. Power cords, power adapters, and other features can create potential safety risks that can result in physical injury or property damage, especially if misused. The safety risks are categorized as follows:





Physical injury or even death may be caused.

• Attention:


Property damage or even minor injury may be caused.

To protect yourself from hazards and create a safer computer work environment, follow the instructions hereafter.









Unpack



Inspect the covers of the computer and the AC adapter, especially parts with the following labels attached for any crack or damage.






* Danger:


 Hazardous voltage, current, and energy levels are present inside any component that has this label attached.






















Working place



Do NOT use the computer in humid places such as a bathroom. Keep the computer and other parts away from liquids.

Danger:

• An electric shock may be caused by spilled liquid.



Do NOT use the computer during a lightning storm.

Attention:

 Lightning storms may damage the computer and result in an electric shock.




Ensure your computer and other components maintain good ventilation.


Danger:


 Placing the working computer or other parts on a bed, sofa or other flexible surface may block the ventilation slots causing overheating of your computer or other parts and increases the risk of fire.



Turn off wireless devices where they may cause interference, such as in a hospital or at an airport.















Correct usage procedures



Use ONLY the power cord, power adapter and battery pack shipped with the computer. Never use these devices with another product. Be sure the power outlet is suitable for the plug and provides the

correct voltage and current for the product you are using.

Danger:

• An unsuitable power supply may damage your computer and can cause an electric shock or fire.



Do NOT use a power outlet, power cord, power adapter or battery pack that appears to be damaged or corroded.





Do NOT share an electrical outlet with other home or commercial appliances that draw large amounts of electricity.

If power strips are used, the load should NOT exceed the power strip's input rating. Unplug the power cord if there are any cracking, hissing, or popping sounds, or if a strong odor comes from the computer.

Danger:

 Overloading the power supply may cause unstable voltages which might damage the computer, data, attached devices, or even cause a fire.













Do NOT wrap the power cord around the power adapter or other objects.

Do NOT squeeze or pinch the cord, or place heavy objects on it.

• Attention:

 Stressing the cord may cause the cord to fray, crack or crimp which may present a safety hazard.



Avoid keeping your hands, your lap, or any other part of your body in contact with a hot section of the working computer for any extended length of time.

Attention:


 Extended contact with your body, even through clothing, could cause discomfort or even a skin burn.




Do not drop, bump, scratch, hit or place heavy objects on the liquid crystal display (LCD) of your computer.

• Attention:

 Direct contact with liquid crystal material from a broken LCD is hazardous; if contact occurs, rinse with large amount of running water for more than 15 minutes.











Service and upgrades



Do NOT attempt to service a product yourself unless instructed to do so by the customer support center or your documentation.

• Attention:


 DO NOT take risks or attempt to diagnose the situation yourself. Contact the customer support center for further guidance. For a list of service and support phone numbers, go to http://consumersupport.lenovo.com.

Lenovo provides documentation with instructions when it is appropriate for customers to install options or replace units (CRUs). Closely follow all instructions when installing or replacing parts.


Disconnect the attached power cords, battery pack, and all the cables before you open the device covers, unless instructed otherwise in the installation and configuration procedures.

Keep the covers closed whenever the computer is plugged in.













Top view



Note: The illustrations in this manual may differ from the actual product. Please refer to the actual product.







1









Chapter 1. Getting to know your computer

Attention:

Do NOT open the display panel beyond 130 degrees. When closing the display panel, be careful NOT to leave pens or any other objects in between the display panel and the keyboard. Otherwise, the display panel may be damaged.

System status indicators

For details, see "System status indicators" on page 19.

Power button

Press this button to turn on the computer.

Integrated camera

Use the camera for video communication.

Built-in

The built-in microphone (with noise reduction) can be used for video conferencing, voice narration, or simple audio

recordings.

Computer display

The LCD display with LED backlight provides brilliant

visual output.

OneKey Rescue system button

microphone

Press this button to open OneKey Rescue system (If OneKey Rescue system has been preinstalled) when the computer is powered off.

Note: For details, see 'Chapter 4. OneKey Rescue system" on page 34.

Quick Start button

When the computer is powered-off, press this button to enter the Lenovo Quick Start if it has been installed.

One-piece touchpad

The touchpad functions as a conventional mouse with

built-in left-click and right-click buttons.


Note: For details, see "Using the touchpad" on page 13. Wireless module antennas (select models only)

The built-in antennas ensure optimal reception of wireless communication radio.
















Chapter 1. Getting to know your computer

Left-side view



VGA port

Connects to external display devices.

AC power adapter jack Connect the AC adapter here.

Note: For details, see "Using AC adapter and battery" on page 10.

USB port Connects to USB devices.

Note: For details, see "Connecting a universal serial bus (USB) device" on page 24.

Fan louvers Dissipate internal heat.

> Note: Make sure that none of the fan louvers are blocked or else overheating of the computer may occur.


Insert memory cards (not supplied) here. Memory card slot

Note: For details, see "Using memory cards (not supplied)" on page 22.

Integrated wireless device Use this switch to turn on/off the wireless radio of all wireless devices on your computer.

switch












Right-side view



Headphone jack Connects to external headphones.

• Attention:

- · Listening to music at high volume over extended periods of time may damage your hearing.
- Microphone jack Connects to external microphones.
- **USB** port Connects to USB devices.


Note: For details, see "Connecting a universal serial bus (USB) device" on page 24.

RJ-45 port Connects to an Ethernet network.


Note: For details, see "Wired connection" on page 27.


Kensington slot Attach a security lock (not supplied) here.

Note: For details, see "Attaching a security lock (not supplied)" on page 20.














Chapter 1. Getting to know your computer

Bottom view













Chapter 1. Getting to know your computer

Battery latch - The manual battery latch is used to keep the battery pack secured in place.

Speakers The stereo speakers provide rich and powerful sound.

Hard disk/
Memory/Mini PCI
ExpressCard slot
compartment

4 Battery pack For details, see "Using AC adapter and battery" on page 10.


SIM card slot Insert a SIM card (not supplied) for using Mobile Broadband.


only) Notes:

• After removing the battery pack, you can insert a SIM card into this slot.

• For details, see "Using Mobile Broadband (select models only)" on page 31

G Battery latch - The spring-loaded battery latch keeps the battery pack secured in place.













- First use
- Read the manuals

Read the supplied manuals before using your computer.

■ Connect to the power


The supplied battery pack is not fully charged at purchase. To charge the battery and begin using your computer, insert the battery pack and connect the computer to an electrical outlet. The battery is automatically charged while the computer is running on AC power.

Install the battery pack


Refer to the supplied Setup Poster to install the battery pack.

Connect the computer to an electrical outlet

- 1 Connect the power cord to the AC adapter.
- 2 Connect the AC adapter to the AC power adapter jack of the computer.
- 3 Plug the power cord into an electrical outlet.















■ Turn on the computer

Press the power button to turn on the computer.

Configure the operating system

You may need to configure the operation system when it is first used. The configuration process may include the procedures below.

- · Accepting the end user license agreement
- Configuring the Internet connection
- Registering the operating system
- Creating a user account




When you finish working with your computer, you can put it into sleep state or shut it down.

Putting your computer into sleep state


If you will be away from your computer for only a short time, put the computer into sleep state.

When the computer is in sleep state, you can quickly wake it to resume use, and bypass the startup process.




















To put the computer into sleep state, do one of the following.

- Click 🚱 and select **Sleep** from the **Start** menu.
- Press Fn + F1.

Note: Wait until the power indicator light starts blinking (indicating that the computer is in sleep state) before you move your computer. Moving your computer while the hard disk is spinning can damage the hard disk, causing loss of data.


To wake the computer, do one of the following.

- Press the power button.
- Press any key on the keyboard.


Shutting down your computer


If you are not going to use your computer for a day or two, shut it down. To shut down your computer, click 🚱 and select **Shut down** from the **Start** menu.















Using AC adapter and battery

Checking battery status

You can determine the percentage of battery power remaining by checking the battery icon in the notification area.

Note: As each computer user has different habits and needs, it is difficult to predict how long a battery charge will last. There are two main factors:


- The amount of energy stored in the battery when you commence work.
- The way you use your computer: for example, how often you access the hard disk drive and how bright you make the computer display.


Charging the battery

When you find that the battery power is low, you need to charge the battery or replace it with a fully charged one.

You need to charge the battery in any of the following situations:

- When you purchase a new battery
- If the battery status indicator starts blinking
- If the battery has not been used for a long time















Notes:

- You are advised to insert the battery pack when using your computer to prevent small particles from entering the inside of your computer.
- To increase the life of the battery pack, the computer does not start recharging the battery immediately after it drops from fully charged.
- Charge the battery at a temperature between 50 °F and 80 °F (10 °C-30 °C).
- Full charge or discharge is not required.


Removing the battery pack

If you are not going to use the computer for an extended period of time, or if you need to send your computer to Lenovo for service, etc., remove the battery pack from the computer. Before removing the battery pack, make sure the computer has been shut down.



















Handling the battery

If the rechargeable battery pack is replaced with an incorrect type, there may be danger of an explosion. The battery pack contains a small amount of harmful substances. To avoid possible injury and detriment to the environment, pay attention to the following points:

- Replace only with a battery of the type recommended by Lenovo.
- Keep the battery pack away from fire.
- Do not expose the battery pack to water or rain.
- Do not attempt to disassemble the battery pack.
- Do not short-circuit the battery pack.
- Keep the battery pack away from children.
- Do not put the battery pack in trash that is disposed of in landfills. When disposing of the battery, comply with local ordinances or regulations and your company's safety standards.














Using the touchpad





One-piece touchpad

To move the cursor on the screen, slide your fingertip over the pad in the direction in which you want the cursor to move.


Bottom left area

The function corresponds to that of the left mouse button on a conventional mouse, which can be implemented by clicking this area.

Bottom right area

The function corresponds to that of the right mouse button on a conventional mouse, which can be implemented by clicking this area.

Note: You can enable/disable the touchpad using **Fn+F6**.








13







Using the keyboard

Your computer has a numeric keypad and function keys incorporated in its standard keyboard.


Numeric keypad

The keyboard has keys that, when enabled, work as a 10-key numeric keypad.

To enable or disable the numeric keypad, press Fn+Insert.





Note: The **1** indicator will light on if the numeric keypad is enabled.















■ Function key combinations


Through the use of the function keys, you can change operational features instantly. To use this function, press and hold **Fn** 1; then press one of the function keys 2.




















The following describes the features of each function key.


Fn + Esc:	Turn on/off the integrated camera.
Fn + F1:	Enter sleep mode.
Fn + F2:	Turn on/off the LCD screen.
Fn + F3:	Open the interface for the display device switch to select notebook or external display.
Fn + F4:	Open the interface for display resolution settings.
Fn + F5:	Open the interface for integrated wireless devices settings (enable/disable).
Fn + F6:	Enable/Disable the touchpad.
Fn + F7:	Start/Pause playback of Windows Media Player.
Fn + F8:	Stop playback of Windows Media Player.
Fn + F9:	Skip to the previous track.
Fn + F10:	Skip to the next track.
Fn + F11:	Activate the F12 function. * You can press Fn+F11 during computer startup to open the boot selection menu.
Fn + PrtSc:	Activate the system request.
Fn + Pause:	Activate the break function.
Fn + Insert:	Enable/Disable the numeric keypad.
Fn + Delete:	Enable/Disable the Scroll Lock.
Fn + ↑ / ↓ :	Increase/Decrease display brightness.
Fn + → /←:	Increase/Decrease volume level.









Special buttons


















OneKey Rescue system button

- When the computer is powered off, press this button to enter the OneKey Rescue system if Lenovo OneKey Rescue system has been preinstalled.
- Under Windows operating systems, press this button to start Lenovo OneKey Recovery.

Note: For details, see "OneKey Rescue system" on page 34.


Quick Start button


• When the computer is powered-off, press this button to enter Lenovo Ouick Start if it has been installed.

Note: For details, see "Using Lenovo Quick Start (select models only)" on page 25.

· Under Windows operating systems, press this button to launch a selfdefined program, file or a Website.

Note: To re-define the Quick Start button, select Self-defined program setting $(start \rightarrow All\ Programs \rightarrow Lenovo \rightarrow Energy\ Management \rightarrow Self-defined$ program setting).














System status indicators

These indicators inform you of the computer status.




- Caps lock indicator 🕸
- Power status indicator ()
- Battery status indicator —
- Wireless communication indicator
- Hard disk drive indicator ⊕















Securing your computer

This section provides information about how to help protect your computer from theft and unauthorized use.


Attaching a security lock (not supplied)


You can attach a security lock to your computer to help prevent it from being removed without your permission. For details on installing the security lock, please refer to the instructions shipped with the security lock that you have purchased.

Refer to the "Right-side view" on page 4 for the location of the Kensington slot.

Notes:

- Before purchasing any security product, verify that it is compatible with this type of security keyhole.
- You are responsible for evaluating, selecting, and implementing the locking devices and security features. Lenovo offers no comment, judgement, or warranty regarding the function, quality or performance of locking devices and security features.
















■ Using VeriFace[™]

VeriFace is a face recognition software which takes a digital snapshot, extracts key features of your face, and creates a digital map that becomes the system's "password".

If you want to activate VeriFace for the first time, click the VeriFace icon on the desktop to register your facial image.

Notes:

- The face registration and verification works best in an environment with steady and even light.
- You can determine whether to use this function when you log on the system.

For more instructions on VeriFace, see the help file on your software.


Using passwords

Using passwords helps prevent your computer from being used by others. Once you set a password and enable it, a prompt appears on the screen each time you power on the computer. Enter your password at the prompt. The computer cannot be used unless you enter the correct password.

Note: This password can be from one to seven alphanumeric characters in any combination.

For details about how to set the password, see the help to the right of the screen in **BIOS Setup Utility**.

Note: To enter **BIOS Setup Utility**, press **F2** when the Lenovo logo appears on the screen while the computer is starting up.







21









Connecting external devices

Your computer has a wide range of built-in features and connection capabilities.

■ Using memory cards (not supplied)


Your computer supports the following types of memory cards:


- Secure Digital (SD) card
- High Capacity Secure Digital (SDHC) card
- MultiMediaCard (MMC)
- Memory Stick (MS)
- Memory Stick PRO (MS PRO)

Notes:

- Insert ONLY one card in the slot at a time.
- This card reader does not support SDIO devices (e.g., SDIO Bluetooth, etc.).



















- Inserting a memory card
 - Push the dummy card until you hear a click. Gently pull the dummy card out of the memory card slot.

Note: The dummy card is used for preventing dust and small particles from entering the inside of your computer when the memory card slot is not in use. Retain the dummy card for future use.


- 2 Slide the memory card in until it clicks into place.
- Removing a memory card
 - Push the memory card until you hear a click.
 - Gently pull the memory card out of the memory card slot.

Note: Before removing the memory card, disable it via Windows safely remove hardware and eject media utility to avoid data corruption.

















Connecting a universal serial bus (USB) device

Your computer comes with three USB ports compatible with USB devices.

Note: When using a high power consumption USB device such as USB ODD, use the external device's power adapter. Otherwise, the device may not be recognized, and system shut down may result.

Connecting a *Bluetooth* enabled device (select models only)

If your computer has an integrated *Bluetooth* adapter card, it can connect to and transfer data wirelessly to other *Bluetooth* enabled devices, such as notebook computers, PDAs and cell phones. You can transfer data between these devices without cables at up to 10 meters range in open space.


Note: The actual maximum range may vary due to interference and transmission barriers. To get the best possible connection speed, place the device as near your computer as possible.


Enabling *Bluetooth* communications on your computer

- 1 Slide the integrated wireless device switch to .
- Press Fn + F5 to make configuration.

Notes:

- When you do not need to use the *Bluetooth* function, turn it off to save battery power.
- You need to pair the *Bluetooth* enabled device with your computer before you can transfer data between them. Read the documentation supplied with the Bluetooth enabled device for details on how to pair the device with your computer.
















Using Lenovo Quick Start (select models only)


With a boot time of just a few seconds, Lenovo Quick Start offers a handy environment that allows you to enjoy an instant access to functions such as Web browsing, instant messaging and other entertainment functions without entering the traditional operating system.

Notes:


- If Lenovo Quick Start is not installed, a prompt notice will appear on the screen when you start it.
- · The Web browser of Lenovo Quick Start is designed for you to get an instant access to online information and does not fully support video streaming. You may experience low frame rate when watching online video in Lenovo Quick Start. To view online video, restart the computer to your Windows operating system and use Internet Explorer to play the online video.













Starting Lenovo Quick Start


Press the QS button when the computer is powered-off. The following will appear on the screen after a few seconds.






Exiting Lenovo Quick Start

- ullet Click ullet to restart the computer.
- Click \circlearrowleft to turn off the computer.

















As a global network, the Internet connects computers worldwide, providing services such as e-mailing, information searching, electronic commerce, Web browsing and entertainment.


You can connect the computer to the Internet in the following ways: Wired connection: uses physical wiring to connect. Wireless network technology: connect without wiring.

Wired connection


Wired connections are a reliable and safe way to connect the computer to the Internet. Generally, the following two accessing methods are widely used.

Cable	Cable Internet services use a cable modem connected to the residential cable TV line.
DSL	DSL is a family of related technologies that bring high-speed network access to homes and small businesses over ordinary telephone lines.












Chapter 3. Using the Internet

Hardware connection:







Note: The above diagrams are for reference only. Actual connection method may vary.

Software configuration

Consult your Internet Service Provider (ISP) for details on how to configure your computer.



















Wireless connection

Wireless connections provide mobile access to the Internet, allowing you to stay online anywhere the wireless signal covers.


Divided by the signal scales, wireless connection to the Internet can be built based on the following standards.


Wi-Fi	Wi-Fi networks cover a small physical area, like a home, office, or small group of buildings. An access point is necessary for the connection.
WiMAX	WiMAX networks connect several Wireless LAN systems to cover a metropolitan area, providing high-speed broadband access without the need for cables.
Mobile Broadband	The Mobile Broadband network provides Internet access to computers, cell phones and other devices over a large geographic area. Mobile networks are used for data transmission, and access is usually provided by a mobile network operator. A Mobile Broadband SIM card is necessary for the connection.

Note: Your computer may not support all wireless connection methods.













Chapter 3. Using the Internet


■ Using Wi-Fi/WiMax (select models only)

Enabling wireless connection

To enable wireless communications, do the following:

- 1 Slide the integrated wireless device switch to (<u>m</u>).
- 2 Press Fn + F5 to make configuration.


Hardware connection




^{*} Not supplied

Software configuration

Consult your Internet Service Provider (ISP) and search Windows Help and Support Center for details on how to configure your computer.















Chapter 3. Using the Internet

Using Mobile Broadband (select models only)

Before getting started with Mobile Broadband, you first need to choose a mobile network operator and make sure you are in the coverage area of the network. After that, you also need:

• To activate the Mobile Broadband service through your local mobile network operator. You will get a Subscriber Identity Module (SIM) card after activation. For instructions on inserting the SIM card, refer to "Inserting the SIM card" on page 32.

Notes:

- Various standards are in use by mobile operators to provide Mobile Broadband services. The Lenovo Mobile Broadband module may support one or more of the following standards:
 - GSM (Global System for Mobile Communications)
 - TD-SCDMA (Time Division-Synchronous Code Division Multiple Access)
 - SCDMA (Synchronous Code Division Multiple Access)
 - EV-DO (Evolution Data Optimized)
 - HSPA (High Speed Packet Access)
- Mobile Broadband is a subscription service. Refer to your local mobile network operator for availability, cost and other information.
- A SIM card is a type of smart card used by mobile network operators to identify their service subscribers on the mobile network. You will get the SIM card from your mobile network operator after you have activated the Mobile Broadband service.

