

AIRE M93 ICE

Anywhere Wireless Mouse

User's Manual



Product Information

GIGABYTE

Model No.: GM-AIRE M93 ICE

Model Name : Anywhere Wireless Mouse

Receiver Model No.: 28713C55RX

Model Name: Wireless Receiver

All other brands and trademarks are the properties of their respective owners.

The product specifications are subject to change without notice.

Introduction

Congratulations on your purchase of the most innovative wireless laser mouse. With an incredible sensitivity to surface details and high tracking speed than other mice, the wireless laser mouse can track reliably on tricky wood-grain and/or shiny surfaces. It is much more advanced than you imagine and will make you more productive and comfortable.

Features

- Auto link, plug-and-play!
- Rechargeable battery with micro USB port
- 2.4GHz, 1200/ 2000 DPI adjustable
- Nano receiver
- Laser tracking engine with high tracking speed and sensitivity
- Power on/off , DPI, and GIGABYTE Free-Scrolling Technology™ switch

Hardware Installation

1. Insert batteries
 - a. Remove the battery compartment cover in the case
 - b. Fit in the batteries accordingly to the diagram indicated in the battery cabinet
 - c. Close the battery compartment cover properly
 - d. Make sure the Power on-off switch on the mouse in ON
 - e. The LED on the bar will blink 3 seconds if the mouse power is on

Warning: A wrong battery placement may cause batteries overheat

△ Note

The unit offers a strong power saving management. Once the mouse accesses sleeping mode, to clip any key on the mouse is compulsory to wake it up.

Power on/off: There is a power on/off switch designed to save the batteries power while non-usage of a longer period.

Connect the Receiver

1. Turn on your PC
2. Connect the receiver to USB on PC

Communication: The mouse & the Receiver

The 2.4GHz RF mouse features a dual-way transmission technology which enables the mouse and the receiver auto-communication.

Auto-link mode

1. Make sure the Power On/Off switch on the mouse is ON
2. Operate the mouse, and cursor's movement is mapping mouse movement. Now the mouse and the receiver is auto-linked successfully.

△Note

While the mouse is working, if encountering any interference, the mouse and the receiver will automatically source out and transfer to another channel. During transferring, the cursor movement may have a second delay.

Replace the new batteries

Please replace new batteries and follow the previous instructions.

△Note

The red LED on the scroll wheel is the low batteries power indicator. It indicates that batteries inside the mouse are needed to be replaced.

Charge the batteries

1. There is a micro-USB nano-receiver. Use the micro-USB line in the box to charge the batteries by plugging the other side into the USB port. The BLUE indicator light will start to blink to show that the battery is charging.
2. Charge your keyboard until the indication light stops blinking.
3. The red LED light indicates that batteries inside needs to be re-charged.

Trouble Shooting

1. Make sure you have connected the receiver correctly on the PC's USB port
2. For the best performance, we suggest you to locate the receiver with a distance from other electric devices, such as the computer monitor or external storage devices
3. Make sure you have set the communications between the receiver and the mouse. Refer to the communication section.
4. If you find the communication channel does not work well, you may use the software connection tool to re-connect the mouse & receiver and reset a new channel ID. You are able to get to software on the website.
5. Some system devices might conflict with the mouse. Confirm the IRQ/address settings of these devices for conflicts, and change the settings as required.
6. Make sure that you are not working the mouse on glossy or reflective surfaces.

Battery use reminders

1. Remove worn-out batteries from equipment immediately and dispose of promptly
2. Keep all batteries (used or new) out of the reach of children
3. To have the batteries with a regular check and replace new batteries if not used for a long time
4. Never dispose of batteries in fire, as they could explode
5. Always replace all the batteries at the same time. Mixing old and new batteries or mixing types (such as alkaline with zinc carbon) will reduce overall performance and could cause leakage or rupture
6. Do not mix different types of batteries (e.g. ni MH, NiCd, alkaline, and etc) in the mouse
7. Remove batteries from the electrical device if the device is not going to be used for a long time
8. If the performance of the batteries decreases substantially, it is time to replace the batteries

Rechargeable battery notice

Danger

Do not attempt to disassemble or modify the battery pack. Attempting to do so can cause an explosion, or liquid leakage from the battery pack. A battery pack other than the one specified, or a disassembled or modified battery pack is not covered by the warranty.

FCC Statement

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example-use only shielded interface cables when connecting to computer or peripheral devices).

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference. and
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
-



This symbol on the product or in the instructions means that your electrical and electronic equipment should be disposed at the end its life separately from your household waste. There are separate collection system for recycling in the EU.

For more information, please contact the local authority or your retailer where you purchased the product.