

BenQ N338 Wireless Ultra Portable Optical Mouse

User's Guide

Important Health Information

Certain repetitive strain injuries, including pain, numbness and weakness to hands, wrists, arms, neck and/or back have been identified by some experts as being associated with the prolonged use of the mouse. If you are experiencing injury symptoms, consult a medical professional. A person's susceptibility to these injuries may be affected by many factors, including body posture, repetitive physical activities and general physical health. For more information, please visit <http://www.BenQ.com/products/comfort>.

Package Contents

1. BenQ P600 Wireless Ultra Portable Optical Mouse
2. BenQ Wireless USB Mini Receiver
3. 2 x AAA Alkaline Batteries
4. User's Guide

System Requirements

- IBM® Compatible System
- Microsoft Windows® 98SE, 2000, Me, XP or Mac® OS X v10.4
- An Available USB Port

Battery Installation


Step 1: Remove the battery cover.

Step 2: Place 2 AAA alkaline batteries into the battery compartment as indicated.

Step 3: Lock the battery cover back into its place.


NOTE:

1. You will find 2 AAA alkaline batteries for the mouse included in this package. If you need to replace the batteries in the future, make sure that you use new batteries and that you change all of the batteries at the same time.
2. Please follow the diagram for battery installation direction. It is recommended to use 2 AAA alkaline batteries. Ensure battery polarity matches the polarity markings on the battery compartment.



Hardware Installation

Step 1: Press the front wireless USB mini receiver eject button located on the battery cover as indicated, then pull out and remove the wireless USB mini receiver from the mouse.



Step 2: With your computer turned on, plug the wireless USB mini receiver into an available USB port on your computer.

Step 3: The system will automatically detect the new hardware and install the device ready for use.

Step 4: Proceed to 'Establishing a Wireless Connection' to complete the installation.


Establishing a Wireless Connection

Once the wireless USB mini receiver is connected to your PC, a wireless connection will need to be established between it and the mouse. Please perform the following steps in order to establish a proper wireless connection:

Step 1: Be sure to power on the power switch of mouse base.

Step 2: Ensure the mouse and wireless USB mini receiver are set up as described in '**Battery Installation**' and '**Hardware Installation**'.

Step 3: Press the **CONNECT** button on the wireless USB mini receiver, then press the **CONNECT** button on the mouse base.



NOTE:

1. To ensure correct operation, please make sure that the wireless USB mini receiver is properly installed at least 20 cm (8 inches) away from electromagnetic devices such as monitors or speakers. Also please make sure that the wireless USB mini receiver is installed at least no more than 1 meter away from the mouse.
2. If the mouse does not activate, please repeat Step 2 and 3.
3. It is also necessary to repeat Step 2 and 3 after any loss of power from battery replacement.

Multiple Power-Saving Modes

- The mouse can be manually set to sleep mode by simultaneously pressing all three buttons (both the Left and Right mouse buttons and the Scroll Wheel button at the

same time). Press any mouse button to resume normal mouse operation.

- This mouse will go into an automatic sleep mode after it has not been used for a period of time. Also press any button to go back to its working mode.
- When the wireless USB mini receiver is stored in the smart receiver storage compartment, the mouse will go into an automatic sleep mode.
- Simply power off the power switch on mouse bottom.

Warranty Information

- One year parts/labor from the date of purchase.
- Please refer to the Warranty Terms and Conditions for your local region for further warranty details.
- For more information, please visit: www.BenQ.com.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

CAUTION:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.