
IEEE 802.11b/g/n

Micro 11bgn 1x1 150Mbps Wireless Client Dongle

Model: WL-6200-V3

USER'S GUIDE

VERSION 1.2



© All rights reserved.

All trade names are registered trademarks of respective manufacturers listed.

This manual may not be copied in any media or form without the written consent of original maker.

TABLE OF CONTENTS

Information To User
1. Introduction 1
2. Wireless LAN Basics
3. IP ADDRESS 4
4. Install Driver/Utility 5
4.1 Windows XP/Vista/Win7 / 8 / 8.15
5. Wireless Network Configuration
5.1 Utility Icon
6. Technical Specifications
7. Troubleshooting
8. Glossary

INFORMATION TO USER

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- * Reorient or relocate the receiving antenna.
- * Increase the separation between the equipment and receiver.
- * Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- * Consult the dealer or an experienced radio/TV technician for help.

REGULATION INFORMATION

The Micro 11bgn 1x1 150Mbps Wireless Client Dongle must be installed and used in strict accordance with the manufacturer's instructions. This device complies with the following radio frequency and safety standards.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC RF Radiation Exposure Statement:

The product comply with the FCC portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.

Your device contains a low power transmitter. When device is transmitted it sends out Radio Frequency (RF) signal. Use only with supplied antenna. Unauthorized antenna, modification, or attachments could damage the transmitter and may violate FCC regulations.

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

The use of the USB dongle with laptops/notebooks is prohibited.

Europe- R&TTE Compliance StatementHereby, the company who declares that this equipment complies with the essential requirements and other relevant provisions of DIRECTIVE 1999/5/CE OF THE EUROPEAN PARLIAMENT AND THE COUNCIL of March 9, 1999 on radio equipment and telecommunication terminal Equipment and the mutual recognition of their conformity (R&TTE).

	CE DE	ciaration of Comornity	
For the following	ng equipment:		
Micro 11bgn 1x	<1 150Mbps Wireless	Client Dongle	
(Product Name	e) Micro 11bgn 1x1 1	50Mbps Wireless Client Do	ongle
(Model Design	ation)		-
parliament) Dire Electromagneti evaluation rega EN 300 328 V	ective on the Approxi c Compatibility of Ra rding this Directive, t I.8.1	h the requirements set out mation of the Laws of the I dio and Telecom device (1) he following standards were	Member States relating to 999/5/EC). For the
	V1.8.1 ; EN 301 489	-17 V2.1.1	
EN 60950-1:20)06+A11:2009		_
			_
This equipment is r community.	narked with the $oldsymbol{(}oldsymbol{(}oldsymbol{)}$	symbol and can be used t	throughout the European
To comply with RF		e requirements, for mobile	configurations, a separation na of this device and all persons.
This device is intental Austria Denmark Germany Italy Lithuania Portugal	ded for use as check Belgium Estonia Greece Iceland Malta Poland Slovenia	c in the following European Czech Republic France Hungary Luxemburg Norway Spain	☐Cyprus ☐Finland ☐Ireland ☐Latvia ☐Netherlands ☐Sweden

The channel identifiers, channel center frequencies, and regulatory domains of each 22-MHz-wide channel are shown in following Table.

	Frequency	Regulatory Domains				
Channel Identifier	innel	Japan	ETSI	North America	Israel	Mexico
1	2412	•	•	•		
2	2417	•	•	•		
3	2422	•	•	•	•	
4	2427	•	•	•	•	
5	2432	•	•	•	•	
6	2437	•	•	•	•	
7	2442	•	•	•	•	
8	2447	•	•	•	•	
9	2452	•	•	•	•	
10	2457	•	•	•		•
11	2462	•	•	•		•
12	2467	•				
13	2472	•	•			
14	2484					



INTRODUCTION

Thank you for your purchase of the WLAN Adapter. Featuring wireless technology, this wireless networking solution has been designed for both large and small businesses, and it is scalable so that you can easily add more users and new network features depending on your business scale.

FEATURES

Support Microsoft XP(32bit/64bit) / Vista(32bit/64bit) / Win7 / 8 / 8.1(32bit/64bit).

Operating distance of up to 150 meters in free space.

150/120/90/60/54/48/36/30/24/22/18/12/11/6/5.5/2/1 Mbps selectable Data Rate.

64/128-bit WEP, WPA (Wi-Fi Protected Access), WPA2

2.400GHz ~ 2.4835GHz unlicensed ISM Frequency Band.

Modulation Method:

IEEE 802.11b: DSSS (Direct Sequence Spread Spectrum).

IEEE 802.11g / 802.11n : OFDM (Orthogonal Frequency Division

Multiplexing). Easy operation and setting up.

SYSTEM REQUIREMENTS

Windows System: XP(32bit/64bit) / Vista(32bit/64bit) / Win7 / 8 / 8.1(32bit/64bit).

System must have a device driver installed. It allows you to communicate with Micro 11bgn 1x1 150Mbps Wireless Client Dongle.

BEFORE YOU START

- 1. Confirm Box Contents
- ♦ Micro 11bgn 1x1 150Mbps Wireless Client Dongle
- Quick Start Guide
- ◆ Driver CD

CONNECTING YOUR Micro 11bgn 1x1 150Mbps Wireless Client Dongle

Quick Start Guide

Connect your Micro 11bgn 1x1 150Mbps Wireless Client Dongle. Install driver.

GETTING TO KNOW WIRELESS LAN ADAPTER

LED

LED turns on when WLAN link to WLAN adaptor or AP.

LED is blinking when WLAN Adapter is active.




WIRELESS LAN BASICS


Wireless LAN network defined by IEEE 802.11b/g standard committee could be configured as :

Ad Hoc wireless LAN.
Infrastructure wireless LAN.

Ad Hoc network is a group of wireless LAN cards, this group is called a BSS (Basic Service Set). This group can use their wireless LAN cards to communicate with each other, but can not connect to the **Internet**.



Ad Hoc Wireless Network



Infrastructure Wireless Network

The most obvious difference between **Infrastructure** wireless network and **Ad Hoc** wireless network in **Infrastructure** wireless network can access the resource in the Internet through **Access Point**.

Depending on your requirement, you can easily set up your system network to be a "Ad Hoc" or "Infrastructure" wireless network. Generally speaking, if in your network, there is an Access Point in it, we recommend you to set your network as an "Infrastructure", so it can connect to the Internet.




IP ADDRESS

The installation & driver CD will automatically activate the autorun installation program after you insert the disk into your CD drive.


Step 1: (Win7/8/8.1 only)

Insert the installation CD into your CD-ROM. Win7/8 UAC Dialog is shown. Click **Yes** to continue.




Step 2:

Preparing Setup dialog is shown



Step 3:

Wizard is ready to install driver and utility. Click **Next** to begin the installation



Installing & configuring WLAN driver and utility



Installing Cisco 802.1x module



Step 4:

Click **Finish** to complete installation. The installation will affect after windows rebooting





Micro 11bgn 1x1 150Mbps Wireless Client Dongle uses its own management software. All functions controlled by users are provided by this application. When you insert the WLAN Adapter into your laptop or desktop, a icon should appear in the Windows System Tray automatically.

5.1 Utility Icon

Client mode utility running but no WLAN Adapter plugged



■ Client mode utility running and WLAN Adapter scan available network.



Client mode utility running and WLAN Adapter can not scan any AP



5.2 Client Mode (Default Setting)

Show Tray Icon	Disable Adapter
Radio Off	Virtual WiFi allowed

Wireless Device Control:


- Show Tray Icon Show icon or not show icon in system tray.
- Radio Off To stop wireless signal.
- Disable Adapter To stop wireless device.
- Virtual WiFi allowed To enable Soft AP

5.2.1 GENERAL SETTING

Once device is set, double click on that icon and the configuration window will pop up as shown. It shows the current connected network.

The signal strength and link quality are displayed also.

The bar graph displays the quality and strength of the link between the node and its Access




Point. Link Quality is a measurement of receiving and transmitting performances over the radio.

Network Address displays current MAC Address, IP Address, Subnet. and Gateway.

Click **Renew IP** button to refresh IP address leased from wireless AP.

5.2.2 PROFILE SETTING

In profile tab, you can
Add, Remove, Edit,
Duplicate and Set
Default to manipulate
profile content
manually. Strongly
recommend to use
profile after you do
Available Network.




5.2.3 AVAILABLE NETWOEK SETTING

Click Available

Network tab and it will show all available networks that radio can reaches. Select proper SSID & BSSID you want to connect. Click Refresh button to force and rescan available networks currently.


Select one of SSIDs, and click Add to Profile to create profile that can be configured more wireless parameters.
In this page, you can edit your profile name, configure wireless security like WEP, WPA, WPA2, 802.1x ...etc. After finishing setup, click OK button to save configuration





5.2.4 Status

Dialog shows
Manufacture, NDIS
Driver Version, Short
Radio Header,
Encryption,
Authentication,
Channel Set, Mac
Address... etc
information



5.2.5 Wi-Fi Protected Setup


An easy and secure setup solution for Wi-Fi network. you can choose PIN Code or Push Button method to connect to an AP.



■ Pin method:

Step 1:

Press "Pin Input Config (PIN)" button.




Step 2:

Select a specific AP




Step 3:

Enter the PIN code into your AP.



Step 4:

Select AP that you want to configure.



Step 5:


Wait for configuring your wireless AP to be the security setting.



■ PBC method:


Step 1:

Press "Push Button Config (PBC)" button



Step 2:

Push the physical button on our AP or visual button on he WPS configuration page.



Push Button Config (PBC)

Cancel

5.3 Virtual WiFi Setup


Step 1:

Click "Virtual WiFi allowed" option to enable Virtual WiFi configuration / status page.




Step 2:

Click "Start Virtual WiFI Soft AP" option to start



Step 3:

Click "Config" button to configure Soft AP SSID and Security Key.



Step 4:

To check "Setting Internet Connection Sharing" and "Auto Select Public Network" options to enable ICS. If setup up Shared Network manually, press "Apply" button to re-initialization ICS.



TECHNICAL SPECIFICATIONS

Product Name	Micro 11bgn 1x1 150Mbps Wireless Client Dongle	
Standard	802.11b/g/n	
Data Transfer Rate	1,2,5.5,6,11,12,18,22,24,30,36,48,54,60,90,120, and maximum of 150Mbps	
Modulation Method	BPSK/ QPSK/ 16-QAW/ 64-QAW/ DBPSK/ DQPSK/ CCK	
Frequency Band	2.4GHz ISM Band	
Spread Spectrum	IEEE 802.11b: DSSS (Direct Sequence Spread Spectrum) IEEE 802.11g/n:OFDM (Orthogonal Frequency Division Multiplexing)	
RF Output Power (tolerance ± 2dBm)	13dBm@11n, 15dBm@11g, 17dBm@11b	
Operation Mode	Ad hoc, Infrastructure	
Receiver Sensitivity	11Mbps -80dBm@8%,54Mbps -70dBm@10%,150Mbps -64dBm@10%	
Operation Range	Indoor up to 100 meters, Outdoor up to 180 meters	
LED	Power	
OS Support	Windows XP /Vista /7/8, Mac, Linux	
Security	64 bit/128 bit WEP, TKIP, AES, WPA, WPA2	
Interface	USB 2.0	
Power Consumption	DC 5V Transmit: around 125 mA Receive: around 68 mA Transmit+Receive: around 105 mA	
Operating Temperature	-10 - 60° C ambient temperature	
Storage Temperature	-20 ~ 70°C ambient temperature	
Humidity	5 to 90 % maximum (non-condensing)	
Dimension	17x15x8mm (LxWxH)	
PCBA Dimension	14.5 x 11.3 x 0.6mm	



TROUBLESHOOTING

Symptom:

The LED is off.

Remedy:

Make sure the dongle is inserted properly. Otherwise contact your vendor.

Symptom:

The LED is always on not blinking.

Remedy:

Make sure that you have installed the driver from attached CD. Otherwise contact your vendor.

Symptom:

The LED is blinking but the icon does not appear in your icon tray.

Remedy:

Make sure that you have installed the Utility from the attached CD.

Symptom:

The dongle is linking, but can't share files with others.

Remedy:

Make sure the **file and printer sharing** function is enabled. You can enable the function by checking the icon of **My Computer** -> **Control Panel** -> **Network** -> **file and printer sharing** -> **I want to be able to give others to access to my files**.

Symptom:

Slow or poor performance under AP mode

Remedy:

Try to select another channel for the communicating group or move your device closer to the Access Point.



GLOSSARY

IEEE 802.11 Standard

The IEEE 802.11 Wireless LAN standards subcommittee, which is formulating a standard for the industry.

Access Point

An internetworking device that seamlessly connects wired and wireless networks together.

Ad Hoc

An Ad Hoc wireless LAN is a group of personal computers, each with a WLAN adapter, connected as an independent wireless LAN. Ad Hoc wireless LAN is applicable at a departmental scale for a branch or SOHO operation.

BSSID

A specific Ad Hoc LAN is called a Basic Service Set (BSS). Personal computers in a

BSS must be configured with the same BSSID.

DHCP

Dynamic Host Configuration Protocol - a method in which IP addresses are assigned by server dynamically to clients on the network. DHCP is used for Dynamic IP Addressing and requires a dedicated DHCP server on the network.

Direct Sequence Spread Spectrum

This is the method the wireless cards use to transmit data over the frequency spectrum. The other method is frequency hopping. Direct sequence spreads the data over one frequency range (channel) while frequency hopping jumps from one narrow frequency band to another many times per second.

ESSID

An Infrastructure configuration could also support roaming capability for mobile workers. More than one BSS can be configured as an Extended Service Set (ESS). Users within an ESS could roam freely between BSSs while served as a continuous connection to the network wireless stations and Access Points within an ESS must be configured with the same ESSID and the same radio channel.

Ethernet

Ethernet is a 10/100Mbps network that runs over dedicated home/office wiring. Users must be wired to the network at all times to gain access.

Gateway

A gateway is a hardware and software device that connects two dissimilar

systems, such as a LAN and a mainframe. In Internet terminology, a gateway is another name for a router. Generally a gateway is used as a funnel for all traffic to the Internet.

IEEE

Institute of Electrical and Electronics Engineers Infrastructure

An integrated wireless and wired LAN is called an Infrastructure configuration. Infrastructure is applicable to enterprise scale for wireless access to central database, or wireless application for mobile workers.

ISM Band

The FCC and their counterparts outside of the U.S. have set aside bandwidth for unlicensed use in the so-called ISM (Industrial, Scientific and Medical) band. Spectrum in the vicinity of 2.4 GHz, in particular, is being made available worldwide. This presents a truly revolutionary opportunity to place convenient high-speed wireless capabilities in the hands of users around the globe.

Local Area Network (LAN)

A LAN is a group of personal computers, each equipped with the appropriate network adapter card connected by cable/air, that share applications, data, and peripherals. All connections are made via cable or wireless media, but a LAN does not use telephone services. It typically spans a single building or campus.

Network

A network is a system of personal computers that is connected. Data, files, and messages can be transmitted over this network. Networks may be local or wide area networks.

Protocol

A protocol is a standardized set of rules that specify how a conversation is to take place, including the format, timing, sequencing and/ or error checking.

SSID

A Network ID unique to a network. Only clients and Access Points that share the same SSID are able to communicate with each other. This string is case-sensitive.

Static IP Addressing

A method of assigning IP addresses to clients on the network. In networks with Static IP address, the network administrator manually assigns an IP address to each personal computer. Once a Static IP address is assigned, a personal computer

uses the same IP address every time it reboots and logs on to the network, unless it is manually changed.

Temporal Key Integrity Protocol (TKIP)

The Temporal Key Integrity Protocol, pronounced tee-kip, is part of the IEEE 802.11i encryption standard for wireless LANs. TKIP is the next generation of WEP, the Wired Equivalency Protocol, which is used to secure 802.11 wireless LANs. TKIP provides per-packet key mixing, a message integrity check and a re-keying mechanism, thus fixing the flaws of WEP.

Transmission Control Protocol / Internet Protocol (TCP/IP)

TCP/IP is the protocol suite developed by the Advanced Research Projects Agency (ARPA). It is widely used in corporate Internet works, because of its superior design for WANs. TCP governs how packet is sequenced for transmission the network. The term "TCP/IP" is often used generically to refer to the entire suite of related protocols.

Transmit / Receive

The wireless throughput in Bytes per second averaged over two seconds.

Wi-Fi Alliance

The Wi-Fi Alliance is a nonprofit international association formed in 1999 to certify interoperability of wireless Local Area Network products based on IEEE 802.11 specification. The goal of the Wi-Fi Alliance's members is to enhance the user experience through product interoperability. The organization is formerly known as WECA.

Wi-Fi Protected Access (WPA)

The Wi-Fi Alliance put together WPA as a data encryption method for 802.11 wireless LANs. WPA is an industry-supported, pre-standard version of 802.11i utilizing the Temporal Key Integrity Protocol (TKIP), which fixes the problems of WEP, including using dynamic keys.

Wide Area Network (WAN)

A WAN consists of multiple LANs that are tied together via telephone services and / or fiber optic cabling. WANs may span a city, a state, a country, or even the world.

Wired Equivalent Privacy (WEP)

Now widely recognized as flawed, WEP was a data encryption method used to protect the transmission between 802.11 wireless clients and APs. However, it used the same key among all communicating devices. WEP's problems are well-known, including an insufficient key length and no automated method for distributing the keys. WEP can be easily

cracked in a couple of hours with off-the-shelf tools.

Wireless LAN (WLAN)

A wireless LAN does not use cable to transmit signals, but rather uses radio or infrared to transmit packets through the air. Radio Frequency (RF) and infrared are the commonly used types of wireless transmission. Most wireless LANs use spread spectrum technology. It offers limited bandwidth, usually under 11Mbps, and users share the bandwidth with other devices in the spectrum; however, users can operate a spread spectrum device without licensing from the Federal Communications Commission (FCC).

Fragment Threshold

The proposed protocol uses the frame fragmentation mechanism defined in IEEE 802.11 to achieve parallel transmissions. A large data frame is fragmented into several fragments each of size equal to fragment threshold. By tuning the fragment threshold value, we can get varying fragment sizes. The determination of an efficient fragment threshold is an important issue in this scheme. If the fragment threshold is small, the overlap part of the master and parallel transmissions is large. This means the spatial reuse ratio of parallel transmissions is high. In contrast, with a large fragment threshold, the overlap is small and the spatial reuse ratio is low. However high fragment threshold leads to low fragment overhead. Hence there is a trade-off between spatial re-use and fragment overhead.

Fragment threshold is the maximum packet size used for fragmentation. Packets larger than the size programmed in this field will be fragmented If you find that your corrupted packets or asymmetric packet reception (all send packets, for example). You may want to try lowering your fragmentation threshold. This will cause packets to be broken into smaller fragments. These small fragments, if corrupted, can be resent faster than a larger fragment. Fragmentation increases overhead, so you'll want to keep this value as close to the maximum value as possible.

RTS (Request To Send) Threshold

The RTS threshold is the packet size at which packet transmission is governed by the RTS/CTS transaction. The IEEE 802.11-1997 standard allows for short packets to be transmitted without RTS/CTS transactions. Each station can have a different RTS threshold. RTS/CTS is used when the data packet size exceeds the defined RTS threshold. With the CSMA/CA transmission

mechanism, the transmitting station sends out an RTS packet to the receiving station, and waits for the receiving station to send back a CTS (Clear to Send) packet before sending the actual packet data. This setting is useful for networks with many clients. With many clients, and a high network load, there will be many more collisions. By lowering the RTS threshold, there may be fewer collisions, and performance should improve. Basically, with a faster RTS threshold, the system can recover from problems faster. RTS packets consume valuable bandwidth, however, so setting this value too low will limit performance.

Beacon Interval

In addition to data frames that carry information from higher layers, 802.11 includes management and control frames that support data transfer. The beacon frame, which is a type of management frame, provides the "heartbeat" of a wireless LAN, enabling stations to establish and maintain communications in an orderly fashion. Beacon Interval represents the amount of time between beacon transmissions. Before a station enters power save mode, the station needs the beacon interval to know when to wake up to receive the beacon (and learn whether there are buffered frames at the access point).

Preamble Type

There are two preamble types defined in IEEE 802.11 specification. A long preamble basically gives the decoder more time to process the preamble. All 802.11 devices support a long preamble. The short preamble is designed to improve efficiency (for example, for VoIP systems). The difference between the two is in the Synchronization field. The long preamble is 128 bits, and the short is 56 bits.

WPA2

It is the second generation of WPA. WPA2 is based on the final IEEE 802.11i amendment to the 802.11 standard.

Temporal Key Integrity Protocol (TKIP)

The Temporal Key Integrity Protocol, pronounced tee-kip, is part of the IEEE 802.11i encryption standard for wireless LANs. TKIP is the next generation of WEP, the Wired Equivalency Protocol, which is used to secure 802.11 wireless LANs. TKIP provides per-packet key mixing, a message integrity check and a re-keying mechanism, thus fixing the flaws of WEP.

802.1x Authentication

802.1x is a framework for authenticated MAC-level access control, defines Extensible Authentication Protocol (EAP) over LANs (WAPOL). The standard encapsulates and leverages much of EAP, which was defined for dial-up authentication with Point-to-Point Protocol in RFC 2284.

Beyond encapsulating EAP packets, the 802.1x standard also defines EAPOL messages that convey the shared key information critical for wireless security.

Advanced Encryption Standard (AES)

Security issues are a major concern for wireless LANs, AES is the U.S. government's next-generation cryptography algorithm, which will replace DES and 3DES.