



1:24 R/C

English

Age 8+

#81016

Maisto Radio Control Vehicles

Please keep this owner's instruction manual for future reference. It contains important information.

We reserve the right to improve/revise the product specifications without notice.

Warning! The Antenna of Transmitter is not to be inserted into socket outlets.

Contents:

- RC Vehicle x 1
- RC Transmitter x 1
- Antenna Tube x 1
- Owner's Instruction Manual x 1

Battery Requirement:

Vehicle: 2 x 1.5V "AA" LR6/R6 batteries.
Transmitter: 2 x 1.5V "AA" LR6/R6 batteries.

Battery installation for the Transmitter and Antenna installation: (Refer to Diagram 1 & 2)

1. Open the battery cover.
2. Install 2 new 1.5V "AA" LR6/R6 batteries with correct polarity (+/-) as shown inside the battery compartment.
3. Install the battery cover.
4. Insert antenna wire into the antenna tube.
Tie a Knot at the top end of the wire.

Battery installation for the Vehicle: (Refer to Diagram 3 & 4)

1. Switch the power OFF.
2. Open the battery cover.
3. Install 2 new 1.5V "AA" LR6/R6 batteries with correct polarity (+/-) as shown inside the battery compartment.
4. Install the battery cover.

How to play: (Refer to Diagram 5 & 6)

1. Switch ON the vehicle.
2. Push forward the lever on the left side of the transmitter to drive the vehicle forward.
Pull back the lever on the left side of the transmitter to drive the vehicle backward.
3. Push the lever on the right side of the transmitter to the left to turn left.
Push the lever on the right side of the transmitter to the right to turn right.
4. If the vehicle does not run in a straight line, adjust the wheel alignment under the chassis.
5. Remember to switch OFF the vehicle power after playing.

Performance Tips:

1. Do not drive the vehicle on grass, sand or go through water.
2. Do not drive the vehicle in windy or rainy weather.
3. Do not drive the vehicle into any hard object.
4. Always switch the power to OFF on the vehicle when you are done playing.
5. Keep fingers, hair and loose clothing away from the vehicle.
6. The operating range can be affected by a variety of factors:
 - a) Weak transmitter or vehicle batteries.
 - b) Interference from other items that emit radio frequency signals such as another R/C item on the same frequency, CB radios, cordless phones, high voltage transformers, etc.
7. Outdoor usage is recommended in order to get optimal control range (32 feet or 10 meters).

Battery use:

1. Alkaline batteries are recommended.
2. Only batteries of the same or equivalent type as recommended are to be used.
3. Do not mix alkaline, standard or rechargeable batteries.
4. Do not mix old and new batteries or different type of batteries.
5. Non-rechargeable batteries are not to be charged.
6. If rechargeable batteries are to be used, they are only to be charged by adult.
7. Rechargeable batteries are to be removed from the product before they are charged.
8. Be sure to insert batteries with correct polarities and always follow the battery manufacturer's instructions.
9. Remove all batteries from the product when not in use for long periods of time.
10. Exhausted batteries are to be removed from the product.
11. The supply terminals are not to be short-circuited.
12. Dispose of batteries properly. Do not dispose of batteries in fire – it may cause them to explode or leak causing injury or damage.
13. Battery change must only be made by adult.







Disposal of batteries

Batteries should not be disposed of in the household waste. As the consumer you are legally obliged to return batteries containing harmful substances and all other used batteries. You can hand in your old batteries at public collection points in your area or wherever batteries are sold.

You will find these chemical abbreviations along with a crossed-out refuse bin on batteries containing harmful substances:

- Pb = Battery contains lead
- Cd = Battery contains cadmium
- Hg = Battery contains mercury

WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.



English

Cautions:

1. Do not attempt to disassemble the products.
2. Do not operate the vehicle with same frequency with other players in same location. This will interfere and cause the vehicle to lose control.
3. Make sure the batteries are installed with correct polarity (+/-) as shown inside the battery compartment.
4. Remove the package, take out all accessories and assemble the product before giving it to children to play.

FCC Label Compliance Statement:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions :

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Note : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
 - Consult the dealer or an experienced radio/TV technician for help.
- Warning : Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RSS-310 Compliance Statement:

This radiocommunication device complies with all the requirements of Industry Canada Standard RSS-310.

Operation is subject to the following two conditions: (1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Carrier Frequency : 49.860MHz

Field strength and measurement distance : 72.2 dBuV/m at 3 meter

Carrier Frequency : 27.145MHz

Field strength and measurement distance : 74 dBuV/m at 3 meter

Troubleshooting:

Problem	Cause	Correction
No Function	Low battery level Battery polarities are reversed The wheels are obstructed by foreign objects	Replace with new batteries Insert the batteries with correct polarities as shown on the battery compartment Remove foreign objects on the vehicle / wheels
Drive Slow / Poor Turning Signal	Low battery level The wheels are obstructed by foreign objects	Replace with new batteries Remove foreign objects on the vehicle / wheels
Poor distance control	Low battery level Strong interference of surroundings	Replace with new batteries Move to a better location for playing

Maisto International, Inc.
Fontana, CA 92336, U.S.A.



www.maisto.com

MADE IN CHINA

MAY CHEONG TOY PRODUCTS FTY. LTD.			DIECUT
Job Item: (Bil)	Finished by:	Date:	Test No.:
Item No.: #81016 - 1:24 R/C with stick controller	Check by:	DWN Name:	Material: