



Product Registration

If you register your SMART product, we'll notify you of new features and software upgrades.

Register online at www.smarttech.com/registration.

Keep the following information available in case you need to contact SMART Technical Support.

Serial Number:		
Date of Purchase:		

Trademark Notice

SMART Board, the SMART logo and smarttech are trademarks or registered trademarks of SMART Technologies ULC in the U.S. and/or other countries. Microsoft, Windows, Windows Vista, Internet Explorer and Excel are either registered trademarks or trademarks of Microsoft Corporation in the U.S. and/or other countries. Mac is a registered trademark of Apple Computer, Inc., registered in the U.S. and other countries. Adobe, Flash and Acrobat Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the U.S. and other countries. Intel, Core Duo, Pentium and Itanium are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the U.S. and other countries. All other third-party product and company names may be trademarks of their respective owners.

Copyright Notice

©2007–2009 SMART Technologies ULC. All rights reserved. The use and copying of SMART Response assessment software is subject to a license agreement. Any other use is prohibited. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language in any form by any means without the prior written consent of SMART Technologies ULC. Information in this manual is subject to change without notice and does not represent a commitment on the part of SMART.

Important Information

Before you use the SMART Response interactive response system, please read and understand the safety warnings and precautions described in this guide. These safety warnings and precautions instruct you in the safe and correct operation of the system and its accessories so you can prevent injuries to yourself, others or damage to the equipment. You must always ensure that the SMART Response interactive response system is being used correctly.

NOTE

If you own a SMART product other than a SMART Response interactive response system, refer to the user's guide that came with your product for relevant warnings and maintenance instructions.

Safety Information

WARNING

- Failure to follow the installation instructions that ship with the SMART product could result in personal injury or damage to the product.
- When using the SMART Response interactive response system with a SMART Board™ interactive whiteboard and projector, do not stare into the beam of light created by the projector. Instruct children not to look in the direction of, or stare at, this beam of light.
- Ensure that any cables extending across the floor to your SMART product are properly bundled and marked to avoid a trip hazard.
- To reduce the risk of fire or electric shock, do not expose the components to rain or moisture.

CAUTION

- Use only the batteries provided or equivalent replacements. Do not attempt to recharge the batteries.
- Do not install batteries with the polarity (+/–) reversed.
- Do not dispose of batteries in a fire or incinerator.
 - Dispose of batteries according to the laws and regulations of your region. If you don't know the applicable rules for your region, consult the battery manufacturer.

- Never use abrasive erasers or harsh chemicals when cleaning SMART Response interactive response system hardware.
- Do not open the receiver or clicker units to attempt repairs. Refer all service to authorized SMART service personnel.

IMPORTANT

- You must connect the USB cable that came with your SMART product to a computer that has a USB compliant interface and that bears the USB logo. In addition, the USB source computer must be compliant with CSA/UL/EN 60950 and bear the CE mark and CSA and/or UL Mark(s) for CAS/UL 60950. This is for operating safety and to avoid damage to the SMART product.
- If your SMART product requires replacement parts, make sure the service technician uses replacement parts specified by SMART Technologies or parts with the same characteristics as the original.

Compliance

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this equipment not expressly approved by SMART Technologies may void the user's authority to operate this equipment.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

iii |

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiver or clicker units.
- Increase the separation between the equipment and the product.
- Connect the affected equipment into an outlet on a circuit different from that to which the receiver's computer is connected.
- Consult your SMART service representative or an experienced radio/TV technician for help.

Contents

	Important Information	i
	Safety Information	i
	Compliance	ii
1	About SMART Response	1
	Overview	1
	Features	2
	Software Features	4
	Hardware - Clickers and Receivers	5
2	Installing SMART Response	7
	Environmental Requirements	7
	Temperature	7
	Humidity	7
	Water and Fluid Resistance	7
	Dust and Scratching	7
	Electrostatic Discharge (ESD)	8
	Conducted and Radiated Emissions	8
	Installing SMART Response Assessment Software	9
	System Requirements	9
	Contacting SMART Technologies	11
	SMART Response Assessment Software Components	11
	Activating SMART Response Software	13
	Installing and Setting up SMART Response	15
	Connecting the SMART Response Receiver	15
	Recommended Height for Mounting the Receiver	15
	Extending the USB Cable	16

	Naming Your Classroom	17
	Renaming the Classroom	18
3	Managing SMART Response	19
	Checking the Receiver	19
	Selecting the Operating Mode	21
	Starting in Anonymous Mode	22
	Starting in Sign In Mode	22
	Locking Sign In	23
	SMART Response Alert	24
4	Managing Class Lists	25
	Creating Class Lists in Teacher Tools	25
	Importing Class Lists from Microsoft Excel® Software (Windows Operating Systems Only)	26
	Importing Class Lists from a CSV File	27
	Tips for Formatting CSV Files for Importing Class Lists	28
	Modifying Class Lists	30
5	Connecting and Disconnecting the Clickers	33
	Connecting Clickers in Anonymous Mode	33
	Connecting the Clickers in Sign In Mode	33
	Disconnecting the Clickers	34
	Monitoring the Clickers	36
	Using the Simulator	37
6	Using SMART Response	39
	About SMART Notebook Software	39
	SMART Notebook Software with SMART Response Assessment Software	39
	SMART Response Preferences	40

7	Using SMART Notebook to Ask Questions and Create Assessments	41
	Question Types	41
	Asking Questions with SMART Notebook	42
	Creating Instant Questions	42
	Adding Questions with the Insert Question Wizard	43
	Creating Assessments	45
	Tagging questions	47
	Adding a Content Page	48
	Importing Questions from a Microsoft Word Document	49
	Importing Questions from XML or SQZ Files	51
	Importing Questions from a PDF File	52
	Printing from SMART Notebook Software's Response Menu	54
	Exporting Results to an Excel, HTML or CSV File	55
8	Using SMART Response Software in the Classroom	57
	Before Class Begins	57
	Starting an Assessment	58
	Using the Clickers	60
	Receiving Student Questions	61
	Using the Menu Button	61
	Viewing, Printing and Exporting Results	62
	Reviewing Instant Results	63
	Evaluating Assessment Results	64
	Generating Student Performance Reports	66
	Generating Class Performance Reports	67
9	Maintaining SMART Response	69
	Preventing Component Damage	69
	Cleaning the Receiver and Clickers	69
	Changing Clicker Batteries	69
	The Receiver Indicators	70

viii | CONTENTS

	Troubleshooting the Receiver	71
	Resetting the Receiver	71
	Troubleshooting Using the Receiver Lights	71
	Other Troubleshooting Tips	72
	Transporting SMART Response	72
Α	Hardware Environmental Compliance	73
	Waste Electrical and Electronic Equipment Regulations (WEEE Directive)	73
	Restriction of Certain Chemicals (REACH Directive)	73
	Restriction of Certain Hazardous Substances (RoHS Directive)	73
	Batteries	74
	Packaging	74
	Covered Electronics Devices	74
	China's Electronic Information Products Regulations	74
	U.S. Consumer Product Safety Improvement Act	74
В	Customer Support	75
	Online Information and Support	75
	Training	75
	Technical Support	75
	Shipping and Repair Status	75
	General Inquiries	76
	Warranty	76
	Registration	76

Chapter 1 About SMART Response

Overview

The SMART Response interactive response system is an assessment tool that enhances learning. It facilitates summative and formative assessment by allowing you to pose a question before, during or after a lesson to find out if students are on track. You can use the feedback to help shape the rest of your lesson.

Once you've finished the lesson, create a question set with SMART Response assessment software to evaluate learning more formally. You can feel confident that the students have answered the way they intended, because they can verify and change their self-paced responses directly on the clicker.

Teachers can easily add creativity to questions by combining text with images to make questions more dynamic. SMART Response comes with SMART Notebook collaborative learning software, and offers 6,000 learning objects that you can easily add to quizzes.

SMART Response also increases one-to-one interaction by allowing teachers to survey and engage students and collect responses.

Features

· Octon oo	
Teacher Tools	Access, view and manage all assessment data in one location. This powerful tool allows you to create class lists, and set up, conduct and manage tests and quizzes.
	You can also monitor each student's progress during a test and instantly view their results.
Smooth integration	SMART Response software integrates with SMART Notebook.
New user interface	With its simple interface, SMART Response's intuitive software allows teachers to create pages that have clear, contextual and concise information for both novice and expert users.
Integrated Gradebook	Through Gradebook, teachers can build comprehensive reports based on their students' grades, and they can sort, organize and monitor their students' progress.
	Reports can be as simple or as detailed as you need. Create high-level comparisons of class performance, specific reports based on tagged characteristics such as demographics or curriculum standards, or personalized reports on how individual students are doing.
Integration with third-party question bank	Third-party questions can be easily integrated into SMART Notebook.
Tagging	Teachers can tag students and questions, and automatically generate reports with comprehensive student and class performance breakdowns.
	They can also tag keywords to describe various characteristics, correlate questions to curriculum standards and break down performance into a printable chart.
	Teacher Tools makes it easy to keep everything organized. The easy-to-use management tool automatically files test results in the built-in Gradebook. It also lets you view performance reports and test scores, and manage your class lists, all from one location.
Ability to assign partial marks to answers	With this feature, teachers can assign partial marks for individual questions.

Content pages let you insert material between questions	Teachers can use SMART Notebook page groups to present a story on a content page, and then follow it up with relevant questions.
One window in control of classrooms and assessments	Teacher Tools adds powerful grading and reporting functionality. It brings teacher's class lists and assessment scores into one place, and assessment results automatically file into Gradebook. Files save to a single .teacher file for easier data management.
Monitoring students during and after the test through the quiz introduction page	Teachers can monitor how much time is remaining for a quiz through the introduction page. Grades are immediately calculated after the test and displayed in graphical charts and numeric tables.
Monitoring time per response per student	SMART Response's interface can determine which student answered first, and who answered what.
One click instant reporting through Gradebook	Create one-click instant reports that display a student's, or class's, performance and progress. Gradebook gives you quick access to test results, making it easy to prepare reports and conduct analysis.

Software Features

Flexible assessment	This feature gives teachers frequent opportunities to ask questions and obtain feedback, which can engage students more actively in the material being studied.
	You can display feedback in a bar or pie chart. All feedback statistically summarizes student responses, and helps teachers record and track each student's progress.
Anonymity	Students can send private responses through the anonymity feature. With this feature, the system logs each response according to an assigned number for each student. Only the teacher knows which student has which number, so students can answer questions without feeling judged by their peers.
Dynamic content	Use SMART Notebook to create questions and assessments with pictures, sound, video and Adobe® Flash® files from the Gallery.
Instant, measurable results	This feature allows teachers to instantly pose questions and receive responses from within SMART Notebook.
Question variety	Teachers can ask different types of questions, including true or false, yes or no, multiple choice, numeric response, and multiple answer.
File import and export	This feature allows teachers to export to their online performance reporting systems, or a reporting system of their choice.
	Convenient monitoring options allow teachers to monitor students during and after tests, see how much time is left, who has completed the questions, who answered first, and which questions were answered.
	The comprehensive Gradebook allows teachers to create new class lists, conduct SMART Notebook assessments, and view class reports.
Import and export assessments	Teachers can export assessment results to other gradebooking or database applications. They can also import scores from other activities/quizzes to include in SMART Response's Gradebook for complete reporting.

Hardware - Clickers and Receivers

Radio frequency (RF) technology	Radio frequency (RF) technology provides a reliable wireless connection between the student clickers and the central receiver. You don't need a line of sight to the clickers, and the range is 100' feet (30 m).
	The receiver verifies receipt of every signal, and messages are automatically resent if they weren't received.
Ergonomic design	Designed to fit comfortably in young hands or lie flat on a desk, the SMART Response clicker has 21 input buttons that make responding to questions quick and easy.
	Even young students will find the handheld device easy to use and comfortable to hold.
LCD screen	The easy-to-read LCD screen has room to display three lines of text. Students can see if responses have been sent, and review the status of their clicker's battery power and network connection.
Descriptive icons	Icons on an LCD screen allow students to monitor battery power and the network status of their clicker.
Extended battery life	Each clicker uses two long-lasting AA batteries.
Easy connection	The receiver connects via a USB cable to a computer, and it doesn't require an additional power adaptor.
Flexible installation	The receiver weighs just under 6 oz. (165 g), measures 4 3/4" W x 7/8" H x 2 1/4" D (12 cm x 2.2 cm x 5.7 cm), and easily mounts onto walls, desks or tables.
Status features	The LED lights indicate power status and whether information is being sent or received.
Compatibility	SMART Response is compatible with both the Microsoft® Windows® and Mac OS operating systems.

Chapter 2

Installing SMART Response

Environmental Requirements

Before installing or using your SMART Response system, review the following environmental requirements and compliance statements.

Temperature

SMART Response's components can operate in the temperature range of 41°F to $95^{\circ}F$ (5°C to $35^{\circ}C$). In addition, the product can withstand storage temperatures from -40°F to $120^{\circ}F$ (-40°C to $50^{\circ}C$).

Humidity

SMART Response's system components can operate in up to 80% relative humidity non-condensing.

Water and Fluid Resistance

SMART Response's components are for indoor use only and don't meet any salt-spray or wateringress requirements. Don't pour or spray any liquids directly onto SMART Response components. These liquids might get into areas where they could damage sensitive electronic components.

Dust and Scratching

SMART Response components are for use in office and classroom environments, and aren't for industrial use where heavy dust and pollutants can cause malfunctions or impaired operation. They're designed for pollution degree 1 (P1) as per EN61558-1, which is defined as "No pollution or only dry non-conductive pollution."

Electrostatic Discharge (ESD)

SMART Response components meet the requirements of EN61000-4-2 severity level 4 for direct and indirect ESD. No malfunction or damage up to 15 kV (both polarities) with a 330 ohm, 150 pF probe (air discharge). Unmated connectors meet 8 kV for direct (contact) discharge.

Conducted and Radiated Emissions

SMART Response hardware's narrowband radiated electric field meets the limits for Class B performance, as defined in EN55022/CISPR 22.

Installing SMART Response Assessment Software

System Requirements

Minimum Requirements - Windows XP SP2 or SP3

Pentium® III 1.0 GHz processor with 512 MB of RAM 331 MB of free hard disk space for minimum installation Microsoft Internet Explorer® 6.0 or later Adobe® Flash® Player version 9 Adobe Reader version 8 or later

Recommended Requirements - Windows XP SP2 or SP3

Intel®-compatible 1.6 GHz processor with 512 MB of RAM
1.2 GB of free hard disk space for full installation with Gallery collections
Microsoft Internet Explorer 6.0 or later
Adobe Flash Player version 9
Adobe Reader version 8 or later

Advanced Requirements - Windows Vista® SP1

1.5 GHz Intel Core™ Duo processor with 1 GB of RAM
1.2 GB of free hard disk space for full installation with Gallery collections Microsoft Internet Explorer 7.0 or later
Adobe Flash Player version 9
Adobe Reader version 8 or later

Minimum Requirements - Mac OS X 10.4.11

1 GHz Power PC G4 processor with 384 MB of RAM 480 MB of free hard disk space for minimum installation Adobe Flash Player version 9

Recommended Requirements – Mac OS X 10.4.11

1 GHz Power PC G5 or Intel processor with 512 MB of RAM 1.5 GB of free hard disk space for full installation with Gallery collections Adobe Flash Player version 9

Advanced Requirements - Mac OS X 10.5.5

1.5 GHz Intel Core Duo processor with 1 GB of RAM 1.5 GB of free hard disk space for full installation with Gallery collections Adobe Flash Player version 9

NOTES

- $1 \text{ MB} = 1024^{2} \text{ bytes}, 1 \text{ GB} = 1024^{3} \text{ bytes}.$
- SMART Response assessment software runs on 32-bit operating systems only.
- You're unable to use SMART Response software on Windows computers with Intel Itanium® processors.

Contacting SMART Technologies

Visit the SMART Support website at www.smarttech.com/support to check for software upgrades, including SMART Notebook software and SMART Response assessment software. You'll find installation and user's guides, how-to and troubleshooting articles, SMART product solutions, and answers to your questions. Use the SMART Support website to contact Technical Support.

SMART Response Assessment Software Components

In the following procedures, you'll install all of these software components:

- Teacher Tools
- Driver software for the receiver
- SMART Notebook, including the SMART Response assessment software menu

IMPORTANT

SMART Response includes SMART Notebook software. However, if you need to connect SMART Response to a SMART Board interactive whiteboard, you will need to visit the SMART Support website to download the appropriate drivers.

Windows Click here to download the drivers.

Mac: Click here to download the drivers.

To install SMART Response on Windows computers

- Insert the SMART Response assessment software CD into your computer's drive.
 The *Installation* Wizard appears. If the wizard doesn't start automatically, locate
- 2. Click Install SMART Response Software to start the wizard, and then click Next.

and double-click the SMARTResponseSoftwareSetup.exe file on the CD.

The Licence Agreement dialog box appears.

- 3. Select the I accept option, and then click Next.
- 4. Click Next to install the software to the default folder.
- 5. Click **Install** to start the installation.
- 6. Click Finish.
- Select the options to check for program updates and install SMART Essential for Educators as desired, click **Next**, and then click **Finish** to complete the installation.

If your computer is connected to the Internet, after a short delay, the SMART Product Update dialog box appears.

To install updates

1. If updates are available, click **Update**, and then click **Close**.

A balloon message appears in the notification area.

2. Click the balloon message to create a classroom.

A dialog box appears.

3. Type a unique classroom name into the box, and then click **OK**.

■ NOTE

The **OK** button is disabled until you type a valid classroom name.

4. Click **Finish** to complete the installation.

To install SMART Response on Mac computers

1. Insert the SMART Response CD into your computer's drive.

A **SMART Response** CD icon appears on the desktop.

2. Double-click the **SMART Response** CD icon.

The SMART Response window appears.

3. Double-click the **SMART Response** box icon.

The Install SMART Response dialog box appears.

4. Click Continue, and then click Continue again.

The Software License Agreement page appears.

- 5. Click **Continue**, and then click **Agree** if you agree with the terms of the license agreement.
- 6. If there is more than one version, select the version that you want to install, and then click **Continue**.
- 7. Click **Install** to start the installation.

NOTE

If the installer asks you for a password, type your password, and then click **OK**.

8. Click **Continue Installation** to complete the installation.

If your computer is connected to the Internet, the SMART Essentials for Educators dialog box appears. Select the categories you want to install, and then click **Next**.

The SMART Product Update dialog box appears. If your computer is connected to the Internet, the dialog box displays the current versions of your SMART product software, and displays the latest updates available for download from SMART's website.

9. If software updates are available, click Update.

OR

If software updates aren't available, or if you don't want to update your software, click **Close**.

After a short delay, a message appears asking you to restart your computer.

10. Click Restart.

Activating SMART Response Software

You must register SMART Response software within 30 days of installation to keep it active.

IMPORTANT

SMART Response software automatically activates when you connect your SMART Response receiver. If the activation isn't successful, use the following procedure to find your license code and activate the software.

You must connect your computer to the Internet and connect the SMART Response receiver to your computer before searching for a license code. After you complete the following procedure to find your license code, use the code to activate the software on other computers, as outlined in the **License** tab in the *About SMART Response*Assessment Software dialog box.

NOTE

After you find your license code, you don't need to connect the SMART Response receiver to the other computers that you want to activate SMART Response software on.

To find your license code and activate SMART Response

1. Click the **SMART Response** icon in the Windows notification area or Mac menu bar, and then select **Activate SMART Response Assessment Software**.

The *Software Evaluation* dialog box appears displaying the time remaining in your software evaluation period.

NOTE

If your SMART Response assessment software is already activated, the Activate SMART Response Assessment Software command is replaced by Check for Updates. See the next procedure to find the license code in the activated software.

- 2. Click Activate Now.
- If a dialog box appears requesting a password, type the administrator's password, and then click OK.

NOTE

Contact your system administrator if you don't know your password.

4. Click Find License Code.

NOTE

You must connect your computer to the Internet, and connect the SMART Response receiver to your computer, before searching for a license code.

5. Click Find License Code.

The license code appears. The activation program automatically copies your license code into the **License Code** box.

NOTE

If you didn't connect the receiver, a warning message appears. Click \mathbf{OK} to close the dialog box.

- 6. Record the license code, and then click Close.
- 7. Type your e-mail address in the License Code box, and then click Next.

Your SMART Response software activates.

8. Click Finish.

Now that you have your license code, complete the steps below to activate SMART Response on other computers.

To activate SMART Response on other computers

1. Click the **SMART Response** icon in the Windows notification area or Mac menu bar, and then select **Activate SMART Response Assessment Software**.

The **SMART Response Software Evaluation** dialog box appears and displays the time remaining in your software evaluation period.

2. Click Activate Now.

If a dialog box appears requesting a password, type the administrator's password.

- 3. Type your license code and e-mail address, and then click **Next**.
- 4. Click Finish.

Your SMART Response software activates.

NOTE

You don't need to connect your SMART Response receiver during this procedure.

- 1. Click the **SMART Response** icon in the Windows notification area or Mac menu bar, and then select About **SMART Response Assessment Software**.
- 2. Record the license code that appears on the **Description** tab.

Installing and Setting up SMART Response

Connecting the SMART Response Receiver

IMPORTANT

For operating safety and to avoid damage to the receiver, you must only connect the interactive whiteboard's USB connector to a computer that has a USB compliant interface and that bears the USB logo. In addition, the USB source computer must be compliant with CSA/UL/EN 60950 and bear the CE mark and CSA and/or UL mark (s) for CSA/UL 60950.

The receiver has a USB 2.0 full-speed peripheral interface that runs at speeds of up to 12 Mbps. The unit works with USB 2.0- and USB 1.1-compliant USB interfaces.

Recommended Height for Mounting the Receiver

Although SMART Response receivers don't require an unobstructed line-of-sight transmission path such as that required by infrared devices, you can operate SMART Response over larger distances if you minimize interference, signal reflections and the number and size of objects between the receiver and the clickers.


Choose a location for the receiver that's as high as possible, and in plain view of the students' clickers. For permanent installations, use a USB extender to mount the receiver high on a wall. To minimize interference from other radio-frequency equipment, position the receiver away from other wireless products, such as 2.4 GHz routers and cordless telephones.

WARNING

To prevent product damage or personal injury, route the USB cable where it will not be stepped on or tripped over.

To connect the receiver

- 1. Position the receiver in an unobstructed location away from other wireless products, such as 2.4 GHz routers and cordless telephones.
 - For temporary installations, place the receiver on top of your desk.
 - For permanent installations, mount the receiver on a wall, or on the front of a piece of furniture using two screws (not provided).
- Orient the receiver with the long side or edge facing the class as shown.
 - Connect the receiver's captive USB cable connector to an available USB receptacle on your computer.



On Windows computers, a balloon message appears in the notification area indicating that new hardware has been detected.

 On Mac computers, a balloon message appears indicating that the hardware is ready to use. The top LED indicator on the receiver turns red to indicate that it's receiving power.

IMPORTANT

If the balloon message indicates that Windows is starting to try to locate a driver from the Microsoft website, stop the search. If Windows can't find the driver on your computer, you haven't installed the SMART Response software. Install the software and repeat the above procedure.

Extending the USB Cable

If the provided 6' (1.8 m) USB cable attached to the receiver isn't long enough, use active USB extender cables, USB extenders or hubs.

The illustration to the right shows the SMART active USB extension cable (Part No. USB-XT). In some cases, you may be able to use up to four cables to extend the length to about 80' (25 m), which is the limit of the USB specification. Passive USB extension cables aren't supported.



NOTE

Some computers use internal active hubs to provide more USB receptacles. The computer's operating system may see these internal hubs as external devices, limiting the number of USB extenders you can use.

Alternately, USB extenders that use Cat 5 cabling can extend the range to approximately 325' (100 m), at a much higher cost. The more economical SMART USB extender pair (Part No. CAT5-XT) can extend the USB connection up to 12' (36.6 m) on Windows computers or 90' (27.5 m) on Mac computers using an RJ45 Cat 5 cable.

These units require that you use the provided 6' (1.8 m) cables or use cables and connectors that meet the same specifications. Impedance mismatches and poor connections can cause signal degradation and performance problems. USB hubs should also work with receivers. If you also use streaming audio through a shared USB hub, the receiver's performance might become intermittent or otherwise unacceptable.

USB extenders and hubs must be USB 1.1 or USB 2.0 compliant to work correctly. They must also provide at least 100 mA to the receiver.

Naming Your Classroom

NOTE

You're unable to assign a classroom name while installing SMART Response. You can create a classroom name only after SMART Response is installed, and Teacher Tools starts for the first time.

To name the classroom

- 1. Click the **SMART Response** icon in the Windows notification area or menu bar, and then click **Teacher Tools**.
- 2. Click Next.

The Classroom Information dialog box appears.

3. Type a classroom name between one and eight characters, and then click Start.

NOTE

The Start button enables only after you've typed in your classroom name.

A dialog box appears indicating that SMART Response is not ready, that there is no receiver plugged in, or that you can use SMART Response in Anonymous mode if the receiver is connected.

NOTE

Before you start asking questions, you may want to **Lock Sign In to** your class and choose one of the following settings:

- restrict students from signing in before you are ready
- restrict late students from signing in

Renaming the Classroom

If you move the SMART Response hardware to another location, use the following steps to change the classroom name.

To change the classroom name

- 1. Click the **SMART Response** icon in the Windows notification area or Mac menu bar, and then select the icon below **Teacher Tools**.
- 2. If Teacher Tools opens to Basic view, click ...switch to Gradebook view.

NOTE

If you want Teacher Tools to open to the *Gradebook* view when you start Teacher Tools, select the **Start here when you start Teacher Tools** option in the bottom-left corner of the window.

3. Click Gradebook.

The Gradebook window appears.

NOTE

You're unable to change the classroom name if a class is started and the receiver is on.

4. Click **Edit** (the blue underlined text beside the gradebook name).

The Edit Gradebook Information window appears.

5. In the **Classroom Name** box, type a new name of eight characters maximum, and then click **Done**.

Chapter 3

Managing SMART Response

Teacher Tools is your primary tool for checking the receiver and clicker status, evaluating student performance, selecting the mode of operation, managing class lists, starting and stopping sessions and viewing historical information about students and clickers.

NOTE

You can safely close Teacher Tools while clickers are connected and question sets are running. Restart Teacher Tools at any time from the Windows notification area or Mac menu bar, or by clicking **Response > Teacher Tools** in SMART Notebook software. After restarting the software, Teacher Tools displays the current connection mode, as well as the student and clicker status.

Checking the Receiver

If you've installed the receiver, you're ready to start a class session. Check the receiver's communication status at any time using the following procedure.

To check the receiver status

 Click the SMART Response icon in the Windows notification area or Mac menu bar.

A message appears below the Configure Hardware heading indicating how many receivers are connected.

Click on your class's name under the Configure Hardware heading.Teacher Tools starts.

3. Click ...switch to Gradebook view if you aren't already in Gradebook view.

₽ NOTE

If you want Teacher Tools to open to the *Gradebook* view when you start the software, select the **Start here when you start Teacher Tools** option in the bottom-left corner of the window.

4. Click in the left column.

The *Devices* window appears.

If a "Your SMART Response receiver is connected and working" message appears, the SMART Response receiver is connected and communicating with the SMART Response clickers. The receiver name appears below the **Devices** heading.

If a "Your SMART Response receiver is not connected" message appears, the SMART Response receiver isn't connected or isn't working properly. The receiver name doesn't appear below the Devices button. Check the receiver's USB connection.

5. Click **My Receiver** to the classroom name and the make, model and hardware ID (MAC address) of the receiver.

Selecting the Operating Mode

Before starting a class session, you must decide whether you want the system to operate in Anonymous mode or Sign In mode. This table summarizes the characteristics of each mode.

Anonymous Mode	Sign In Mode
You can operate the system without a class list.	You must operate the system with a class list that identifies each student by name and a unique ID number.
Students can connect their clickers without identifying themselves.	Students can connect their clickers but must sign in with their assigned ID number.
Under the teacher's control, students can see their own scores but can't see any other students' scores.	Under the teacher's control, students can see their own scores but can't see any other students' scores.
Teachers can see how many clickers are connected.	Teachers can identify individual students as they connect and sign in with their clickers.
Teachers can't save and evaluate student and class performance over time.	Teachers can use <i>Gradebook</i> to save and evaluate student and class performance over time.
Teachers can't generate student or class performance reports.	Teachers can generate student and class reports.
Teachers can see, export and print the total class score.	Teachers can see, export and print the total class score.
Teachers can see, export and print total scores for each question.	Teachers can see, export and print total scores for each question.
Teachers can't prevent a student from signing in, and can't remotely disconnect individual students.	Teachers can prevent individual students from signing in for a time interval, and can disconnect individual students.
Teachers can't identify students' names or their individual scores.	Teachers can see, export and print each student's score for each question and their total score.

Starting in Anonymous Mode

You don't need a class list to operate SMART Response in Anonymous mode.

To start in Anonymous mode

- 1. Click the **SMART Response** icon in the Windows notification area or Mac menu bar, and then select the icon below **Teacher Tools**.
- 2. If Teacher Tools opens to the *Basic* view, click **Start a Class**, and then select **Anonymous Mode** from the drop-down list.

OR

If Teacher Tools opens to the *Gradebook* view, select **Anonymous Mode** from the area below *Gradebook*, and then click **Start Class**.

The receiver's power LED flashes, and then turns solid green, and the receiver's transmit LED flashes green. You can now ask the students to turn on and connect their clickers.

NOTES

- If the students have already signed in to a class, and you select Anonymous mode, the clickers switch to Anonymous mode.
- If the clickers are in Anonymous mode, and you start a class that requires sign-in, the clickers sign off and then ask the students to sign in.

Starting in Sign In Mode

Before connecting the clickers in Sign In mode, open a class list.

To open a class list in Sign In Mode

- 1. Click the **SMART Response** icon in the Windows notification area or Mac menu bar, and then select the icon below **Teacher Tools**.
- If Teacher Tools opens to the Basic view, click Start a Class, and then select the class from the drop-down list.

OR

If Teacher Tools opens to the *Gradebook* view, select the class from the area below **Gradebook**, and then click **Start Class**.

The receiver's power LED flashes, and then turns solid green, and the receiver's transmit LED flashes green. You can now ask the students to turn on and connect their clickers.

Locking Sign In

At any time after you start SMART Response software you can restrict students from signing in. Simply select the **Lock Sign In** command to restrict students from signing in before you're ready, or select it to restrict late students from signing in. When you start SMART Response, Sign In is unlocked by default. If you stop and restart SMART Response, or open a new class list, Sign In is unlocked.

To stop students from signing in

- 1. Click the **SMART Response** icon in the Windows notification area or Mac menu bar, and then select the icon below **Teacher Tools**.
- 2. If Teacher Tools opens to Basic view, click ...switch to Gradebook view.

NOTE

If you want Teacher Tools to open to the *Gradebook* view when you start Teacher Tools, select the **Start here when you start Teacher Tools** option in the bottom-left corner of the window.

- 3. If a class isn't already started, select a class in the *Gradebook* area, and then click **Start Class**.
- 4. Click Lock Sign In.

Students are unable to sign in.

NOTE

If a student disconnects their clicker when Sign In is locked, they're unable to sign in again until you select **Unlock Sign In**.

SMART Response generates alert messages for four events by default:

- · Student sign in
- · Student sign out
- Student has a question
- Clicker battery is low

To enable or disable alert messages

- 1. Click the **SMART Response** icon in the Windows notification area or Mac menu bar, and select the icon below **Teacher Tools**.
- 2. If Teacher Tools opens to *Basic* view, click ...switch to Gradebook view if it isn't already selected.

NOTE

If you want Teacher Tools to open to the *Gradebook* view when you start Teacher Tools, select the **Start here when you start Teacher Tools** option in the bottom-left corner of the window.

3. Click Edit, and then select Preferences.

The SMART Response Preferences dialog box appears.

4. Select or clear the applicable check box to display or prevent alert messages from appearing.

Chapter 4

Managing Class Lists

Use Teacher Tools to create, import or modify class lists.

NOTE

You're unable to create, import or modify class lists once a class is started.

Creating Class Lists in Teacher Tools

NOTE

You don't need to create class lists to start a class in Anonymous mode.

To create a class list

- 1. Click the **SMART Response** icon in the Windows notification area or Mac menu bar, and select **Click here to start a class**.
- 2. If Teacher Tools opens to Basic view, click ... switch to Gradebook view.

₩ NOTE

If you want Teacher Tools to open to the *Gradebook* view when you start, select the **Start here when you start Teacher Tools** option in the bottom-left corner of the window.

- 3. Click Add a Class in the Gradebook area on the left.
- 4. Type a name for your class, add other details to the *Class Information* boxes if desired, and then click **Add**.

After a short delay, the new class's window appears, and the class name appears in the *Gradebook* area.

- 5. Click the **Students** tab at the top of the window.
- 6. Select **Edit > Add**, or click the **Add** button in the tool bar.

The *Properties* window appears below the table.

7. Type a unique number between 1 and 15 digits in the **Student ID** box.

NOTES

- You must type a unique valid ID into the Student ID box.
- You can type a student's name in the Name boxes. The student's e-mail address and Tags are optional. You can also type name and ID information directly into the table fields.
- Use tags to categorize the students into custom groupings that SMART Response uses when you create student reports.

The student information saves to the class list as you enter it.

8. Repeat steps 6 and 7 for each new student.

Tagging Students

Use tags to identify groups or categories of students. SMART Response uses the tags to sort student results when you generate Class Performance reports. For example, you can assign the tags "Senior" and "Junior" to the students, and SMART Response will add one chart to the report with two bars, one for each tag.

Assign multiple tags to a student by separating them with a semicolon (;), for example "Senior; Honors" and "Junior; Honors". SMART Response then generates a report including a chart with three bars for "Senior", "Junior" and "Honors", respectively.

Create tag subcategories by separating them with a colon (:), for example, "Gender:Male" and "Gender:Female". In this case, SMART Response generates a single report section for "Gender" showing data grouped into "Male" and "Female" subsections.

Importing Class Lists from Microsoft Excel® Software (Windows Operating Systems Only)

If you use Microsoft Excel to maintain student rosters, you can import an XLS file into the Teacher Tools to create a class list.

NOTE

You may find it easier to copy the list of names into a new Excel spreadsheet.

To create a class list in a Microsoft Excel Spreadsheet

- 1. Open the spreadsheet listing your student names in Microsoft Excel.
- 2. Insert a blank row at the top of the spreadsheet, if it doesn't already have one.

- 3. In the first cell (A1), type **ID Number**.
- 4. In the first cell of the second column (B1), type First Name.
- 5. In the first cell of the third column (C1), type **Last Name**.
- 6. Move the first and last names into columns B and C, directly below the headings.
- 7. Type a unique ID number from 1 to 15 digits for each student into column A, and then save the spreadsheet.

To import a class list from Microsoft Excel software

- 1. Click the **SMART Response** icon in the notification area, and then select the icon under **Teacher Tools**.
- 2. Click ...switch to Gradebook view if you aren't already in *Gradebook* view, and then click Add a Class in the *Gradebook* area on the left.
- 3. Type a name for your class, optionally add other details to the *Class Information* boxes, and then click **Add**.
 - After a short delay, the new class's window appears, and the class name appears in the *Gradebook* area.
- 4. Click the **Students** tab at the top of the window.
- 5. Click the **Import** button at the top of the window, or click **Add students to your** class below *Next steps*.
- 6. Select **Students** from the drop-down list.
 - The *Import* dialog box appears.

properties as required.

- 7. Select the class into which you want to import the student list, and then click **Next**.
- 8. Select Microsoft Excel from the Import from list, and then click Next.
- Browse to and select the XLS file containing the student list, and then click **Open**.
 The student list information appears in the table. You can now edit each student's

Importing Class Lists from a CSV File

If you use a database or spreadsheet program to maintain student lists, you may be able to export the student list as a comma separated value (CSV) file. Refer to your software's Help system or user's guide for procedures.

After exporting your student list as a CSV file, format your file in a text editor so that the first three values are **ID Number**, **First Name** and **Last Name** as shown in this example.

Tips for Formatting CSV Files for Importing Class Lists

- The order of the columns isn't important, but the first row must contain the column headings identifying what's in each column.
- You must have a column with the heading "ID Number".
 - You must put a single space between "ID" and "Number".
 - In place of "ID Number", you can use: "ID", "Student ID" or "Number".
 - If you don't use a correct column name for the "ID Number", the import fails.
- The student name columns are optional.
 - For the student's given names, you can use "First Name" for the column heading.
 - For the student's family names, you can use "Last Name" as the column heading.
 - You must put a single space between "First" (or Last) and "Name".
 - In place of "First Name", you can use "Surname".
 - In place of "Last Name", you can use "Last", "Family Name" or "Surname".
- Use the heading "Full Name" to import a single value that combines the first and last names.
 - You must put a single space between "Full" and "Name".
 - In place of "Full Name", you can use "Full", or "Name".
 - If you use "Full Name", the software first checks to see if the first and last names are separated by a comma. E.g., "Last", "First". If there isn't a comma, it separates the names with a space. For instance, "First Last".
 - If you enter three or more names with spaces between the names, the software uses the last word as the last name and joins all of the first words to form the first name. For instance, "Michael John Smith" is split with the last name as Smith, and the first name as Michael John.
- If your spreadsheet or database software inserts double-quote characters around the comma-separated values, the software ignores them and the import works properly.

To import a class list from a CSV file

- 1. Click the **SMART Response** icon in the Windows notification area or Mac menu bar, and select **Click here to start a class**.
- 2. Click ...switch to Gradebook view if you aren't already in *Gradebook* view.
- 3. Click **Add a Class** in the *Gradebook* area on the left.

4. Type a name for your class, optionally add other details to the *Class Information* boxes, and then click **Add**.

After a short delay, the new class's window appears, and the class name appears in the *Gradebook* area.

- 5. Click the **Students** tab at the top of the window.
- 6. Click the **Import** button at the top of the window, or click **Add students** to your class below *Next steps*.
- 7. Select the class to which you want to import the student list, and then click **Next**.
- 8. Select Comma Separated Values (CSV) from the Import from list, and then click Next.
- 9. Browse to and select the CSV file, select it, and then click **Open**.

After a short delay, the names and IDs from your CSV file appear in the *Students* page. You can now edit each student's properties, as required.



Modifying Class Lists

NOTE

You're unable to modify student information if a class is started.

To modify student information

- Click the SMART Response icon in the Windows notification area or Mac menu bar, and then select Teacher Tools.
- 2. Click ...switch to Gradebook view if you aren't already in Gradebook view.
- 3. Select the class in the Gradebook area on the left.
- 4. Click the **Students** tab.

The class list appears.

5. Select the student whose information you want to modify.

The Properties window appears.

- 6. Type the changes into the **Properties** text boxes.
- 7. Repeat steps 5 and 6 for each student.

Adding Student to Class Lists

To add a student to a class list

- Click the SMART Response icon in the Windows notification area or Mac menu bar, and then select Teacher Tools.
- 2. Click ...switch to Gradebook view if you aren't already in Gradebook view.
- 3. Select the class from the Gradebook area on the left.
- 4. Click the Students tab.

The class list appears.

5. Select **Edit > Add**, or click the **Add** button in the tool bar.

The *Properties* window appears.

6. Type a unique number between 1 and 15 digits in the **Student ID** box.

The student information saves to the class list as you enter it.

If you add students while you're in Anonymous mode, SMART Response switches to Sign In mode.

NOTE

You must type a unique valid ID into the student properties.

TIP

You can use tags to categorize the students into custom groupings that SMART Response uses when you create student reports.

8. Repeat steps 5 through 7 for each new student.

Removing Students from Class Lists

NOTE

You're unable to remove students from a class list while a class is running.

To remove a student from a class list

- 1. Click the **SMART Response** icon in the Windows notification area or Mac menu bar, and then select **Teacher Tools**.
- 2. Click ...switch to Gradebook view if you aren't already in Gradebook view.
- 3. Select the class in the *Gradebook* area on the left.
- 4. Click the Students tab.

The class list appears.

 Select the student you want to remove, and then select Edit > Delete, or click Delete on the toolbar.

A message appears asking you to confirm the deletion.

- 6. Click Yes.
- 7. Repeat steps 5 and 6 for each student you want to remove.

Chapter 5

Connecting and Disconnecting the Clickers

Connecting Clickers in Anonymous Mode

NOTE

- If the teacher selected the Lock Sign In option, the clicker turns off.
- When all of your students are connected, you can start asking questions.

Connecting the Clickers in Sign In Mode

NOTE

In this mode, students must know the classroom name. They must also sign in with a unique ID number, either with the ID you assigned to them when you created the class list, or unassigned ID.

When the "SMART Response is ready to use" balloon message appears, tell your students to follow these steps.

To connect clickers in Sign in mode

- 1. Press the clicker's **Power** button for one second.
- 2. A message appears asking if you want to join the last class the clicker was connected to, or find a different class.
- 3. Press Enter to join the last class.

OR

Press **Down** to select **Find a class**, and then press **Enter**.

The clicker scans for classes, and then displays a list of classes within range.

4. Press the **Up** and **Down** buttons to select the correct class, and then press **Enter**.

A connecting message appears, followed by a message asking for an ID number.

If you've entered a valid ID, a message appears asking you to confirm your name.

NOTE

If the teacher selected the **Lock Sign In** option, the clicker returns to the ID screen.

6. Press Enter to connect.

A welcome message appears.

When all of your students are connected, you can start asking questions.

NOTE

If a student attempts to sign in using an ID already in use by another student, the clicker displays a message indicating that they're unable to sign in, and allows them to retry.

Disconnecting the Clickers

You can disconnect and turn off all clickers simultaneously.

NOTE

You're unable to use Teacher Tools to disconnect the clickers while a question set is running.

To disconnect all clickers using Teacher Tools

- 1. Click the **SMART Response** icon in the Windows notification area or Mac menu bar, and then select **Teacher Tools**.
- 2. Select a class in the *Gradebook* area, and then click **Stop Class**.

All student clickers disconnect and turn off.

A message appears on the clickers indicating that the class is over, and that the clickers are turning off. The power, transmit and receive LEDs on the receiver turn off.

To disconnect all clickers using the Devices menu

- Click the SMART Response icon in the Windows notification area or Mac menu bar, and then select Teacher Tools.
- 2. Select Devices, and then click Turn off all clickers.

A message appears on the clickers indicating that the class is over, and that the clickers are turning off. The power, transmit and receive LEDs on the receiver turn off.

To disconnect individual clickers using Teacher Tools

- 1. Click the **SMART Response** icon in the Windows notification area or Mac menu bar, and then select **Teacher Tools**.
- 2. Select the active class in the *Gradebook* area.
- 3. Click the Students tab.
- 4. Select the row of the student you want to disconnect.

The *Properties* window appears below the student list table.

5. Click the **Disconnect Clicker** button at the top-right of the window.

The Log Off Student dialog box appears.



6. Click **OK** to log off the student.

OR

If you don't want the student to log on for a while, select **Also ban this student for**, select the number of minutes, and then click **OK**.

Getting Students to Disconnect their Clickers

Students can disconnect their clickers by pressing the **Power** button for one or two seconds.

If signed-in students turn off their clickers when a question set is started, they can turn on their clickers, sign in with the same ID, and rejoin the assessment in progress without losing the answers they previously entered. If students anonymously reconnect, they lose any previously-entered answers when they reconnect.

If students connect to the wrong class, ask them to log off by pressing the **Menu** button, selecting **Sign out**, and then pressing the **Enter** button. They can then connect and sign in to the correct class without turning off their clickers.

Monitoring the Clickers

You can use Teacher Tools to check each clicker's status. You can see if a clicker is logged on or if it's in Anonymous mode. You can also see the clickers' serial numbers (MAC addresses), and identify which students are logged on.

The clicker displays the signal strength, as measured by the receiver. If the signal level is low for one or more clickers, and they're having communication problems, you may want to reposition the receiver or remove signal path obstructions.

To check the clickers

1. Start a class and have your students connect their clickers.

The Transmit light flashes green, and the Ready light is solid green.

- 2. Click the **SMART Response** icon in the notification area, or Mac menu bar, and then click the icon below the **Configure Hardware** heading.
- 3. Click...switch to Gradebook view, if you aren't already in *Gradebook* view.

NOTE

If you want Teacher Tools to open to the *Gradebook* view each time you start Teacher Tools, select the **Start here when you start Teacher Tools option** in the window's bottom-left corner.

4. Click **Devices** in the left column.

The *Devices* window appears and displays a "Your SMART Response receiver is connected and working" message. The receiver name appears below the **Devices** button.

5. Click My Receiver, and then click the Clickers tab at the top of the window.

The *Clickers* window appears and displays a table of all connected clickers. Each row of the table shows one clicker's signal strength, battery condition, student name and hardware ID (MAC address).

NOTE

If students' clickers are connected anonymously, the Student Name field displays Anonymous.

Using the Simulator

The simulator is an aid for demonstrating the clicker's functions, and to assist people who are vision impaired. You can project the simulator onto an interactive whiteboard, where students or teachers can use it the same way they use a hardware clicker.

To start the simulator

Click the Simulator button on the Teacher Tools toolbar bar.

OR

Click the **SMART Response** icon in the Windows notification area or Mac menu bar, and then select **Simulator**.

OR

Click Start > All Programs > SMART Technologies > SMART Response > Simulator.

Chapter 6

Using SMART Response

About SMART Notebook Software

Use SMART Notebook software to save notes written on a SMART interactive product or at your computer as a series of pages. You can use SMART Notebook to create a presentation that's full of colorful clip art, Adobe Flash objects, graphics and text from a variety of sources. Then present that SMART Notebook file, keeping your audience's attention as you move and interact with these objects. When your audience provides comments and suggestions, write their input on a page using the pen tray tools or the pen buttons in SMART Notebook software.

Because SMART Notebook works on many platforms, you can share files created on a Windows computer with people who use a Mac computer. You can also export your SMART Notebook file as a cross-platform HTML or PDF file, or as a series of image files.

SMART Notebook Software with SMART Response Assessment Software

SMART's addition of SMART Response software to SMART Notebook means that you can create question sets, import questions from Microsoft Word or XML files and start and stop question sessions directly from SMART Notebook. You can export the class's and individual students' results to a Microsoft Excel file or an HTML page. Using SMART Response's printing feature, create handout materials, copies of the questions and marked results pages for each student and for the class.

This section introduces the SMART Response software features in SMART Notebook. For more information about using other SMART Notebook features, refer to SMART Notebook's online Help or the SMART website.

SMART Response Preferences

You can customize the default behavior of some of SMART Notebook's SMART Response features.

To define how SMART Response inserts instant questions

- 1. Click **Response**, and then select **Preferences**.
- 2. If you want the **Instant Question** button to insert the question on a SMART Notebook page that already has notes or images, select **Insert on current page**.

If you want to create a new page containing your question, select **Always insert** on a new page. If you want SMART Response software to ask you each time, select **Always ask before inserting.** This is the default setting.

To define Response tab options

- 1. Click **Response**, and then select **Preferences**.
- 2. Select the type of results chart (pie or bar) you want to display by default.
- 3. If you want to display the **Response** tab immediately after you start an assessment so you can monitor the progress of the assessment, select **Show the Response tab when you start an assessment**.

OR

If you want to display the **Response** tab immediately after you stop an assessment so you can display the assessment results, select **Show the Response tab when you stop an assessment**.

Chapter 7

Using SMART Notebook to Ask Questions and Create Assessments

By creating assessments, you can collect results for a set of questions simultaneously. You can print and hand out the assessment pages so students can answer questions at their own pace.

Question Types

You can use SMART Notebook to create, import and run assessments with five types of questions.

Question Type	Description
Yes or no	Students must use the Y or N buttons to answer a question. You can also choose the Opinion option to allow any answer.
Multiple choice	Students must use a single button, A through J , to answer the question. Select from 2 to 10 answers for a question. You can also choose the Opinion option to allow any answer.
Number, fraction or decimal	Ask a question with a numeric answer using whole numbers, fractions or decimals. You can also choose the Opinion option to allow any answer.
True or False	Students must use the T or F buttons to answer a question. You can also choose the Opinion option to allow any answer.
Multiple answer	Students use the A through J buttons to select the correct combination of answers to the question. Select from 2 to 10 answers for the question. You can also choose the Opinion option to allow any answer.

Asking Questions with SMART Notebook

Creating Instant Questions

Use the **Instant Question** feature to introduce the SMART Response interactive response system to your students. When you use Instant Questions, you're unable to type a question or assign a correct answer. You can ask questions verbally, by writing on a whiteboard, or by typing the question and adding objects directly onto the SMART Notebook page.

NOTE

Make sure that you start your class, and that all students' clickers are connected before asking individual questions.

To ask individual questions using the Instant Question feature

 Click the SMART Response icon in the Windows notification area or Mac menu bar, and then select Open Notebook Software below the Ask Questions heading.

A blank SMART Notebook page appears.

2. Select the **Response** tab.

OR

Click the **Insert Question** button (in Windows operating systems) or click and hold the button (in Mac operating systems).

NOTE

If the **Insert Question** button isn't in the menu bar (or Mac Dock), you can right-click (or control-click) the menu bar and add the button.

3. Click one of the Instant Question buttons.

The *Instant Question* dialog box appears asking if you want to insert the question on this page or a new page.

4. Select one of the options.

NOTE

It you want to use the same option by default, select the **Always perform this action** option. You can change the default in the Preferences menu.

A SMART Notebook page appears showing the possible answer to the question. The **Response** tab changes to *Single Question*, and the **Progress** button is selected. The question starts automatically, and appears on the clickers.

- 5. Present your question to the class.
- 6. When all students have answered the question, click **Stop this question**.

7. To save the results, select **File > Save** (or **Save As**).

OR

To ask the same type of question again, select SMART Response > Clear.

OR

To add another question without clearing the results of the previous question, don't click **Clear**, and then repeat steps 2 through 5.

Adding Questions with the Insert Question Wizard

You can use SMART Notebook software to create five types of questions you can ask students and then collect their answers.

To add a questions using the *Insert Question* wizard

 Click the SMART Response icon in the Windows notification area or Mac menu bar, and then select Open Notebook Software below the Ask Questions heading.

A blank SMART Notebook page appears.



Add questions to an existing SMART Notebook file by clicking **Open Existing File**.

Select the Response tab.

OR

Click the **Insert Question** button (in Windows operating systems) or click and hold the button (in Mac operating systems).

NOTE

If the **Insert Question** button isn't in the menu bar (or Mac Dock), you can right-click (or control-click) the menu bar and add the button.

The Insert Question wizard appears.

- 3. Click the thumbnail for the desired question type, and then click Next.
- 4. Type the question into the text box.
- 5. If you use tags to create categories in your reports, type them into the **Tags** box using the examples, and then click **Next**.

- 44 | CHAPTER 7 USING SMART NOTEBOOK TO ASK QUESTIONS AND CREATE ASSESSMENTS
- 6. For *Yes or No* and *True or False* questions, select the correct answer, or the **Opinion** option.

For *Number, fraction, decimal* questions, type the correct answer.

For *Multiple choice* or *Multiple answer* questions, select the number of answers, type the answers into the text boxes, click **Next**, and then select the correct answers or the **Opinion** option.

7. Assign the number of points that the student will receive if they answer the question correctly.

NOTE

The value can be a whole or decimal number.

8. If you want to create more questions, click the **Insert Question** button.

OR

Click the **Response** tab, click the **Next Steps** button, select **Add a question to the next page**, then repeat steps 3 through 7.

NOTE

If you create another question on the next page, a message asks if you want to add a title page to the questions, which groups them together.

9. Use SMART Notebook software tools to add images or Adobe Flash objects from the Gallery if desired.

Collecting Question Responses

NOTE

Make sure that you start your class and that all the students' clickers are connected before asking questions.

To collect question responses

1. Click the **Response** tab, click the **Progress** button, and then select **Start this** assessment now.

OR

Click Response > Start Assessment.

If you haven't started a class, a message appears asking you to select a class. Select a class, and then click **Start Class**.

A message appears on the clickers asking the students to respond with their answers.

- 45 | CHAPTER 7 USING SMART NOTEBOOK TO ASK QUESTIONS AND CREATE ASSESSMENTS
- 2. When all students have answered, click the **Response** tab, click the **Progress** button, and then select **Stop this assessment**.

OR

Click Response > Stop Assessment.

NOTE

SMART Notebook stores the results in your document. Remember to save your document after collecting responses.

3. If you want to save the questions as a .notebook file, click **File > Save** (or **Save As**).

A Save As dialog box appears.

4. Browse to a destination folder, type a file name for the .notebook file, and then click **Save**.

Creating Assessments

By creating assessments, you can collect results for each question and for the entire assessment at the same time. You can print and hand out the assessment pages so that students can answer the questions at their own pace.

You can install SMART Response assessment software on a computer that isn't connected to a receiver and create question sets that you can later copy to and run on the computer system in your classroom.

NOTE

You're unable to run assessment .notebook files on a computer with standard SMART Notebook software installed. You must have SMART Notebook software that includes SMART Response.

To create a new assessment

 Click the SMART Response Assessment Software icon in the Windows notification area or Mac menu bar, and select Open Notebook Software below the Ask Questions heading.

A blank SMART Notebook page appears.

2. Click the **Response** tab.

TIP

Clear the **Auto-hide** option to keep the options visible while you're working on your assessment.

- 46 | CHAPTER 7 USING SMART NOTEBOOK TO ASK QUESTIONS AND CREATE ASSESSMENTS
- 3. Click the **Title Page** button.

OR

Click Response, and then select Insert Title Page.

The Insert SMART Response Title Page dialog box appears.

- 4. In the top text box, type a title for your assessment.
- 5. Select the type of assessment you want to create, and then click **Add**. Optionally, you can type in the **Subject** and **Topic** information as well.

The title page information appears on the SMART Notebook page, and the tab displays several options that allow you to customize your assessment.

To edit the assessment title page and description

- 1. On the SMART Notebook page, double-click the title, **Grade**, **Subject** or **Date** text to change its display properties or edit the text.
- 2. In the *Description* area, edit or change the options you defined when you created the assessment.

NOTE

If you edit the SMART Notebook page, the *Description* information doesn't change. The reverse is also true.

To add a question to your assessment

1. Click Add a question to the next page.

OR

Click **Next Steps** at the top of the tab, and then click **Add a question to the next page**.

OR

Click Response, and then select Insert Question.

The Insert Question wizard appears.

- 2. Click the thumbnail for the desired question type, and then click **Next**.
- 3. Type the question.
- 4. If you use tags to create categories in your reports, type them into the **Tags** box using the examples, and then click **Next**.

For Yes or No and True or False questions, select the correct answer, or the **Opinion** option.

For *Number, fraction, decimal* questions, type the correct answer. For *Multiple choice* or *Multiple answer* questions, select the number of answers, type the answers into the text boxes, click **Next**, and then select the correct answers or the **Opinion** option. Optionally, you can add notes that appear when you print the assessment results.

- 47 | CHAPTER 7 USING SMART NOTEBOOK TO ASK QUESTIONS AND CREATE ASSESSMENTS
- 5. Assign the number of points that the student will receive if they answer the question correctly.
- If you want to create more questions, click the Next Steps button, click Add a question to the next page, and then repeat steps 3 through 5.

OR

If this is your last question, click **End on this page**.

NOTE

You can use SMART Notebook software's tools to add images or Adobe Flash objects from the SMART Notebook Gallery, if desired.

To add a choice to your question page

- 1. Click the thumbnail of the question page to which you want to add a choice.
- 2. Select SMART Response > Add Choice.
- 3. Follow the on-screen instructions.
- If you have to change the correct answer for the question, select SMART Response > Set All Answers, and then make the changes.
 - NOTE

If you add choices to *True or False* or *Yes and No* questions, the question changes to multiple choice.

Tagging questions

Using the *Insert Question* wizard, you can add tags to the questions you create in SMART Notebook assessments. You can also add or change the tags to questions after you finish creating an assessment.

You can use tags to identify groups of categories of questions when you generate Student Performance and Class Performance reports. For example, if you assign the tags "Difficult" and "Easy" to the questions, and SMART Response will create one chart in the report for questions with "Difficult" and "Easy" tags.

You can assign multiple tags to a question by separating them with a semicolon (;). For example, "Science; Nature;" and "Science; Astronomy". SMART Response will create one chart with three bars for "Science", "Nature" and "Astronomy".

You can also create tag subcategories by separating them with a colon (:). For example, "Science: Basic" and "Science: Advanced". In this case, SMART Response generates a single report section for "Science" showing data grouped into "Basic" and "Advanced" subsections.

48 | CHAPTER 7 - USING SMART NOTEBOOK TO ASK QUESTIONS AND CREATE ASSESSMENTS

To add or change tags in existing questions

 Click the SMART Response Assessment Software icon in the Windows notification area or Mac menu bar, and then select Open Notebook Software below the Ask Questions heading.

A blank SMART Notebook page appears.

2. Select **File > Open**, and then double-click your assessment file.

The .notebook file appears displaying the title page.

3. Click the **Page Sorter** tab, and then click the thumbnail of the page with the question to which you want to add tags.

The question page appears.

- 4. Click the **SMART Response** tab, and then click the **Properties** button.
- 5. If the *Tags* box isn't visible, click **Show** beside the *Answer Key* heading.
- 6. Type your tags into the **Tags** box.
- 7. Press **Page Up** or **Page Down** to select other questions as required, and then repeat step 6.
- 8. Save your assessment.

Adding a Content Page

You can add content pages anywhere in your assessment to introduce questions or provide background information for questions that follow.

To add a content page

- 1. Click the **Page Sorter** tab, and then navigate to the SMART Notebook page you want to follow with a content page.
- 2. Click the Response tab, and then click Make the next page a content page.

A blank page appears.

3. Use SMART Notebook software's tools to add text, images or Adobe Flash objects from the Gallery.

To save your assessment

1. Select File > Save (or Save As).

A Save As dialog box appears.

2. Browse to a folder, type a name for the file, and then click **Save**.

Importing Questions from a Microsoft Word Document

NOTE

This feature is only available in SMART Response for Windows operating systems.

When you import questions from a Microsoft Word document, SMART Response's conversion utility uses a variety of techniques to identify which paragraphs are questions, which are possible answers, and what type of question to create. Its most basic technique is to format the numbering of the paragraphs. The software also searches for key words when parsing the paragraphs. The software then converts the paragraphs into SMART Notebook assessment pages.

NOTE

SMART Response software can't provide the correct answers to the imported questions.

Example Word Document Question Formats

1.	According t	to the U.S.	Census Bureau,	the majori	ty of	poor children	live i	n:
----	-------------	-------------	----------------	------------	-------	---------------	--------	----

- a. urban areas
- b. suburban areas
- c. rural areas
- 2. Can you fill a 10 L aquarium with five 2 L pitchers of water?

Yes

No

3. True or false: Half of all even whole numbers are divisible by 4.

True False

4. Let x = 3. Compute y from the equation below.

y = 20 - 4	4x		
Answer: _			

- 5. Which Native American group lived in the highlighted area on the map?
 - a. Kwakitul
 - b. Sioux
 - c. Iroquois

NOTE

Ensure that you format the questions in your Microsoft Word document before you begin this procedure. In most cases, the import utility ignores headers and footers in the Word document.

To import questions from a Microsoft Word document

1. Click the **SMART Response** icon in the notification area, and then select **Open Notebook Software** below the *Ask Questions* heading.

A blank SMART Notebook page appears.

- 2. Select Response > Import Questions From > Microsoft Word.
- 3. Browse to and select the Word document, and then click **Open**.

A progress bar appears and closes when the conversion is complete.

- 4. In the *Page Sorter* tab, select the thumbnail for the title page.
- 5. Edit and customize the page and description as desired.
- 6. In the *Page Sorter* tab, select the thumbnail for the first question page, and then check it carefully to verify that the conversion process was accurate.
- 7. Repeat step 6 for all questions in the assessment.

To set the answers for imported questions

- 1. In the **Page Sorter** tab, select the thumbnail for the first question page.
- 2. Select Response > Set All Answers.

The Set All Answers dialog box appears.

- 3. Type or select the correct answer from the options, and then click **Done**.
- 4. Repeat steps 1 through 3 for all questions.
- 5. Select File > Save (or Save As).

The Save As dialog box appears.

6. Browse to a folder, type a file name for the .notebook file, and then click **Save**.

You can run the question set on this computer, or copy the assessment .notebook file to any computer that has SMART Response software installed.

Importing Questions from XML or SQZ Files

SMART Response assessment software includes an import feature for converting questions from ExamView® format XML files or SMART Sync (formerly SynchronEyes™) software SQZ files into question sets. SMART Response software uses the tags in the XML and SQZ files to extract questions, answers and correct responses, and then converts the information into SMART Notebook assessment pages.

₽ NOTE

You must create an Exam View formatted XML file or a SMART Sync SQZ file before performing this procedure. Binary Exam View formatted files aren't supported.

To import questions from an XML or SQZ file

 Click the SMART Response icon in the Windows notification area or Mac menu bar, and then select Open Notebook Software below the Ask Questions heading.

A blank SMART Notebook page appears.

- 2. Select Response > Import Question From > XML.
- 3. Browse to and select an XML file or a SMART Sync (SQZ) file, and then click **Open**.

A progress bar appears, followed by the title page for the new question set.

- 4. In the **Page Sorter** tab, select the first question page.
- 5. Add a title page to the assessment, and then customize the page and description as desired.
- 6. Edit and customize the page as desired.

Check the question carefully, including the correct answer (see below), to verify that the conversion process was successful.

- 7. Repeat step 6 for all questions in the set.
- 8. Select File > Save (or Save As).

A Save As dialog box appears.

9. Browse to a folder, type a name for the .notebook file, and then click **Save**.

To set the answers for imported questions

- 1. In the **Page Sorter** tab, select the thumbnail for the first question page.
- 2. Select Response > Set All Answers.

The Set All Answers dialog box appears.

- 52 | CHAPTER 7 USING SMART NOTEBOOK TO ASK QUESTIONS AND CREATE ASSESSMENTS
- 3. Type or select the correct answers from the options, and then click **Done**.
- 4. Select File > Save (or Save As).
 - A Save As dialog box appears.
- 5. Browse to a folder, type a name for the .notebook file, and then click **Save**.

You can run the question set on the current computer, or copy the assessment .notebook file to any computer that has SMART Response software installed.

Importing Questions from a PDF File

NOTE

This feature is only available with SMART Response software for Mac operating systems.

When you import questions from a PDF document, the SMART Response software conversion utility detects the numbering of the paragraphs. The software also recognizes key words when parsing the paragraphs. The software then converts the paragraphs into SMART Notebook assessment pages.

NOTE

You can't run assessment .notebook files on a computer with standard SMART Notebook software installed. You must have SMART Notebook that includes SMART Response assessment software.

PDF Document Formatting

The text below shows examples of multiple choice or multiple answer questions formatted so that SMART Response software can easily convert them to question pages.

- 1. How is the boy involved in the dog's care?
 - a. He feeds the dog twice a day.
 - b. He walks the dog once a day.
 - c. He cleans up the dog's messes.
 - d. He gives the dog a lot of affection.
- 2. What percentage of the U.S. Government budget goes to welfare and Social Security?
 - a. 25% to welfare and 25% to Social Security
 - b. less than 1% to welfare and 20% to Social Security
 - c. 20% to welfare and 1% to Social Security
 - d. less than 1% to welfare and less than 1% to Social Security

NOTES

- You can only import multiple choice questions.
- You should remove headers and footers from your PDF document because the import utility will attempt to convert them into questions.
- Introduction, background or source information not related to questions should be on separate pages.
- Text and graphics that the import utility can't convert into questions are handled differently, depending on the Mac OS used on your computer. If you use Mac OS X 10.5 operating system, the text or graphics are imported to a Notebook page as a graphic. If you use Mac OS X 10.4 operating system, the text and graphics are discarded.

To import questions from a PDF file

1. Click the **Response** icon in the menu bar, and then select **Open Notebook Software** below the *Ask Questions* heading.

A blank SMART Notebook page appears.

- 2. Select Response > Import Question From > PDF File.
- 3. Browse to and select the PDF document, and then click **Open**.

A progress bar appears and closes when the conversion is complete.

- 4. In the Page Sorter tab, select the thumbnail of the title page.
- 5. Edit and customize the page and description as desired.
- 6. Edit and customize the first question page as desired.
- 7. Check the questions carefully to verify that the conversion process was accurate.
- 8. Repeat steps 6 and 7 for all questions in the assessment.

To set the answers for imported questions

- 1. In the **Page Sorter** tab, select the thumbnail for the first question page.
- 2. Select Response > Set All Answers.

The Set All Answers dialog box appears.

- 3. Type or select the correct answers from the options, and then click **Done**.
- 4. Select File > Save (or Save As).

A Save As dialog box appears.

5. Browse to a folder, type a file name for the .notebook file, and then click **Save**.

You can run the question set on the current computer, or copy the assessment .notebook file to any computer that has SMART Response software installed.

Printing from SMART Notebook Software's Response Menu

You can print a variety of information from the **Response** menu in SMART Notebook software. You can create and include header, footer and date information, and select a page range to print.

Print Option	Description
Thumbnails	Prints from one to six full-color reduced images of each SMART Notebook title page and question pages on one page. You can include page numbers, image borders and page titles.
Handouts	Prints from one to three full-color, reduced images of each SMART Notebook title and question pages together with ruled lines for notes on one page. You can include page numbers, image borders, and page titles.
Full page	Prints one full-color image of each SMART Notebook question page on separate pages. You can also include page numbers.
Questions	Prints several questions on a page. If the question page in SMART Notebook software doesn't have any objects or images, the questions appear on the page in text-only format. If there are objects on the question page, a full-color thumbnail of the question appears.
	You can choose to include page numbers. In the Print Preview view, click the question to toggle from thumbnail to text-only format.
Results	NOTE This option is only available after stopping a question or assessment.
	Prints several questions on a page. If the question page doesn't have any objects or images, only the text appears on the page. If there are objects on the question page, a full-color thumbnail of the question appears.
	The correct answer and the student's response appear beside each question, and the total score appears at the top of the first page. You can choose to include page numbers.
	You can print a results summary for all students in the class list, or you can print the results for selected students.

To print questions or results, click **Response > Print**, and then select the option that you want to print. For other options, click **Response > Print > More Print Options** or press CTRL + P to open SMART Response's *Print* window.

NOTE

The Questions and Results print options are only available if the .notebook file includes SMART Response questions and saved results information. If the assessment is still running, or if it's stopped before any student answers a question, no results are saved.

Exporting Results to an Excel, HTML or CSV File

If you save your .notebook file after asking questions or after running an assessment, you can re-open the .notebook file at any time to view the results.

You can export the results to a Microsoft Excel spreadsheet (Windows computers only) to an HTML page for viewing on a Web browser or to a comma separated value (CSV) file that you can import into many spreadsheet and database applications.

NOTE

You can only export results after stopping the assessment. If you clear the results after you stop, the results are permanently deleted so you're unable to print or export them. After saving and closing the .notebook file, you can re-open the file and print or export the results.

To export results to a file

1. Stop the assessment, if it's running.

Don't clear the results.

From the SMART Notebook menu bar, select Response > Export results to >
Microsoft Excel, Web Page (HTML), or Comma Separated Value (CSV).

A Save As dialog box appears.

3. Select a folder, type a name, and then click **Save**.

Either Microsoft Excel software or your default Web browser appear and displays the exported file.

IMPORTANT

To display class assessment results, a **View detailed results in Teacher Tools** link is available if the user is not in Anonymous mode.

56 | CHAPTER 7 - USING SMART NOTEBOOK TO ASK QUESTIONS AND CREATE ASSESSMENTS

Chapter 8

Using SMART Response Software in the Classroom

Before Class Begins

Safety Tips for Teachers

When using SMART Response software with a SMART Board interactive whiteboard and a projector:

- Tell students not to look directly at the light beam from the projector. Instead, encourage them to keep their back to the projector when working at the interactive whiteboard. Before they turn to face the class, they should take a big step (or even two) sideways.
- Make sure you don't look directly into the light beam from the projector. Keep your back to the class when you write over a projected image. Step to the side of the interactive whiteboard before you turn and face the class.
- Tell your students not to touch the projector, as it can become extremely hot during normal operation.
- Don't use a chair to increase a student's reach. If your students can't reach the
 top of the interactive whiteboard, lower it. You may need to remount a wallmounted unit to a lower position. If your interactive whiteboard is mounted on a
 floor stand, lower it with the help of another adult.
- Tell students not to run in the vicinity of the floor stand, as they may trip over the floor stand's feet.

Starting an Assessment

When you use SMART Notebook software to ask questions, SMART Response software uses the options you set in Teacher Tools to control how students use their clickers. Before starting a SMART Response assessment, check that the receiver is connected and ready. If you don't have an assessment .notebook file, you must create one.

To open and start an assessment

 Click the SMART Response icon in the Windows notification area or Mac menu bar, and then select Open Notebook Software below the Ask Questions heading.

A blank SMART Notebook page appears.

- 2. Select File > Open.
- Select the SMART Notebook file with your questions, and then click Open.
 The assessment file's title page appears.
- 4. Select the **Response** tab, and then click the **Properties** button, if it isn't already selected.
- 5. If you don't want SMART Notebook to collect student results, clear the **Remember Names** option.
- 6. From the **Show grades to students** drop-down list, select one of the options:

Option	Description
After you stop collecting responses	The clicker shows how the students answered after you click the Stop button. Grades display after you click the Stop button.
After all questions are answered	The clicker shows how the students answered, and displays their grades after they finish answering all questions.
After each question is answered	The clicker shows how the students answered each question, and displays their grades after they finish answering all questions.
Don't show grades on clickers	The clickers don't show results or grades.

- 7. If the students haven't connected their clickers, have them do so now.
- 8. Click Start this assessment now.

If you're projecting the questions on a screen, you can control the students' progress by selecting each question page in turn. If you provided printed student handouts, they can control their own pace.

9. Click **Stop this assessment** in the **Response** tab.

OR

Click **Response > Stop Assessment** to end the session.

NOTE


SMART Notebook stores the results in your document. Be sure to save your document after collecting responses.

10. Select File > Save (or Save As).

Using the Clickers

Before asking questions, review the clicker's operation with the students.

Clicker Buttons and Features



Clicker Button	Description
Power	Press for one second to turn on the clicker.
	Press for one to two seconds to turn off the clicker.
Selection	Scroll up and down option lists.
True/False or Yes/No	Answer true or false, or yes or no questions.
Alphanumeric	Answer multiple choice and numeric questions.
+ / -	Make a numeric answer positive or negative.
Enter	Make or confirm a selection.
Ask Question	Alert the teacher or ask a question. See next page for details.
Menu	Open clicker menu. See the table on the next page for details.
Delete	Delete alphanumeric characters entered.
Fraction/Decimal	Create fractional or decimal numeric answers.

Receiving Student Questions

At any time during a class, a student can request the teacher's attention by pressing the clicker's **Ask Question** button. Teacher Tools displays the number of students that have questions on the class **Home** tab beside the **Questions** heading.

To identify students with questions

- Click the **Students** tab to show the list of student names and IDs.
 In the **Status** column, you may see one or more rows with a question icon.
- 2. After you've answered the student's question, select the row that displays the student name, and then click the **Clear Question** button in the top-right corner of the *Properties* window.

Using the Menu Button

Students can press the **Menu** button at any time to log off the session or change the clicker's settings. The following options are available in the menu:

Option	Description
Sign Out	Press to log off a class without turning off the clicker.
Language	Press to select the language displayed on the clicker's LCD panel.
Contrast	Press to lighten or darken the clicker's LCD panel. Use the Up and Down arrows to increase or decrease the contrast.
Device information	Press to display the clicker's MAC address and firmware version.
Advanced	You must have a valid security code to open this menu. Your customer support representative may provide the code to help troubleshoot clicker problems.

Viewing, Printing and Exporting Results

If you save your SMART Notebook file after asking questions, or after running a question set, you can re-open the file at any time to view the results. You can print a variety of information, including question results, using SMART Notebook software's **Response > Print** menu.

You can also export the results to a Microsoft Excel spreadsheet (Windows operating systems only) to an HTML page for viewing on a Web browser or to a comma separated value (CSV) file that you can import into many spreadsheet and database applications.

NOTE

You can only print or export results after stopping the question or assessment. Clearing the results after stopping the question permanently deletes the information, so you're unable to print or export the results. After saving and closing the .notebook file, you can re-open the file and print or export the results.

To export results to a file

- 1. Stop the question or question set, if it's still running. Don't clear the results.
- Select Response > Export results to > Microsoft Excel (Windows computers only).

OR

Select Response > Export results to > Web Page (HTML).

OR

Select Response > Export results to > Comma Separated Value (CSV).

The Save As dialog box appears.

3. Select a destination folder, type a file name, and then click **Save**.

Either Microsoft Excel or your default Web browser appears and displays the exported file.

Reviewing Instant Results

You can use SMART Response to collect and display results instantly while you're running an assessment. You can use assessments as an interactive learning tool and a way to give students continuous feedback about what they're learning.

To display instant class assessment results

- After all students have answered their questions, return to the assessment's title page.
- 2. Click the **Response** tab, if it isn't already open.
- 3. Click the **Progress** button, and then click **Stop this assessment**.

The **Progress** button changes to **Results**. A summary of the class's performance appears, including a chart showing the class response to each question.

NOTE

You can toggle the type of chart displayed by selecting **Show bar chart** or **Show pie chart**.

4. Press Results.

A summary of the class's performance appears, including a chart showing the class response to each question.

- 5. If you want to view more detailed class results, click **View detailed results in Teacher Tools**.
- 6. Click the class name in the *Gradebook* area, and then click the **Students** button or the **Assessments** button for detailed information.
- 7. To display the students' grades, return to the SMART Notebook title page, and then click **Show** beside the *Details* title.

₩ NOTE

Use caution when displaying sensitive grade information to all class members.

To display instant results for each question

- After all students have answered their questions, return to the assessment's title page.
- Click SMART Notebook's Response tab, if it isn't already open.
- 3. Click the **Progress** button, and then click **Stop this assessment**.

The **Progress** button changes to **Results**. A chart representing the class's performance appears.

4. Press Results.

A summary of the class's performance appears.

5. Click the Page Sorter tab, and then select a question.

6. Click the Response tab.

A summary of the class's response to the question appears, including a chart showing the number of responses to each possible answer.

NOTE

You can toggle the type of chart displayed by selecting **Show bar chart** or **Show pie chart**.

TIP

You can insert the chart into the question page by clicking **Insert chart into Notebook**.

7. Click **Show** beside the *Details* title.

A list showing each student's response appears, including the time it took the student to respond.

NOTE

Use caution when displaying sensitive grade information to all class members.

Evaluating Assessment Results

After you run and stop an assessment, Teacher Tools records the class results and each student's results. At any time after you run an assessment, review the student, question or assessment results and performance.

NOTE

Use caution when displaying sensitive information to all class members. To hide sensitive information, click the **Privacy** button before you display student or assessment results.

To display student results

- 1. If a class is currently running, stop the class.
- 2. In Teacher Tools, click the class name in the *Gradebook* area.

The *Teacher Tools* window appears with the **Home** tab selected.

3. Click the Students tab.

After a short delay, a table of results appears. If you previously turned on Privacy mode, the student IDs and statistics appears as gray shapes in the table.

4. If Privacy mode is on, click **Privacy**.

The first columns of the table of class results show the student name, ID and average score for all the assessments the student has participated in. The following columns show each student's results for every assessment the class has taken.

1. Complete the above procedure, and then select the student's row.

The lower pane of the window displays the student properties.

2. Click the **Performance** tab.

An Assessment Results over Time chart appears showing the student's results compared to the class average for all assessments since the first assessment was run.

NOTE

The chart is hidden while Teacher Tools is in Privacy mode.

- Place your pointer over the chart coordinates to display details about the specific assessment.
- Click the Results tab.

A table appears showing detailed information about each assessment the student has completed, including the date and the score the student achieved. If the student's score fell below the passing grade you defined when you created the assessment, the score appears in red.

NOTE

The student marks are hidden while Teacher Tools is in Privacy mode.

To display class assessment results

- 1. If a class is currently running, stop the class.
- 2. In Teacher Tools, click the class name in the *Gradebook* area.

The *Teacher Tools* window appears with the **Home** tab selected.

3. Click the Assessments tab.

After a short delay, a table of results appears listing all assessments that the class has participated in, including the class average score for each assessment. If the class average score fell below the passing grade you defined when you created the assessment, the score appears in red.

To display detailed results for each assessment

1. Complete the above procedure, and then select the assessment's row.

The lower pane of the window displays the assessment's properties.

2. Click the **Performance** tab.

A *Student Achievement per Question* chart appears showing the student responses to each question.

NOTE

The chart is hidden while Teacher Tools is in Privacy mode.

3. Place your pointer over the chart bars to display details about the specific questions.

A table appears showing the mark each student received for the assessment. If the student's score fell below the passing grade you defined when you created the assessment, the mark appears in red.

NOTE

The student IDs and marks are hidden while Teacher Tools is in Privacy mode.

Generating Student Performance Reports

You can generate student performance reports at any time after your assessments are complete. You can tailor the reports to include all classes or select classes. You can also create reports for individual students or for all students in the selected classes at one time.

To generate a student performance report

- Click the SMART Response icon in the Windows notification area or Mac menu bar, and then select Teacher Tools.
- 2. Click ...switch to Gradebook view if you aren't already in Gradebook view.
- 3. In the **Reports** area, click **Student Performance**.

The Student Performance Report window appears.

4. In the Class drop-down list, select the class that you want to report on.

OR

Select All Classes to report on all classes.

5. In the **Student** drop-down list, select the class you want to report on.

OR

Select All Students.

- 6. Select the **Report Period**, if you only want to report information for a range of dates.
- 7. In the Include drop-down list, select Selected assessment types or All assessment types.
- 8. If you chose **Selected assessment types**, select the types you want to report on from the checklist that appears.
- 9. Browse to a location on your computer's file system where you want to save the report file, and then click **Create**.

SMART Response software creates one or more reports as PDF files that appear in your default PDF viewer. The files are named using the student name and ID, and the date they're created.

If you generated one report, the report opens automatically. If you generated multiple reports, the reports' folder location appears in Windows Explorer or Mac OS X Finder.

Generating Class Performance Reports

You can generate class performance reports at any time after your assessments are complete. You can tailor the reports to include all classes or select classes, or you can also create reports on all assessment types or on specific types of your choice.

To generate a class performance report

- 1. Click the **SMART Response** icon in the Windows notification area or Mac menu bar, and then select **Teacher Tools**.
- 2. Click ...switch to Gradebook view if you aren't already in *Gradebook* view.

The Class Performance Report window appears.

3. In the **Class** drop-down list, select the class you want to report on.

OR

Select All Classes.

- 4. Select the **Report Period** if you only want to report on information for a range of dates.
- 5. In the Include drop-down list, select Selected assessment types or All assessment types.
- 6. If you chose **Selected assessment types**, select the types you want to report on from the checklist that appears.
- 7. Browse to a location on your computer's file system where you want to save the report file, and then click **Create**.

SMART Response software creates one or more reports as PDF files that appear in your default PDF viewer. The files are named using the class name and the date they're created.

If you generated one report, the report opens automatically. If you generated multiple reports, the reports' folder location appears in Windows Explorer or Mac Finder.

Chapter 9

Maintaining SMART Response

Preventing Component Damage

CAUTION

- Do not use sharp or pointed objects, such as ballpoint pens or pointers, to press the clicker buttons.
- Never use abrasive erasers or harsh chemicals while cleaning the receiver or clickers.
- Avoid setting up and using your system in an area with excessive levels of dust, humidity or smoke.

Cleaning the Receiver and Clickers

With proper care, your SMART Response hardware will provide years of trouble-free service. Follow these cleaning tips to maintain your SMART Response system:

- Remove dust with a damp cloth before using a cleaner.
- Clean the unit's surface with a household glass cleaner, such as Windex®, daily, weekly or as required.
- Do not spray cleaner directly onto the clicker. Instead, spray a light amount of cleaner on a cloth and then wipe gently.

Changing Clicker Batteries

Under normal operating conditions, the clicker batteries can operate for up to 200 days. When replacing them, use fresh batteries of the same type and quality, and change both at the same time.

CAUTION

- Do not install batteries with the polarity (+ / -) reversed.
- Do not attempt to recharge the batteries.
- Do not dispose of batteries in a fire or incinerator.
- Dispose of batteries according to your region's laws and regulations. If you
 don't know the applicable rules for your region, consult your battery
 manufacturer.

- 1. Using the included Phillips® screwdriver, remove the screw from the back of the clicker, and then remove the cover.
- 2. Remove the exhausted batteries, and dispose of them according to local regulations.
- 3. Insert new AA batteries.

70 I

The clicker turns on.

- 4. Replace the cover and screw.
- 5. Verify that the start-up menu appears.
- 6. Press Power for one to two seconds to turn the clicker off.

The Receiver Indicators

Receivers have the following indicators:

- · The Ready light
- · The Transmit light
- · The Receive light

The Ready light LED is in the upper-right corner of the receiver's enclosure. The Ready light indicates the operational states of the receiver module. You can see the Transmit and Receive lights in the lower-right part of the receiver's enclosure. The lights flash green, indicating transmit and receive activity between the receiver and the clickers.

NOTE

The following table shows the Ready light's *normal* states. If the light's behavior doesn't match a state listed here, refer to the *Troubleshooting the Receiver* section.

Ready Light State	Meaning		
Off	The receiver is disconnected from the computer, or SMART Response Manager has placed the receiver into Off (PowerSave) mode.		
Solid red	The receiver has power, but it's not communicating with the computer.		
Solid green	The receiver is receiving power and communicating successfully with SMART Response.		

Troubleshooting the Receiver

CAUTION

Do not open the receiver or the clicker units to attempt repairs. Refer all service inquiries to authorized SMART service personnel.

Resetting the Receiver

If your SMART Response software behaves erratically (possibly because of a static discharge or power fade), you may be able to restore normal operation by resetting the receiver.

Reset the receiver completely by disconnecting and then reconnecting the USB cable.

Troubleshooting Using the Receiver Lights

Should you experience a problem with your receiver, you can use the receiver lights to troubleshoot it.

Ready Light	Transmit Light	Receive Light	Receiver State	
Red, green yellow	Green	Green	Receiver is starting up. Lights flash in sequence.	
Flashing green	Off	Off	Receiver is scanning radio channels.	
Blinking green	Any state	Any state	Receiver is accepting commands from the computer.	
Green	Constant flashing (approx. 250 ms)	Blinks when it receives data from a clicker	Receiver has power and is communicating with the computer, but isn't receiving commands.	
Yellow	Off	Off	Receiver has power, but communication circuits have failed.	
Flashing red	Flashing	Flashing	Manufacturing tests running, and receiver isn't operational. All lights flash together.	
Flashing yellow	Any state	Any state	Receiver software checksum failed.	
Flashing yellow	Flashing	Flashing	Receiver software failure.	

Other Troubleshooting Tips.

Symptom/Observation	Action/Remedy		
When you export SMART Response question set results from a SMART Notebook file using the comma separated values (CSV) command, fractions change to dates.	In your exported results convert the exported dates to fractions, add a space before each fraction and convert the month to its numerical value. The converted month is the fraction's numerator, and the day is the denominator.		
Your computer doesn't recognize SMART Response, and the receiver's status light remains solid red.	Remove the SMART Response hardware drivers on your computer, and then reconnect the receiver following the instructions in document 115401.		
Responses from SMART Response clickers don't appear in SMART Notebook software reports.	Wait at least 10 seconds after the last student responds before you stop a question set.		
Additional SMART Response receivers don't connect to the network when you install more than one receiver on your computer.	 Disconnect the additional receiver's USB plug to resume normal operation. Install only one receiver per 		
	 Disconnect and reconnect the first receiver's USB plug if it doesn't work, or if the LED light turns red. 		
	i NOTE Installing more than one receiver affects your computer's performance and doesn't increase your reception.		
During the installation of a SMART software product on the Windows XP SP2 operating system, a dialog box appears informing you that the installation was interrupted.	To prevent interruptions, restart the computer, and follow the procedure outlined in document 77681.		

Transporting SMART Response

If you need to ship your SMART Response hardware, repack it with as much of the original packaging as possible. If you prefer to use your own packaging materials, make sure you adequately protect the product.

Appendix A

Hardware Environmental Compliance

SMART Technologies supports global efforts to ensure that electronic equipment is manufactured, sold and disposed of in a safe and environmentally friendly manner.

Waste Electrical and Electronic Equipment Regulations (WEEE Directive)

Waste Electrical and Electronic Equipment regulations apply to all electrical and electronic equipment sold within the European Union.

When you dispose of any electrical or electronic equipment, including SMART Technologies products, we strongly encourage you to properly recycle the electronic product when it has reached end of its life. If you require further information, please contact your reseller or SMART Technologies for information on which recycling agency to contact.

Restriction of Certain Chemicals (REACH Directive)

The European Union has enacted the EU REACH Directive which restricts the use of certain chemicals in products. SMART Technologies is committed to complying with this initiative.

Restriction of Certain Hazardous Substances (RoHS Directive)

This product meets the requirements of the European Union's Restriction of Certain Hazardous Substances (RoHS) Directive 2002/95/EC.

Consequently, this product also complies with other regulations that have arisen in various geographical areas, and that reference the European Union's RoHS directive.

Batteries

74 |

Batteries are regulated in many countries. Check with your reseller to find out how to recycle used batteries.

Packaging

Many countries have regulations restricting the use of certain heavy metals in product packaging. The packaging used by SMART Technologies to ship products complies with applicable packaging laws.

Covered Electronics Devices

Many U.S. states classify monitors as Covered Electronic Devices and regulate their disposal. Applicable SMART Technologies products meet the requirements of the Covered Electronic Devices regulations.

China's Electronic Information Products Regulations

China regulates products that are classified as EIP (Electronic Information Products). SMART Technologies products fall under this classification and meet the requirements for China's EIP regulations.

U.S. Consumer Product Safety Improvement Act

The United States has enacted the *Consumer Product Safety Improvement Act* which limits the lead (Pb) content in products. SMART Technologies is committed to complying with this initiative.

Appendix B

Customer Support

Online Information and Support

Visit <u>www.smarttech.com/support</u> to view and download user's guides, how-to and troubleshooting articles, software and more.

Training

Visit <u>www.smarttech.com/trainingcenter</u> for training materials and information about our training services.

Technical Support

If you experience difficulty with your SMART product, please contact your local reseller before contacting SMART Technical Support. Your local reseller can resolve most issues without delay.

NOTE

To locate your local reseller, visit www2.smarttech.com/st/en-US/Where+to+Buy.

All SMART products include online, telephone, fax and e-mail support:

Online <u>www.smarttech.com/contactsupport</u>

Telephone +1.403.228.5940 or

Toll Free 1.866.518.6791 (U.S./Canada)

(Monday to Friday, 5 a.m. – 6 p.m. Mountain Time)

Fax +1.403.806.1256

E-mail <u>support@smarttech.com</u>

Shipping and Repair Status

Contact SMART's Return of Merchandise Authorization (RMA) group, Option 5, +1.866.518.6791, for shipping damage, missing part and repair status issues.

General Inquiries

Address SMART Technologies

3636 Research Road NW Calgary, AB T2L 1Y1

CANADA

Switchboard +1.403.245.0333 or

Toll Free 1.888.42.SMART (U.S./Canada)

Fax +1.403.228.2500

E-mail <u>info@smarttech.com</u>

Warranty

Product warranty is governed by the terms and conditions of SMART's "Limited Equipment Warranty" that shipped with the SMART product at the time of purchase.

Registration

To help us serve you, register online at www.smarttech.com/registration.

Contact SMART Technologies

Toll Free 1.866.518.6791 (U.S./Canada) or +1.403.228.5940

