

Document number: 00054577 Document revision: B Document title: Resusci Main Board Radio module Installation instructions



Figure 1. Resusci Main Board. Radio part within red line



Table of Contents

1.	Sco	ppe	3			
2. Application						
3.	3. Features					
4.	. Abbreviations					
5.	5. Dimensions					
6. Power						
6	1.	Sources	1			
6	.2.	Power source switching	1			
6	.3.	Board current consumption5	5			
7 Padia						
/.	nac		,			
7.	.1.	Antenna5	;			
7.	.2.	Integration radio module into Laerdal CPR manikins5	;			
8. Module label						
9.	Reg	gulatory Statements	1			
9.	.1.	FCC Statement:	1			
9.	.2.	FCC Important Notes:	1			
9.	.3.	IC Statement:	3			
Tab	ole d	of Figures				
Figure 1. Resusci Main Board. Radio part within red line						
Figu	Figure 2. Dimension in mm					



1. Scope

This document describes instructions of how to integrate PCA Resusci Main board radio module in a host device. The document covers the radio part of the module only. Internal Laerdal Medical documents covers the application related part of module.

2. Application

Resusci Main board is designed for integration in Laerdal Medical CPR manikins. It is not intended for integration by others than Laerdal Medical

3. Features

- Power management
- CAN interface
- Bluetooth Low Energy radio (BLE)
- USB interface
- Skillguide interface
- Sound output
- Control panel interface

4. Abbreviations

- BLE Bluetooth Low Energy
- SoC System on Chip
- CPR Cardiopulmonary resuscitation
- MCU Micro Controller Unit



5. Dimensions



Figure 2. Dimension in mm

6. Power

6.1. Sources

Battery:

Minimum battery voltage: 3,6V. Board is designed to use minimum 4 alkaline cells connected in series with a battery cutout voltage of 0,9V per cell Maximum battery voltage is 14V

USB power:

Input voltage 5V±5%

6.2. Power source switching

Circuit is designed to use USB power when this is present. Main MCU and BLE SoC will always be powered but will be in a low current mode (stop mode) when system is off. **Logic:**

USB voltage > ca.2,9V \rightarrow USB is source USB voltage < ca.2,9V \rightarrow Battery is source



6.3. Board current consumption

OFF mode: 65±10uA@Vin=6V ON mode (without CAN modules/control panel):28±3mA@Vin=6V

7. Radio

Based on Nordic Semiconductor nRF52832 Bluetooth v4.2 Integrated Antenna only Integrated DC-DC converter Radio is controlled by Nordic Semiconductor Softdevice version S132 Operating Frequency Range 1: 2402 MHz to 2480 MHz Modulation: GFSK Antenna Gain: -0,5dBi Overall highest e.i.r.p. : 0dBm Occupied bandwidth: 1,1 MHz Radio type: Adaptive equipment without possibility to change to non-adaptive

7.1. Antenna

Johanson Technology chip antenna 2450AT18A100

Mini 2.45 GHz	Antenna	P/N 2450AT18A100
Detail Specification:	7/18/2014	Page 1 of 4

General Specifications		
Part Number	2450AT18A100	
Frequency Range	2400 - 2500 Mhz	
Peak Gain	0.5 dBi typ. (XZ-V)	
Average Gain	-0.5 dBi typ. (XZ-V)	
Return Loss	9.5 dB min.	
Input Power	2W max. (CW)	
Impedance	50 Ω	
Operating Temperature	-40 to +125°C	
Reel Quanity	3,000	



7.2. Integration radio module into Laerdal CPR manikins

- For best range, place module so that metal parts are kept away from radio parts. Especially large
 grounded metal should be avoided. Small ungrounded parts as screws are not critical, but RF
 performance should be evaluated if placed closer than 5mm to antenna or antenna track from
 nRF52832.
- Metal enclosure covering antenna should not be used
- If module is to be co-located with other radio transmitters, regulatory approvals have to be reevaluated





8. Module label

FCC ID: QHQ 20-10494 IC: 20263-2010494 HVIN:Resusci Main Board PCA 20-10494

The label is located on the PCA. It is approximately 1 cm high and 2 cm wide – see picture below for label placement and size.

The HVIN (Resusci Main Board PCA 20-10494) is labeled on the board (see information encircled in picture below).





9. Regulatory Statements

Note: Regulatory Statements are for reference only pending the completion of testing and approvals. For this module, Laerdal Medical will be both the manufacturer and OEM integrator.

9.1. FCC Statement:

This device has been tested and found to comply with part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Operation is subjected to the following two conditions: (1) This device may no cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: Modification to this product will void the user's authority to operate this equipment.

Note: Modification to this product will void the users' authority to operate this equipment.

9.2. FCC Important Notes:

(1) FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment complies with Part 15 of the FCC Rules. Operation is subject the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

The devices must be installed and used in strict accordance with the manufacturer's instructions as described in this document.

Caution!

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modification could void the user authority to operate the equipment.

(2) Co-location Warning:



This device and its antenna(s) must not be co-located or operating in conjunction with any other transmitter antenna.

(3) OEM integration instructions :

This device is intended only for OEM integrators under the following conditions:

The antenna and transmitter must not be co-located with any other transmitter or antenna. The module shall be only used with the integral antenna(s) that has been originally tested and certified with this module.

As long as the two (2) conditions above are met, further transmitter testing will not be required. However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirements with this module installed (for example, digital device emission, PC peripheral requirements, etc.)

In the event that these conditions cannot be met (for example certain laptop configuration or co-location with another transmitter), then the FCC authorization for this module in combination with the host equipment is no longer considered valid and the FCC ID of the module cannot be used on the final product. In these and circumstance, the OEM integrator will be responsible for re-evaluating. The end product (including the transmitter) and obtaining a separate FCC authorization.

Caution!

The OEM is still responsible for verifying compliance with FCC Part 15, subpart B limits for unintentional radiators through an accredited test facility.

(4) End product labeling :

The final end product must be labeled in a visible area with the following:

• "Contains FCC ID: QHQ 20-10494"

Any similar wording that expresses the same meaning may be used.

The FCC Statement below should also be included on the label. When not possible, the FCC Statement should be included in the User Manual of the host device.

"This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions. (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation."

(5) Information regarding the end user manual :

The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module. The end user manual shall include all required regulatory information/warning as show in this manual (Section 15.2(4)).

9.3. IC Statement:

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.



Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF exposure warning: The equipment complies with RF exposure limits set forth for an uncontrolled environment. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Avertissement d'exposition RF: L'équipement est conforme aux limites d'exposition aux RF établies pour un incontrôlés environnement. L'antenne (s) utilisée pour ce transmetteur ne doit pas être co-localisés ou onctionner en conjonction avec toute autre antenne ou transmetteur.

15.4 IC Important Notes:

1. The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user manual of the end product. The user manual which is provided by OEM integrators for end users must include the following information in a prominent location.

2. To comply with IC RF exposure compliance requirements, the antenna used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter, except in accordance with IC multi-transmitter product procedures.

3. The final system integrator must ensure there is no instruction provided in the user manual or customer documentation indicating how to install or remove the transmitter module except such device has implemented two-ways authentication between module and the host system.

4. The host device shall be properly labelled to identify the module within the host device. The final end product must be labeled in a visible area with the following:

"Contains IC: 20263-2010494 "

Any similar wording that expresses the same meaning may be used.

The IC Statement below should also be included on the label. When not possible, the IC Statement should be included in the User Manual of the host device.

"This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le onctionnement."