Option 1: Aux In Cable Installation Instructions

1 Plug one end of the Aux In Cable into the green AUDIO connector on the dock.



- 2 Plug the other end into the auxiliary input jack connection of your vehicle's stereo system.
- 3 Insert your Stratus 6 into the dock, aligning the radio against the rear of the dock so that the rails on the dock fit into the mounting slots in the back of the radio.



Vehicle Installation

- 4 Power on your Stratus 6 by pressing the Power button.
- 5 Be sure the vehicle is outside and the antenna has a clear view of the sky. Verify that you are receiving the SIRIUS signal. There should at least be one bar on the upper right corner of the main display screen that denotes antenna signal strength. You can also

press and hold **menu** and then press $\mathbf{\nabla}$ to scroll to and highlight **Signal**.

Press the **Select button**. The Satellite and Terrestrial bars show the strength of the signal being received. If the signal reception is good, press and hold **menu** to return to the main display screen.

- 6 Ensure that the Stratus 6 is tuned to channel 184. Upon power up, the Stratus 6 should tune to channel 184 by default, when it's not yet activated. If it's not on channel 184, refer to "Listening to Satellite Radio" on page 62 to learn about how to tune a channel.
- 7 Turn on your vehicle's stereo system. Set it to play input from the auxiliary input source.
- You should hear SIRIUS channel 184 through your vehicle's stereo system. You are now ready to activate your Stratus 6.
- 9 The audio level output of the Stratus 6 can be increased or decreased as necessary to match the audio levels of other sources in your vehicle. Refer to "Audio Level" on page 84.





If the signal reception is good, but there is no audio when tuned to channel 184, be sure the vehicle's stereo system is set to the correct source, i.e., auxiliary input source (step 7). Also be sure that the audio level is set high enough to be heard (step 9). Refer to "Troubleshooting" on page 88 for additional help.

Vehicle Installation

Option 2: Cassette Adapter Installation Instructions

- Plug the Cassette Adapter into the green AUDIO connector on the dock.
- 2 Insert the Cassette Adapter in the vehicle's cassette deck. You may need to turn on your vehicle's stereo system in order to do so.



3 Insert your Stratus 6 into the dock, aligning the radio against the rear of the dock so that the rails on the dock fit into the mounting slots in the back of the radio.



- 4 Power on your Stratus 6 by pressing the Power button.
- 5 Be sure the vehicle is outside and the antenna has a clear view of the sky. Verify that you are receiving the SIRIUS signal. There should at least be one bar on the upper right corner of the main display screen that denotes antenna

signal strength. You can also press and hold **menu** and then press ▼ to scroll to and highlight **Signal**. Press the **Select button**. The

Satellite and Terrestrial bars show the strength of the signal being received. If the signal reception is good, press and hold **menu** to return to the main display screen.



Satellite Radio" on page 62 to learn about how to tune a channel.

- 7 If you haven't done so, turn on your vehicle's stereo system. Set it to play input from the cassette source.
- 8 You should hear SIRIUS channel 184 through your vehicle's stereo system. You are now ready to activate your Stratus 6.
- 9 The audio level output of the Stratus 6 can be increased or decreased as necessary to match the audio levels of other sources





in your vehicle. Refer to "Audio Level" on page 84.

If the signal reception is good, but there is no audio when tuned to channel 184, be sure the vehicle's stereo system is set to the correct source, i.e., cassette source (step 7). Also be sure that the audio level is set high enough to be heard (step 9). Refer to "Troubleshooting" on page 88 for additional help.

Option 3: *Power*Connect Installation Instructions

- Insert your Stratus 6 into the dock, aligning the radio against the rear of the dock so that the rails on the dock fit into the mounting slots in the back of the radio.
- 2 Power on Stratus 6 radio by pressing the **Power button**.
- 3 Be sure the vehicle is outside and the antenna has a clear view of the sky. Verify that you

are receiving the SIRIUS signal. There should at least be one bar on the upper right corner of the main display screen that denotes antenna signal strength. You can also press and hold **menu** and then press \checkmark to scroll to and highlight **Signal**. Press the **Select button**. The Satellite and Terrestrial bars show the strength of the signal

being received. If the signal reception is good, press and hold **menu** to return to the main display screen. You are ready to make the audio connection.







Vehicle Installation

- 4 You'll first need to find an available FM channel. An available FM channel is one that's not being used by an FM radio station in your area. When you tune your FM radio to an available channel, you should only hear static or silence not talk or music. We recommend one of the following methods to find an available FM channel:
 - a. Use the SIRIUS | XM FM Channel Finder at www.sirius.com/ fmchannel. Go to the website and enter your zip code. The Channel Finder will suggest a list of available FM channels in your area. For convenience, write down or print out the list.

OR

b. Manually tune through your local FM channels on your vehicle's FM radio. Locate and create a list of channels that aren't being used by any FM radio station. Write down the list. Once you have created your list of available FM channels, you will need to find the one that provides the best match for your Stratus 6.



TIP! You'll need to use the 'Manual' tune function on your vehicle's FM radio to tune through every FM channel one-by-one. Turn on your vehicle's FM radio. Start at 88.1 and use the 'Manual' tune function on your vehicle's FM radio to tune through each FM channel one-by-one (88.1 followed by 88.3 etc.) to locate channels that aren't being used by a local FM radio station. Write down each FM channel that has only static or silence on it, until you reach 107.9.

5 Ensure that the Stratus 6 is tuned to channel 184. Upon power up, the Stratus 6 should tune to channel 184 by default, when it's not yet activated. If it's not on channel 184, refer to "Listening to Satellite Radio" on page 62 to learn about how to tune a channel.

• Pick the first FM channel on your list from step 4. Turn on your vehicle's FM radio (if you have not already done so) and tune it to this FM channel.



- 7 Set your Stratus 6 to transmit on the same FM channel that you have selected in step 4:
 - i. Press and hold menu until the menu options are displayed.
 - ii. Press ▼ to scroll to and highlight FM Settings and press the Select button.
 - iii. FM Channels will be highlighted. Press the Select button.
 - iv. Press \bigtriangledown to scroll to and highlight the storage location FM2. Press the **Select button**.
 - v. Tune to the FM channel you found in step 3. Press ▼ and ▲ to to 99.5. Press ◀ and ▶ to tune in steps of 1, i.e., 99.3 to 100.3. Press the Select button to select the FM channel.

Vehicle Installation

vi. The FM channel you selected will be confirmed on the display screen. The Stratus 6 will tune to the FM channel.



vii. Press and hold menu to exit.

- **9** You should hear SIRIUS channel 184 through your vehicle's FM radio. If you are satisfied with the sound quality, you're done! You are now ready to activate your Stratus 6.
- **10** If the selected FM channel doesn't work well for you, work down the list of FM channels until you find one that allows you to hear SIRIUS clearly. Each time, you will need to tune your vehicle's FM radio to the FM channel and then set your Stratus 6 to transmit on the same FM channel (steps 6 & 7).

If the signal reception is good, but there is no SIRIUS audio when tuned to channel 184, verify that both the radio and your vehicle's FM radio are tuned to the same FM channel (steps 6 & 7). Also ensure the chosen FM channel is a suitable one to use in your area (step 4). Verify that nothing is plugged into the **AUDIO** connector on the *Power*Connect Vehicle Dock. Refer to "Troubleshooting" on page 88 for additional help.

Option 4: FM Direct Adapter (FMDA) Installation

The FMDA needs to be installed by a professional installer. Professional installation can help improve your radio's reception and significantly reduce the visibility of wires. To learn more, check with the retailer where you bought your radio, or go to sirius.com/accessories.

Activation

Before you can enjoy Commercial-Free Music, plus Sports, News, Talk & Entertainment, you need to activate your Stratus 6:

- 1 Make sure your Stratus 6 is properly installed, turned on, and receiving the SIRIUS signal so that you can hear the audio on channel 184.
- 2 When you first turn on the Stratus 6, after the startup sequence, the SIRIUS channel lineup may update. Wait until any channel updates have completed before pressing any buttons. Once the channels have been updated, the radio will automatically tune to channel 184.
- 3 Make a note of the SIRIUS ID. You can find it:
 - on channel O (zero)
 - on a label on the bottom of the gift box
 - on the label on the back of your Stratus 6.
- **4** Activate your service:
 - Online: Go to www.sirius.com and click on "Install and Activate" OR
 - By phone: Call 1-888-539-SIRIUS 1-888-539-7474)
- 5 When your service is activated, your Stratus 6 will display an alert message. To continue, press any

Channel Updates 20% Completed

000 Sirius ID " SID 123456789012

184 Meather л Sub Updated ress Any Key

button. Thereafter, if you press \blacktriangle or \bigtriangledown , you can scroll and tune other channels. Activation usually takes less than 5 minutes, but sometimes may take longer. We recommend that your radio remain on until activated.

Using Your Stratus 6

The Main Display

Whenever you power your Stratus 6 On, it will automatically tune to the last channel you were listening to before it was powered Off. The Stratus 6's display screen will show the channel number, the song or show being played, and the artist name of the current channel. This screen is referred to as the main display screen in this guide.



You can also choose to have either the channel name or category name displayed on the main display screen. To pick the mode, press and hold the **menu** button, press the ▼ button to highlight **Display** and press the **Select button**. Press the ▼ button to highlight **Mode** and press the **Select button**. Then choose the desired option. (Refer to "Display" on page 82.)

072 RealJazz "	072 JzStndrd al
Luther Hu9hes An	Luther Hu9hes An
Spectacular	Spectacular
Channel Name	Category Name

My Channels

Channels are organized into categories to make it easier for you to find the ones that suit your taste. My Channels is a special category that displays the channels contained in your subscription plan. You can display this and any category by pressing \blacktriangleleft or \blacktriangleright until the category is displayed.

Category Name — My Channels(151) Channel Names — 2001 Hits 1 002 TheBlend

Using Your Stratus 6

Navigation Basics

Power Button

Pressing the **Power button** turns the Stratus 6 On or Off.

Navigation Buttons

Use the Left, Right, Up, and Down buttons to navigate through various features and functions of Stratus 6.

- Left < or Right button: Displays the channel categories such as Rock, Pop. Sports, Talk/New etc. Repeated presses cycle through the categories one at a time. Decreases or increases the settings of various menu options such as Brightness, Audio Level, etc.
- Up \blacktriangle or Down \checkmark button (press and release): Immediately tunes to the next or previous channel in the channel lineup. Scrolls through lists and highlights an item in the list.
- Up A or Down V button (press and hold): Continuously scrolls through any list. While on the main display screen, continuously scrolls through the channel lineup and briefly displays the information of each channel. When the button is released, radio tunes to the last channel it had scrolled to in the channel lineup.

Select Button

The **Select button** selects a highlighted item and confirms settings. At the main

sel



display screen, pressing the **Select button** prompts for the entry of a channel number using the number buttons. Once the channel number is entered, the radio directly tunes to the new channel. At the main display screen, pressing and holding the **Select button** tunes to the previous channel that was being played.

FM/Menu Button

FM provides easy tuning of FM presets for optimized *Power*Connect performance. Repeatedly pressing FM displays and cycles through the list of preset FM channels one at a time. The radio automatically tunes to the displayed FM channel.

Pressing and holding **menu** displays various options to make setup and feature changes. Pressing **menu** when in menu options returns to the previous menu option screen until menu options is exited. Pressing and holding **menu** when in menu options returns to the main display screen.

Jump Button

Pressing **jump** tunes to the channel broadcasting traffic and weather conditions for the 20 most congested cities.

Number Buttons

Each number button stores a favorite channel in its button location and provides one touch access to it afterward. Number buttons also directly tune to a channel when the channel number is entered after pressing the **Select button**.







Using Your Stratus 6

Listening to Satellite Radio

Tune a channel:

- Press and release ▲ and ▼ to immediately tune to the next or previous channel.
- 2 Press and hold ▲ and ▼ to speed scroll through the channels. Release to tune to channel which is displayed.

View a category:

Channels are organized into categories to make it easier for you to find the ones that suit your taste.

- 1 To view a category press \blacktriangleleft or \blacktriangleright .
- Scroll through the channels in the category using ▲ and ▼, and find the channel you want.
- 3 Press the Select button to select the channel, or press ◀ or ▶ for the previous or next category.

POP Hits 1 >001 002 TheBlend

Rock >014 ClsVinyl 015 ClsRewnd

Dance/Electronic >035 Chill 036 BPM

Direct Tune

A channel can be tuned directly by entering the channel number using the number buttons.

1 To directly tune a channel press the Select button.



2 Enter the channel number using the buttons 0-9. Wait a moment until the channel is tuned, or press the **Select button** to immediately tune to the channel.

Using Your Stratus 6

Jump

Pressing **jump** will tune to the traffic and weather channel of one of the 20 most congested cities. This button allows you to quickly tune the traffic/weather broadcast for one of these cities, and then tune back to the original channel to which you were listening by pressing **jump** again.



If the traffic/weather broadcast of your selected city is not immediately available,

the display will indicate that a jump is pending. Once the traffic/weather report is ready to be broadcast, the radio will automatically tune to the traffic/weather channel. Since a channel may carry the traffic and weather reports of more than one city, you may have to wait a few minutes for your desired broadcast.



Pressing the **jump** while a jump is pending will cancel the jump. Pressing **jump** after the radio has tuned to the traffic/weather channel will return it back to the channel you to which you had been listening immediately prior to pressing **jump**.



TIP! To select a city for traffic/weather, refer to "Jump Settings" on page 81.

Returning to main display screen

When changing the radio options using the menu options, pressing and holding **menu** in most instances will return you to the main display screen. In some instances, you may need to follow the instructions on the display screen.

Favorite Channels

You can set up to 10 of your favorite channels so you can easily access them. Each favorite channel can be assigned to a number button (**0-9**).

To assign a favorite channel to a number button:

- 1 Tune to the desired channel.
- Press and hold a number button (0-9) for one second, to assign the channel as a favorite.

To listen to a favorite channel:

1 Press the number button **0-9** that was assigned to the desired favorite channel.

Using Your Stratus 6

FM Presets

FM presets make it easy to quickly access stored FM channels and choose a new FM channel from them.

Use FM presets when you use *Power*Connect to listen to your Stratus 6 through your vehicle's FM radio.

To start using a different FM preset:

- 1 Press FM to display the current FM channel preset.
- 2 The currently selected FM preset is shown. To display and select the next FM preset press FM.
- 3 Repeatedly pressing FM will cycle through the FM presets. The last displayed FM preset will be tuned. To return to the main display screen, allow the screen to time out.



IMPORTANT! You need to ensure that

the FM Transmitter in the Stratus 6 is turned On, and that your vehicle's FM radio is tuned to the same FM channel.



TIP! To configure the list of preset FM channels, you need to find available FM channels in your area. Refer to "Find Available FM Channels in Your Area" on page 75. Next, refer to "Set and Select an FM Channel" on page 79.

Special Features

Parental Lock

Your Stratus 6 has the ability to lock channels you do not want others (such as children) to access without your permission. Locked channels will not appear in the channel or category list. The default lock code is 0000.

Locked channels can be tuned directly using the 0-9 number buttons and entering the locked channel number. You will be prompted to enter your lock code. If the lock code is correctly entered, the channel will begin playing. If you tune away from the locked channel to a different channel, the locked channel will again be locked.

Changing the lock code:

- 1 Press and hold menu until the menu options are displayed.
- 2 Press ▼ to scroll to and highlight Parental Lock and press the Select button.
- 3 Press ▼ to scroll to and highlight Change My Code and press the Select button.
- 4 You will be prompted to enter the existing lock code. The default lock code is 0000. If this is the first time you are changing the lock code, enter 0000, otherwise enter your lock code. Use the 0-9 number buttons to enter the code and press the Select button.



- **5** Enter a new 4 digit code using the **0-9** number buttons.
- Once you have entered the code you will then be prompted to enter the new code again to confirm. If you entered the same lock code again, the code is saved.
- 7 Press and hold menu to exit.



Confirm Code Code Saved

To lock or unlock a channel:

- 1 Press and hold menu until the menu options are displayed.
- 2 Press ▼ to scroll to and highlight Parental Lock and press the Select button.
- 3 Lock/Unlock is highlighted. Press the Select button.
- 4 You will be prompted to enter your 4 digit lock code. Enter the lock code using the **0-9** number buttons.





5 When you have entered the correct code, a list of channels will be displayed. Press ▼ and ▲ to scroll though the list and highlight a channel you want to lock or unlock.

6 Press the Select button to lock or unlock a channel. Note that locked channels will display a lock icon a to the right of the channel name.



7 You can continue to select channels for locking or unlocking. When you are finished, press and hold **menu** to exit.

Where Else Can You Use Your Stratus 6?

SIRIUS | XM offers a variety of accessories that allow you to adapt your Stratus 6 Radio to your lifestyle and enhance your listening experience. With these accessories, you can effortlessly take your Satellite Radio listening experience from your vehicle to your home or office or on the go – all with a single subscription.

- In the Home, Office, etc. With a Home Kit, you can play your Stratus 6 over an existing home, office, or other stereo system.
- In Other Vehicles With a Vehicle Kit, you can enjoy your Stratus 6 in more than one vehicle.
- In Almost Any Location You Like With a desktop or portable Sound System you have the freedom to listen to your Stratus 6 where and when you want, from your kitchen or den, to the office, to outside on the deck, or at a picnic.

For more information on SIRIUS accessories or to purchase an accessory, please visit your local retailer or www.sirius.com/accessories.

onfiguring Your Stratus 6

Configuring Your Stratus 6

Sirius ID

Your Stratus 6 has a numeric 12-digit ID which uniquely identifies the radio. This ID is used during the activation process.

To display the Sirius ID:

- 1 Press and hold menu until the menu options are displayed.
- 2 Sirius ID will be highlighted. Press the Select button. The Radio ID will be displayed.



3 Press and hold menu to exit.

Find Available FM Channels in Your Area

Before attempting any of the procedures below, you should park your vehicle in a safe location. Do not attempt to set up your FM channels or any Stratus 6 function while driving.

PowerConnect allows you to listen to SIRIUS audio through your vehicle's FM radio. You will first need to find an available FM channel, which is a channel that is not being used by an FM radio station in your area. When you tune your FM radio to an available channel, you should only hear static or silence – not talk or music.

Once you have found an available channel, you need to tune the Stratus 6's built-in transmitter to the same channel to receive SIRIUS sound through your vehicle's radio.

We recommend one of the following methods to find an available FM channel:

1 Use the SIRIUS | XM FM Channel Finder

Use the SIRIUS | XM FM Channel Finder at **www.sirius.com/ fmchannel**. Go to the website and enter your zip code. The Channel Finder will suggest a list of available FM channels in your area. For convenience, write down or print out the list.

Tune the Stratus 6 to a favorite SIRIUS channel (or to channel 184, if it's not yet activated). Turn on your vehicle's FM radio. Pick the first FM channel on your Channel Finder list and tune the FM radio to that channel. If you do not hear a local FM station broadcast, then tune the Stratus 6 to the same FM channel. (Refer to "Set

Configuring Your Stratus 6

and Select an FM Channel" on page 79.) You should hear the SIRIUS channel through your vehicle's radio. If you are satisfied with the sound quality, you're done! If this FM channel doesn't work well for you, work down the list until you find an FM channel that allows you to hear SIRIUS clearly.

OR

2 Manually tune through your local FM channels

Manually tune through your local FM channels on your vehicle's FM radio. Turn on your vehicle's FM radio. Start at 88.1 and use the 'Manual' tune function on your vehicle's FM radio to tune through each FM channel one-by-one (88.1 followed by 88.3 etc.) to locate channels that aren't being used by a local FM radio station. Write down each FM channel that has only static or silence on it, until you reach 107.9. Once you have created your list of available FM channels, you will need to find the one that provides the best match for Stratus 6.

Tune the Stratus 6 to a favorite SIRIUS channel (or to channel 184, if it's not yet activated). Pick the first FM channel on your list and tune the FM radio to that channel. Then tune the Stratus 6 to the same FM channel. (Refer to "Set and Select an FM Channel" on page 79.) You should hear the SIRIUS channel through your vehicle's radio. If you are satisfied with the sound quality, you're done! If this FM channel doesn't work well for you, work down the list until you find an FM channel that allows you to hear SIRIUS clearly.



NOTE! You may find an FM channel with static or silence that does not work with the Stratus 6. It is possible that some type of inaudible interference is present that prevents reception of the Stratus 6 broadcast. Your only options are to use another FM channel or a different audio connection method.



TIP! If you regularly drive from one location to another, such as your daily commute, you may need to use different FM channels along your route for best performance. If this is the case, we recommend saving the best FM channels as presets on your FM radio and Stratus 6. Then you simply select and match the best channel for the area you are in.



TIP! It will be much more difficult to find available FM channels in large cities than in most suburban or rural locations. A direct audio connection using the Aux In Cable, Cassette Adapter, or professional installation is your best solution if you drive in or near large metropolitan areas.



NOTE! The SIRIUS | XM FM Channel Finder relies on data from the Federal Communications Commission. The data may not reflect the latest stations in your area. In addition, local geography and weather conditions can impact reception, so your results may be different from the list.



NOTE! The performance of FM radios are different, based on manufacturer and vehicle style. Some may not work well with the type of FM transmitter used by the Stratus 6. This is why we recommend a direct audio connection using the Aux In Cable or Cassette Adapter if they can be used in your vehicle. Professional installation can also resolve almost any performance issue.

Configuring Your Stratus 6

Turn FM Transmitter On/Off

The built-in FM Transmitter in the Stratus 6 works with the *Power*Connect Vehicle Dock, and is used when you choose to listen to the Stratus 6 through your vehicle's FM radio.

To turn the FM Transmitter On or Off:

- 1 Press and hold **menu** until the menu options are displayed.
- 2 Press ▼ to scroll to and highlight FM Settings and press the Select button.
- 3 Press ▼ to scroll to and highlight FM Transmitter and press the Select button.
- 4 Press either ▼ or ▲ to scroll to and highlight either On or Off and press the Select button.

FM Transmitter >∩n Off

5 Press and hold menu to exit.



TIP! The Stratus 6 is shipped with the FM Transmitter turned On by default.



TIP! The FM1 storage location is preset with FM channel 97.9.

Set and Select an FM Channel

The Stratus 6 allows you to easily store (i.e., preset) up to 5 different FM channels. At any time, you can select any one of these 5 FM presets to transmit audio from the Stratus 6 to your vehicle's FM radio. Having a choice of 5 FM presets also makes it easy to switch to the appropriate FM channel as you travel from one area to another. Each FM preset is stored in its own storage location. You can easily add or edit the FM preset in any one of the 5 storage locations.



TIP! The FM1 storage location is preset with FM channel 97.9.

To set an FM preset:

- 1 Press and hold **menu** until the menu options are displayed.
- 2 Press ▼ to scroll to and highlight FM Settings and press the Select button.
- 3 FM Channels will be highlighted. Press the Select button.
- 4 Press ▼ to scroll to and highlight the storage location (FM1 to FM5) that you want to set or select, and press the Select button.



5 Change the FM Channel for the selected storage location by

Configuring Your Stratus 6

pressing \checkmark and \blacktriangle to tune in steps of .2, i.e., 99.3 to 99.5, and pressing \checkmark and \triangleright to tune in steps of 1, i.e., 99.3 to 100.3. Press the **Select button** to select the FM channel. The FM channel you selected will be confirmed on the display screen and the Stratus 6 will tune to the FM channel.

6 Set your vehicle's FM radio to same FM channel.



IMPORTANT! You first need to find available FM channels in your area. Refer to "Find Available FM Channels in Your Area" on page 75.

To quickly select an FM channel from the preset list:

- 1 Press FM to display the current FM channel preset.
- 2 The currently selected FM preset is shown. To display and select the next FM preset press FM.
- 3 Repeatedly pressing FM will cycle through the FM presets. The FM channel displayed will be selected. To return to the main display screen, allow the screen to time out.
- 4 Set your vehicle's FM radio to the same FM channel.

Jump Settings

Jump can be set to jump to the traffic and weather channel of one of the 20 most congested cities. You'll need to select the desired city from the list.

To configure jump:

- 1 Press and hold **menu** until the menu options are displayed.
- 2 Press ▼ to scroll to and highlight Jump Settings and press the Select button.
- 3 A list of cities will be displayed. Press ▼ or ▲ to scroll to and highlight your desired location and press the Select button.
- 4 Press and hold menu to exit.



Configuring Your Stratus 6

Display

The Display option allows you adjust the brightness and contrast of the Stratus 6's display to improve its visibility in different lighting conditions. You also can set the mode of the display screen to show channel name or category name information.

To change the display's brightness or contrast:

- 1 Press and hold menu until the menu options are displayed.
- 2 Press ▼ to scroll to and highlight **Display** and press the **Select button**.
- 3 Press the Select button to choose Brightness or press ▼ to scroll to and highlight Contrast and press the Select button.
- Bri9htness - IIIIIIIIIIIIIII +
- 4 Press ◀ or ▶ to decrease or increase the brightness/contrast of the display.
- 5 Press the Select button to confirm the brightness setting.
- 6 Press and hold menu to exit.



To change the display screen mode:

- 1 Press and hold menu until the menu options are displayed.
- 2 Press ▼ to scroll to and highlight **Display** and press the **Select button**.
- 3 Press ▼ to scroll to and highlight Mode and press the Select button.



4 Press ▼ or ▲ to scroll to and highlight Channel Name or Category Name and press the Select button.

Channel Name displays the name of the channel at the top of the display screen, and Category Name displays the name of the category for the currently tuned channel.



Channel Name



Category Name

5 Press and hold menu to exit.

Configuring Your Stratus 6

Audio Level

The audio level of the Stratus 6 can be adjusted when an audio connection is made between the dock and the vehicle's stereo system. Audio level is used to adjust the Stratus 6's volume level to match the volume of other audio sources you may use, such as a CD player, other FM stations, or an MP3 player.

Do not use the audio level as a volume control. Use the volume control on your vehicle stereo instead.

To adjust the audio level:

- 1 Press and hold menu until the menu options are displayed.
- 2 Press ▼ to scroll to and highlight Audio Level and press the Select button.
- 3 Press ◀ to decrease or ▶ to increase the audio level.
- **4** Press the **Select button** to confirm the new audio level setting.



5 Press and hold menu to exit.

Signal

For best reception, your Magnetic Mount Antenna should have an unobstructed view of the SIRIUS satellites. In large cities, terrestrial transmitters (ground repeaters) help increase the signal coverage.

Your Stratus 6 can display the received strength of the satellite and terrestrial signals being received.

To display the signal strength:

Press and hold menu until the menu options are displayed.

- 1 Press and hold **menu** until the menu options are displayed.
- 2 Press ▼ to scroll to and highlight Signal and press the Select button.
- **3** The Satellite and Terrestrial bars show the strength of the signal being received.



- 4 Reposition the antenna if you are having trouble getting a signal. Be sure your vehicle is outside with an unobstructed view of the sky.
- 5 Press and hold menu to exit.

Factory Default

You can clear all of your personal settings, such as favorite channels, and return the radio to its original out-of-the-box settings.

To restore the Stratus 6 to the factory defaults:



NOTE! Restoring defaults permanently removes all personal settings.

- 1 Press and hold **menu** until the menu options are displayed.
- 2 Press ▼ to scroll to and highlight Factory Default and press the Select button.
- 3 Press ▲ to scroll to and highlight Yes and press the Select button.
- 4 A warning screen will be displayed. If you are certain that you want to reset your Stratus 6 to the factory defaults, press ▲ to scroll to and highlight Yes and press the Select button.
- 5 The radio will display Restoring, and will be restored to the factory settings.
- 6 Press and hold menu to exit.

Restorin9

Troubleshooting

Troubleshooting

Stratus 6 has been designed and built to be trouble-free but if you experience a problem, try this:

- Check that all connections are firm and secure.
- Make sure the vehicle power socket is clean and free of corrosion.
- Make sure you have connected the Stratus 6 as described in this User Guide. Verify that the *Power*Connect Power Adapter is plugged into the vehicle's cigarette lighter or power adapter socket, and that the LED on the *Power*Connect Power Adapter is lit (on). If not, your vehicle may need to be running to provide power to the socket.

If you see this on the screen:	Try this:
Acquiring Signal	 Make sure that the vehicle is outdoors with a clear view of the sky. Make sure the Magnetic Mount Antenna is mounted outside of the vehicle
	 Move your Magnetic Mount Antenna away from any obstructed area. For example, if you are parked in an underground garage, you should receive a signal after leaving the garage.
Check Antenna Connection	 Make sure that the antenna cable is firmly and securely plugged into the <i>Power</i>Connect Vehicle Dock. Make sure the cable is not bent or broken. If the message persists, most likely the Magnetic Mount Antenna cable has been damaged. Replace the antenna.

If you see this on the screen:	Try this:
Invalid Channel	 You have attempted to tune to a channel that you have not subscribed to, or does not exist. Select a channel to which you have subscribed.
Firmware Updating	 Your Stratus 6 is being updated over the air with the latest software. Wait until the update is done.
If this happens:	Try this:
You do not receive all the SIRIUS channels to which you have subscribed	 Ensure that you have followed the proper activation process. Refer to "Activation" on page 54. Call 1-888-539-7474 for further assistance.
No audio when using the Aux In Cable or Cassette Adapter	 Check all cables between your Stratus 6 and your vehicle's stereo system for a firm and secure connection. Ensure you have selected the proper input source on your vehicle's stereo system.
No audio when using <i>Power</i> Connect or FMDA	 Check that your Stratus 6 and your vehicle's FM radio are tuned to the same FM channel.
Audio sounds too soft	• Raise the volume of your stereo system or increase the audio level of your Stratus 6 until the sound quality improves. Refer to "Audio Level" on page 84.

Troubleshooting

If this happens:	Try this:
Audio fades or has static when listening	 Check all cables for a firm and secure connection. If you are using <i>Power</i>Connect to listen via your vehicle's FM radio, and the problem persists, it most likely is interference from another commercial or broadcast FM station. You will need to find an unused or available FM channel in your area. Refer to "Find Available FM Channels in Your Area" on page 75. If you are using <i>Power</i>Connect, and you cannot solve the audio problem, try connecting the audio using the Aux In Cable or a Cassette Adapter. (Refer to page 41 and page 44.) If you cannot use those solutions, consider using an FM Direct Adapter. (Refer to page 51.)
No song title or artist name is displayed	• The information may not be available or updates may be in progress.

Product Specifications

Product Specifications

114 mm (W) X 48 mm (H) X 15 mm (D) 4.5 in (W) X 1.9 in (H) X 0.6 in (D)
85 g (3.0 oz)
3.5 mm diameter mini stereo jack
5V DC
1.5 A

Patent Information

It is prohibited to, and you agree that you will not, copy, decompile, disassemble, reverse engineer, hack, manipulate, or otherwise access and/or make available any technology incorporated in this product. The music, talk, news, entertainment, data, and other content on the Services are protected by copyright and other intellectual property laws and all ownership rights remain with the respective content and data service providers. You are prohibited from any export of the content and/or data (or derivative thereof) except in compliance with applicable export laws, rules and regulations. The user of this or any other software contained in a SIRIUS | XM radio is explicitly prohibited from attempting to copy, decompile, reverse engineer, hack, manipulate or disassemble the object code, or in any other way convert the object code into human-readable form.

Environmental Information

Follow local guidelines for waste disposal when discarding packaging and electronic appliances.

FCC Statement

The user is cautioned that changes or modifications not expressly approved by SIRIUS XM Radio Inc. can void the user's authority to operate this device.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.

2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the installation instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna of the affected receiver.
- Increase the separation between the SIRIUS | XM equipment and the affected receiver.
- Connect the SIRIUS | XM equipment into an outlet on a circuit different from that to which the affected receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING! The FCC and FAA have not certified this Satellite Radio Receiver for use in any aircraft (neither portable nor permanent installation). Therefore, SIRIUS | XM Radio Inc. cannot support this type of application or installation.

Copyrights and Trademarks

©2009 SIRIUS XM Radio Inc. SIRIUS, XM and all related marks and logos are trademarks of SIRIUS XM Radio Inc. and its subsidiaries. All other marks and logos are the property of their respective owners. All rights reserved. Visit sirius.com/siriuslineup for updates. All programming/channel lineup/SIRIUS service subject to change or preemption. Hardware, subscription and activation fee required. Other fees and taxes will apply. Month-to-month subscriptions must be activated via telephone. Hardware and subscription sold separately. Subscription governed by SIRIUS Terms & Conditions, which can be found at sirius.com/serviceterms. Prices and programming are subject to change. SIRIUS | XM Radio U.S. service only available in the 48 contiguous United States and the District of Columbia.

Owners Record

Owner's Record

The model number is located below and the SIRIUS ID is located on the label on the back of the Stratus 6.

Record the SIRIUS ID in the space provided below. Refer to these numbers whenever you call your dealer regarding this product.

Model Number: SDSV6

SIRIUS ID:_____

sirius.com

SIRIUS XM Radio Inc. 1221 Avenue of the Americas New York, NY 10020

1.888.539.7474

© 2009 SIRIUS XM Radio Inc.

SDSV6UG 081609b